

A  
B  
C  
D  
E

## CONTENTS

### FUNDAMENTALS

<b>SERVICE INFORMATION</b> .....	<b>6</b>
<b>SHEET METAL WORK</b> .....	<b>6</b>
<b>SHEET METAL WORK TOOLS</b> .....	<b>6</b>
SHEET METAL WORK TOOLS : Sheet Metal Work Tools .....	6
SHEET METAL WORK TOOLS : Hammers .....	6
SHEET METAL WORK TOOLS : Dollies .....	8
SHEET METAL WORK TOOLS : How to Use Hammer and Dolly .....	11
SHEET METAL WORK TOOLS : Spoons .....	14
SHEET METAL WORK TOOLS : Scribing Chisels... .....	16
SHEET METAL WORK TOOLS : Types and Uses of Tinman's Shears .....	18
SHEET METAL WORK TOOLS : Tools for Pulling... .....	19
<b>SHRINKING THE SHEET METAL</b> .....	<b>22</b>
SHRINKING THE SHEET METAL : Shrinking The Sheet Metal .....	22
SHRINKING THE SHEET METAL : Shrinking Methods .....	22
SHRINKING THE SHEET METAL : How to Heat Sheet Metal .....	24
<b>CORRECTING A DEFORMED PANEL</b> .....	<b>25</b>
CORRECTING A DEFORMED PANEL : Determining Panel Damage .....	25
CORRECTING A DEFORMED PANEL : Basic Types of Damage .....	26
CORRECTING A DEFORMED PANEL : Examination of Panel Damage .....	26
CORRECTING A DEFORMED PANEL : Elastic VS. Plastic Deformation .....	28
CORRECTING A DEFORMED PANEL : Basic Repair Procedure .....	28
<b>COLORED SHEET METAL WORK</b> .....	<b>31</b>
COLORED SHEET METAL WORK : Colored Sheet Metal Work .....	32

COLORED SHEET METAL WORK : Confirmation of The Panel .....	32
COLORED SHEET METAL WORK : Selection of Repair Tools .....	33
COLORED SHEET METAL WORK : Panel Repair Methods .....	33
COLORED SHEET METAL WORK : Polishing of Panel Surface and Anti-corrosive Treatment .....	35
COLORED SHEET METAL WORK : Examination of Panel .....	35
<b>BODY WELDING AND PRECAUTIONS</b> .....	<b>36</b>
<b>OUTLINE OF WELDING</b> .....	<b>36</b>
OUTLINE OF WELDING : Features of Welding .....	36
OUTLINE OF WELDING : Welding of Automobile Body .....	36
<b>ELECTRIC RESISTANCE SPOT WELDING</b> .....	<b>37</b>
ELECTRIC RESISTANCE SPOT WELDING : Principles of Spot Welding .....	37
ELECTRIC RESISTANCE SPOT WELDING : Features of Spot Welding .....	37
ELECTRIC RESISTANCE SPOT WELDING : Construction of Spot Welder .....	38
ELECTRIC RESISTANCE SPOT WELDING : Cooling Methods .....	38
ELECTRIC RESISTANCE SPOT WELDING : Spot Welding Gun .....	38
ELECTRIC RESISTANCE SPOT WELDING : Multi-functional Type Spot Welder .....	39
ELECTRIC RESISTANCE SPOT WELDING : Process of Spot Welding .....	39
ELECTRIC RESISTANCE SPOT WELDING : Condition of the Panel .....	40
ELECTRIC RESISTANCE SPOT WELDING : Precautions when Performing Spot Welding .....	41
ELECTRIC RESISTANCE SPOT WELDING : Inspection of Welded Portion .....	43
<b>ARC WELDING</b> .....	<b>44</b>
ARC WELDING : Arc Welding .....	44

BRM

L  
M  
N  
O  
P

ARC WELDING : Principles of MIG and MAG Arc Welding .....	44	DAMAGE DIAGNOSIS : Determining Various Conditions of the Collision .....	56
ARC WELDING : Features of MIG and MAG Welding .....	45	DAMAGE DIAGNOSIS : External Appearance .....	56
ARC WELDING : Structure of MIG and MAG Welding Machine .....	45	DAMAGE DIAGNOSIS : Key Points in Choosing Repair Methods .....	57
ARC WELDING : Condition of Panel to be Welded .....	46	DAMAGE DIAGNOSIS : Parts to be Replaced .....	57
ARC WELDING : Inspection of Welded Portions .....	46	<b>CHECKING DAMAGE</b> .....	58
ARC WELDING : Types of MIG and MAG Welding .....	48	CHECKING DAMAGE : Checking Damage .....	58
<b>SAFETY AND HEALTH</b> .....	50	CHECKING DAMAGE : Centering Gauge .....	58
<b>PRECAUTIONS FOR OPERATION</b> .....	50	CHECKING DAMAGE : Tracking Gauge and Steel Tape .....	59
PRECAUTIONS FOR OPERATION : Precautions for Operation .....	50	<b>BODY STRAIGHTENING EQUIPMENT</b> .....	60
PRECAUTIONS FOR OPERATION : Protectors .....	50	BODY STRAIGHTENING EQUIPMENT : Comparison of Pulling Methods .....	60
PRECAUTIONS FOR OPERATION : Safety Stand .....	50	BODY STRAIGHTENING EQUIPMENT : Clamps .....	60
PRECAUTIONS FOR OPERATION : Inflammables .....	50	BODY STRAIGHTENING EQUIPMENT : Hooks and Other Tools .....	62
PRECAUTIONS FOR OPERATION : Working Environment .....	50	BODY STRAIGHTENING EQUIPMENT : High Intensity Cabin Structure .....	62
PRECAUTIONS FOR OPERATION : Handling of Welding Equipment .....	50	<b>REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT</b> .....	63
<b>WORKING WITH BODY STRAIGHTENING EQUIPMENT</b> .....	52	REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT : Securing the Vehicle .....	63
WORKING WITH BODY STRAIGHTENING EQUIPMENT : Use of Protectors .....	52	REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT : Securing and Pulling .....	65
WORKING WITH BODY STRAIGHTENING EQUIPMENT : Precautions while Working .....	52	<b>REPAIR PROCEDURE FOR PULLING</b> .....	66
WORKING WITH BODY STRAIGHTENING EQUIPMENT : Protection of Vehicle .....	53	REPAIR PROCEDURE FOR PULLING : Repair Sequence .....	66
<b>WORKING WITH GRINDING THE BODY FILLER (PUTTY)</b> .....	53	REPAIR PROCEDURE FOR PULLING : Key Points in Actual Repair Work .....	67
WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Danger from Dust .....	53	<b>REPLACEMENT OF PANEL</b> .....	69
WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Precautions during Dust Generating Work .....	53	REPLACEMENT OF PANEL : Replacement of Panel .....	69
WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Protector and Equipment .....	53	REPLACEMENT OF PANEL : Door Hemming .....	70
WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Precautions during Air Blow .....	54	REPLACEMENT OF PANEL : Adjustment Fitting of Front Fender .....	72
<b>PAINT SAFETY PRECAUTIONS</b> .....	54	REPLACEMENT OF PANEL : Adjustment Fitting of Door Assembly .....	73
PAINT SAFETY PRECAUTIONS : Paint Safety Precautions .....	54	<b>PARTIAL REPLACEMENT OF PANEL (WELDED PANEL)</b> .....	73
<b>REPAIRING PROCEDURES AND PRECAUTIONS</b> .....	55	PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Partial Replacement of Panel (Welded Panel) .....	73
<b>FUNDAMENTALS OF BODY REPAIR</b> .....	55	PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Welded Panel Replacement Procedure .....	73
FUNDAMENTALS OF BODY REPAIR : Fundamentals of Body Repair .....	55	PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Rough Cutting of Panel .....	74
<b>DAMAGE DIAGNOSIS</b> .....	55	PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Cutting Off Welded Portions .....	75
DAMAGE DIAGNOSIS : Damage Diagnosis .....	56	PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Precautions for High Strength Steel (HSS) .....	78

PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Prohibition for Ultra High Strength Steel (UHSS) .....	80	A
PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Rear Fender Hemming Process .....	80	B
PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Welding Method for Stud Bolt and Nut....	81	C
PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Preparation for Service Panel Installation .....	82	D
PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Anti-corrosive Treatment .....	84	
<b>USE OF BODY FILLER (PUTTY) AND GRINDING...</b>	<b>85</b>	
USE OF BODY FILLER (PUTTY) AND GRINDING : Use of Body Filler (Putty) and Grinding .....	85	E
USE OF BODY FILLER (PUTTY) AND GRINDING : Types of Filler and Putty .....	85	
USE OF BODY FILLER (PUTTY) AND GRINDING : Procedure for Applying Body Filler .....	86	F
USE OF BODY FILLER (PUTTY) AND GRINDING : Drying the Body Filler .....	89	
USE OF BODY FILLER (PUTTY) AND GRINDING : Grinding the Filled Area .....	89	G
USE OF BODY FILLER (PUTTY) AND GRINDING : Sandpaper Grits .....	91	H
USE OF BODY FILLER (PUTTY) AND GRINDING : Grinding Power of Air Sander .....	91	
<b>REPAIR OF RUST AND CORROSION .....</b>	<b>91</b>	I
REPAIR OF RUST AND CORROSION : Repair of Rust and Corrosion .....	92	J
REPAIR OF RUST AND CORROSION : Removal of Rust Limited to the Skin Panel Surface .....	92	
REPAIR OF RUST AND CORROSION : Repair of Corroded Panel .....	92	BRM
<b>FRAME REPAIR .....</b>	<b>97</b>	
<b>GENERAL INFORMATION .....</b>	<b>97</b>	L
GENERAL INFORMATION : General Information...97		
GENERAL INFORMATION : Checking Damage ....97		M
GENERAL INFORMATION : Repair by Heating ....97		
GENERAL INFORMATION : Frame Securing Method .....	97	N
GENERAL INFORMATION : Safety and Health ....97		
GENERAL INFORMATION : Elimination of Residual Stress .....	97	O
GENERAL INFORMATION : Repairable Frame Damages .....	98	
<b>FRAME VEHICLE CONSTRUCTION .....</b>	<b>98</b>	P
FRAME VEHICLE CONSTRUCTION : Frame Vehicle Construction .....	98	
FRAME VEHICLE CONSTRUCTION : Frame Repair Procedure .....	100	
<b>FRAME DEFORMATION .....</b>	<b>100</b>	
FRAME DEFORMATION : Frame Deformation ...100		
FRAME DEFORMATION : Sagging .....	101	
FRAME DEFORMATION : Side-sway .....	101	
FRAME DEFORMATION : Twisting .....	101	
FRAME DEFORMATION : Diamond .....	102	
FRAME DEFORMATION : Buckling .....	103	
<b>FRAME DEFORMATION MEASURING METHOD..</b>	<b>103</b>	
FRAME DEFORMATION MEASURING METH-OD : Frame Deformation Measuring Method .....	103	
FRAME DEFORMATION MEASURING METH-OD : Measurement with Manual Gauges .....	103	
FRAME DEFORMATION MEASURING METH-OD : Measurement with Three-dimensional Measuring Equipment .....	105	
<b>FRAME SECURING .....</b>	<b>106</b>	
FRAME SECURING : Frame Securing .....	106	
FRAME SECURING : Anchoring by Rigid Racks and Chains .....	107	
FRAME SECURING : Anchoring with Frame Attachments .....	107	
<b>FRAME STRAIGHTENING WORK .....</b>	<b>109</b>	
FRAME STRAIGHTENING WORK : Frame Re- pair Method according to Deformation Type .....	109	
FRAME STRAIGHTENING WORK : Precautions for Frame Repair .....	110	
FRAME STRAIGHTENING WORK : Cut and Butt Joint Weld .....	110	
<b>CONCLUSION .....</b>	<b>113</b>	
CONCLUSION : Conclusion .....	113	
<b>REPAIR INFORMATION - XD</b>		
<b>VEHICLE INFORMATION .....</b>	<b>114</b>	
<b>BODY EXTERIOR PAINT COLOR .....</b>	<b>114</b>	
Body Exterior Paint Color .....	114	
<b>PRECAUTION .....</b>	<b>116</b>	
<b>PRECAUTIONS .....</b>	<b>116</b>	
Precautions for Body Repair .....	116	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	116	
<b>HANDLING PRECAUTIONS FOR PLASTICS.</b>	<b>117</b>	
Precautions For Plastics .....	117	
<b>REPAIRING HIGH STRENGTH STEEL .....</b>	<b>121</b>	
High Strength Steel (HSS) .....	121	
Handling of Ultra High Strength Steel Plate Parts..123		
Welding of Ultra High Strength Steel .....	123	
<b>PREPARATION .....</b>	<b>125</b>	
<b>REPAIRING MATERIAL .....</b>	<b>125</b>	
Foam Repair .....	125	
<b>BODY COMPONENT PARTS .....</b>	<b>126</b>	
Underbody Component, Engine Compartment Parts .....	126	
Body Component Parts .....	128	

Frame Component Parts .....	130	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	191
<b>REMOVAL AND INSTALLATION .....</b>	<b>132</b>	<b>HANDLING PRECAUTIONS FOR PLASTICS.</b>	<b>192</b>
<b>CORROSION PROTECTION .....</b>	<b>132</b>	Precautions For Plastics .....	192
Description .....	132		
Anti-Corrosive Wax .....	132		
Undercoating .....	133		
Stone Guard Coat .....	134		
<b>BODY SEALING .....</b>	<b>135</b>	<b>REPAIRING HIGH STRENGTH STEEL .....</b>	<b>195</b>
Description .....	135	High Strength Steel (HSS) .....	195
<b>BODY CONSTRUCTION .....</b>	<b>139</b>	Handling of Ultra High Strength Steel Plate Parts.	197
Body Construction .....	139	Welding of Ultra High Strength Steel .....	197
Rear Body .....	140		
<b>REPLACEMENT OPERATIONS .....</b>	<b>142</b>	<b>PREPARATION .....</b>	<b>199</b>
Precautions for Body Repair .....	142		
Description .....	142	<b>REPAIRING MATERIAL .....</b>	<b>199</b>
Radiator Side Support .....	145	Foam Repair .....	199
Hoodledge .....	145		
Front Pillar .....	148	<b>BODY COMPONENT PARTS .....</b>	<b>200</b>
Dash Side .....	151	Underbody Component, Engine Compartment Parts .....	200
Center Pillar .....	152	Body Component Parts .....	202
Rear Pillar .....	155	Frame Component Parts .....	204
Back Panel .....	158	<b>REMOVAL AND INSTALLATION .....</b>	<b>206</b>
Roof .....	159		
Sill Outer .....	162	<b>CORROSION PROTECTION .....</b>	<b>206</b>
Sill Inner .....	164	Description .....	206
Rear Body Outer Panel .....	165	Anti-Corrosive Wax .....	206
Rear Body Rear Wheel House Outer .....	165	Undercoating .....	207
Rear Body Inner Panel .....	166	Stone Guard Coat .....	208
Rear Body Header Panel .....	168	<b>BODY SEALING .....</b>	<b>209</b>
Rear Body Floor Tail Bolster .....	168	Description .....	209
Rear Body Floor .....	170	<b>BODY CONSTRUCTION .....</b>	<b>213</b>
Front Side Member Extension .....	170	Body Construction .....	213
<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>174</b>	Rear Body .....	214
<b>BODY ALIGNMENT .....</b>	<b>174</b>	<b>REPLACEMENT OPERATIONS .....</b>	<b>215</b>
Body Mounting .....	174	Precautions for Body Repair .....	215
Body Center Marks .....	176	Description .....	215
Description .....	177	Radiator Side Support .....	218
Engine Compartment .....	177	Hoodledge .....	218
Passenger Compartment .....	179	Front Pillar .....	220
Roof .....	183	Dash Side .....	223
Rear Body .....	184	Center Pillar .....	224
Underbody .....	186	Rear Pillar .....	227
<b>REPAIR INFORMATION - NON-XD</b>		Back Panel .....	230
<b>VEHICLE INFORMATION .....</b>	<b>189</b>	Roof .....	231
<b>BODY EXTERIOR PAINT COLOR .....</b>	<b>189</b>	Sill Outer .....	234
Body Exterior Paint Color .....	189	Sill Inner .....	236
<b>PRECAUTION .....</b>	<b>191</b>	Rear Body Outer Panel .....	237
<b>PRECAUTIONS .....</b>	<b>191</b>	Rear Body Rear Wheel House Outer .....	237
Precautions for Body Repair .....	191	Rear Body Inner Panel .....	238
<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>250</b>	Rear Body Header Panel .....	240

<b>BODY ALIGNMENT .....</b>	<b>250</b>	Passenger Compartment .....	255
Body Mounting .....	250	Roof .....	259
Body Center Marks .....	252	Rear Body .....	260
Description .....	253	Underbody .....	262
Engine Compartment .....	253		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O  
P

## SERVICE INFORMATION

### SHEET METAL WORK

#### SHEET METAL WORK TOOLS

##### SHEET METAL WORK TOOLS : Sheet Metal Work Tools

INFOID:0000000014391561








This section explains various tools used in body repair work.

##### SHEET METAL WORK TOOLS : Hammers

INFOID:0000000014391562

A hammer is used to correct dents, projections or other deformations. Various shapes have been designed according to their purposes.

##### (1) TYPES AND FEATURES OF HAMMERS

	<b>A</b> Cross peen hammer	For shaping the panel together with dollies and spoons
	<b>B</b> Straight peen hammer	For shaping the panel together with dollies and spoons
	<b>C</b> Bumping hammer	For shaping the panel together with dollies and spoons
	<b>D</b> Roughing hammer	For rough-shaping the panel in combination with straightening equipment, or when great force is required
	<b>E</b> Pick hammer	For correcting small dents
	<b>F</b> Shrinking hammer	For shrinking stretched panels
	<b>G</b> Wooden hammer	For shrinking or correcting the panel without stretching

JSKIA6238GB

##### (2) SELECTION AND MAINTENANCE OF HAMMERS

It is necessary to choose lighter or heavier hammers according to application or purpose.


Hammer weight should be selected according to the user's physical strength.

Hammer maintenance is important. In particular, the hammer face must always be kept clean. A distorted or damaged hammer face will lead to distorted panels.


Accordingly, hammers for sheet metal work must not be used to hit other objects such as a chisel. Do not mix sheet metal hammers with ordinary hammers.

Repairing the face of a sheet metal hammer is explained below.


(a) Clamp the hammer in a vise with the hammer face up.  
If the hammer face is deformed, use a hand file to smooth it.  
(b) File the face in all directions. Do not file in only one direction.



(c) Chamfer the edge of the face to prevent it from nicking or distorting the sheet metal.




(d) After smoothing the hammer face, polish it with an oil stone or #400 - #800 abrasive paper wrapped around a wooden block. Polish the face in all directions.



(e) To check the finish, apply marking paint to the hammer face. Hit a piece of flat sheet metal on a flat surface.

**GOOD** : The paint comes off the center to the face.

**NO GOOD** : The paint comes off at a section other than the center or the face. Grind the surface again.



## (3) HOLDING AND HITTING WITH THE HAMMER

(a) Holding the hammer


- Hold the hammer handle tightly with the middle, third and little fingers so that it will not slip when it is swung.

# SHEET METAL WORK

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


- Hold the sides of the hammer handle lightly with the thumb and index finger to prevent sideways movement.




### (b) Hammering

- For rough straightening work, strike strongly.

For ordinary correcting work, swing the hammer using the wrist. In this case, the arm serves as a guide to determine the hammer direction.



- The hammer face should be flush with the panel surface when hitting. If the hammer edge strikes the surface, it will nick the panel.
- Hammering should be approximately 100 hits a minute, and should be kept constant. An irregular hammering rhythm will lead to an uneven hammering force. Sheet metal will stretch when it is hammered. Irregular hammering also makes sheet metal correction more difficult.



## SHEET METAL WORK TOOLS : Dollies

INFOID:000000014391563

Dollies are used in combination with a hammer. They are a 1 kg - 2 kg (2 lb - 4 lb) steel blocks, heavier than a hammer, with various curves and planes.


### (1) USE OF DOLLIES

# SHEET METAL WORK


## < SERVICE INFORMATION >

## [FUNDAMENTALS]


(a) Place the dolly on the underside of the deformed sheet metal. Strike the deformed section of the sheet metal with the hammer to stretch it.



(b) Move the hammer and dolly as necessary, and direct the hammer blows so as to bend the sheet metal.





(c) If ordinary hammering is impossible due to limited space, substitute a dolly for the hammer, and strike the dented portion with the dolly.






A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

## (2) TYPES AND FEATURES OF DOLLIES

 JSKIA6249ZZ	General purpose dolly	This is also called a rail dolly. It has both wide and narrow curved faces.
 JSKIA6250ZZ	Utility dolly	This type of dolly features various curved surfaces and has wide applicability to automobile body repair work. It can be handled easily in narrow spaces.

L  
M  
N  
O  
P

 JSKIA625122	Heel dolly	One side is flat and the other side is curved slightly. This is suitable for correcting flat and slightly curved surfaces.
 JSKIA625222	Toe dolly	This dolly is formed by two flat surfaces and a connecting curved surface. It can be used in narrow places.
 JSKIA625322	Round dolly	Both sides are curved. This dolly is used for repairing small dents.
 JSKIA625422	Wedge dolly	This dolly has a curved surface which changes gradually from sharp to gentle. Its sharp end can be inserted into narrow portions.
 JSKIA625522	Shrinking dolly	The surface is like a file. This dolly is used in combination with a shrinking hammer.


### (3) SELECTION AND MAINTENANCE OF DOLLIES

Ideally, a dolly whose curved surface just fits the curvature of the panel should be used. However, this is often difficult. In most cases, a dolly whose curvature is slightly smaller than that of the panel should be selected. Generally speaking, four types of dollies (general purpose, utility, heel and toe dollies) are sufficient for ordinary panel work. However a special dolly can be designed for unique shaping.

The size and weight of the dolly must be easy to handle.

The maintenance procedures and cautions described for the hammer also apply to the dolly.

The entire surface of the dolly must be free from damage.



### (4) HOW TO HOLD THE DOLLY


## &lt; SERVICE INFORMATION &gt;

Basic handling of the dolly.

## (a) TOP:


Place the dolly in the palm of your hand.

Holding it lightly, place the curved surface against the curved surface of the panel.




## (b) CORNER:

Hold the dolly lengthwise, and place the corner in the sharply bent portion of the panel.




## (c) EDGE:

Hold the dolly so that the edge faces upward.  
Place this edge to the press line of the panel.



## (d) CORRECTING THE PRESS LINE:

To correct a concave press line in a narrow space on the back of the panel, use a dolly as shown in the figure and strike the press line with it.



## SHEET METAL WORK TOOLS : How to Use Hammer and Dolly

INFOID:000000014391564


## (1) HAMMER-ON-DOLLY

# SHEET METAL WORK

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

This is also known as dinging on the dolly. The dolly is held directly under the area being struck with the hammer. Hammering smoothes the dented metal between the dolly and hammer. This method causes the sheet metal to stretch.




Hammering on a dolly is most effective for repairing shallow dents.


(a) The hammer strikes the sheet metal, causing the dolly to bounce against the metal surface. Thus the damaged portion is worked out from both inside and outside.



(b) The sheet metal stretches between the hammer and dolly, and deformation is distributed around the strike area.



(c) Continuously move the dolly under the shifting deformation so that it can be struck properly.




# SHEET METAL WORK

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(d) The sheet metal gradually stretches and returns to its original shape.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P

### (2) HAMMER-OFF-DOLLY


This is also known as dinging off the dolly.

Place the dolly directly under a dent, and hammer against the edge of the dent. The hammer drives one area downward while the reaction of the dolly drives the adjacent area upward.




An example of the hammer-off-dolly operation is given below.

(a) Place the dolly under the deepest dent, and hammer the highest portion of the top surface.



(b) The raised portion of the surface lowers as it is struck with the hammer.




# SHEET METAL WORK


## < SERVICE INFORMATION >

## [FUNDAMENTALS]


(c) Hammer blows are transmitted to the dolly, creating a reaction force.



(d) This reaction force pushes the dent.



(e) Repeat steps (a) - (d) until the surface is smooth.



## SHEET METAL WORK TOOLS : Spoons

INFOID:0000000014391565

Spoons are made of steel, and one or both ends are flat. Spoons are used as dollies in narrow spaces or as pry bars.

### (1) TYPES AND FEATURES OF SPOONS

 JSKIA6273ZZ	General purpose spoon	This spoon has a gently curved surface and sharply curved ends. It is widely used in automobile body repair work.
 JSKIA6274ZZ	Long spoon	This spoon has a long handle and thin, rigid faces. It is used primarily for prying.

	Curved spoon	The handle of this spoon is comparatively short. It has a wide curved blade. This spoon is used for smoothing.
	Flat spoon	This spoon has a short handle and a wide, flat blade. When the spoon is placed on the panel and hammered, the force disperses over a wide area.
	High crown spoon	This spoon has a wide hooked blade. It is used for repairing narrow body panel spaces such as inside of outer sill panel.
	Sickle-shaped spoon	This spoon has a wide, gently curved surface with a thin end. It can be inserted into very narrow gaps between panels.


## (2) SELECTION AND MAINTENANCE OF SPOONS

Select spoons suitable for the particular panel shape and internal structure. Spoons can be made from leaf springs.

BRM

Cut the leaf spring to the desired shape. Heat it with a gas torch and shape it into a spoon by bending or stretching with a hammer. Then grind and polish. (See Hammer Maintenance, refer to [BRM-6. "SHEET METAL WORK TOOLS : Hammers"](#).)

The precautions described for the hammer and dolly also apply to spoons. Do not damage the surface which comes into direct contact with the panel during repair work.




## (3) HOW TO USE SPOONS

# SHEET METAL WORK

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

(a) Insert the spoon into tight spaces such as inside of door, and use as a dolly.




JSKIA6280ZZ

(b) Place a spoon between two panels and pry out the concave portion.



JSKIA6281ZZ


(c) Hammer directly on the spoon to disperse the force of the hammer blows.



JSKIA6282ZZ

(d) The figure to shows an example of incorrect spoon usage. There is no fulcrum point for the spoon.

If a spoon is used in this way, insufficient force is applied to the mating face, and the spoon cannot act as a dolly.



JSKIA6283ZZ


## SHEET METAL WORK TOOLS : Scribing Chisels

INFOID:000000014391566

Chisels are generally used to cut sheet metal.

They are also used in body repair work. There are numerous types of chisels. This section, however, describes scribing chisels used exclusively for bending sheet metal or for shaping panel press lines.

This type of chisel must have a smoothly rounded edge as shown in the figure. If the edge is sharp, the body panel will be nicked.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P


## HOW TO USE SCRIBING CHISELS

### (a) For bending sheet metal


- First scribe a line on the sheet metal.
- Place thick paper or cardboard under the sheet metal.
- Place the scribing chisel on the line and hammer it.



- Place the sheet metal on a flat, angled surface scribed-side down, and bend the sheet metal with a wooden hammer.



- Using a hammer and the scribing chisel, neatly bend the sheet metal squarely. Do not bend all at once.
- Bend the sheet metal gradually by gently hammering against the chisel head.




- (b) Shaping the press line

# SHEET METAL WORK


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

- If the dent in the press line is smaller than the width of the chisel, apply the chisel to the center of the dent. Hammer to flatten. Hammer gently so that the dent can be removed gradually.



- If the dent is larger than the width of the chisel, do not strike the dent in the center. Apply the chisel at the edges of the dent.




## SHEET METAL WORK TOOLS : Types and Uses of Tinman's Shears

INFOID:0000000014391567


### (1) STRAIGHT BLADE SHEARS

For cutting straight lines.




### (2) CURVED BLADE SHEARS

The blades are smoothly curved. Suitable for straight or curved cutting.



### (3) SCOOPED BLADE SHEARS

The entire blade is bent to one side. Suitable for cutting along a sharply curved line.



JSKIA6292ZZ


INFOID:000000014391568

## SHEET METAL WORK TOOLS : Tools for Pulling

If it is impossible to gain access to the damaged area, dents can be pulled out and repaired.

### (1) HAND HOOK


Small holes are drilled in the dented portion, and a hand hook is inserted into the hole. The dented panel is pulled out with the hook. This method is used to repair small panel dents.



JSKIA6293ZZ

When using a hand hook, fit the end snugly against the panel. Do not pry up or use too much force. Pull the hook lightly while tapping with a hammer at the edge of the dent.


The drilled hole must be refilled with body putty after completing the work.



JSKIA6294ZZ

### (2) VACUUM PULLER

The vacuum puller is suitable for pulling out large dents if the dented surface is comparatively smooth.




JSKIA6295ZZ

### (3) SLIDING HAMMER


A B C D E F G H I J K L M N O P

The sliding hammer is used for repairing large, deep dents. Since it provides greater force than an ordinary hammer, it is used to repair dents in thick panels.




JSKIA6296ZZ

(a) A hook similar to the hand hook is attached to the end of the sliding hammer. Pulling holes are drilled in the panel. A limited force is allowed for pulling. The panel must be pulled carefully to avoid tearing.




JSKIA6297ZZ

(b) A tapping screw is attached to the end of the sliding hammer. It is then screwed into the panel. A greater pulling force is possible than with the hook.




JSKIA6298ZZ

(c) Instead of a hole, a metal pin or washer is welded to the panel. Great force can be used for pulling.




JSKIA6299ZZ

(d) When the dent is deep and narrow, pull it with a single blow.



JSKIA6300ZZ


(e) When the panel dent is shallow and wide, hold the end of the sliding handle. Repair the dent by gradually tapping the edge of the dent.



JSKIA6301ZZ

### (4) STUD WELDER (BODY REPAIR STATION)


A pin or washer is welded directly to the body panel dent without drilling. The panel dent area is then pulled outward with the sliding hammer. Because no drilling is required, panel strength is unaffected. Corrosion problems are also reduced.



JSKIA6302ZZ

Because the stud welder welds pins directly, the paint must be removed from the dent surrounding area and the area where body ground is established.

As shown in the figure, the ground can be established at the flange area or in the dent surrounding area using a magnet.



JSKIA6303GB

### (5) WELDED PIN OR WASHER


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SHEET METAL WORK


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

A pin or washer is welded to the dent without drilling. It is then pulled to repair the dent.



Several pins or washers are welded to the dent. They are then pulled together or separately to repair the dent.




## (6) SPOT HAMMER WELDING

The sliding hammer tips are welded to the dent.

They are then pulled separately to repair the dent.

After the tips are pulled, they are twisted to separate them from the panel.



## SHRINKING THE SHEET METAL

### SHRINKING THE SHEET METAL : Shrinking The Sheet Metal

INFOID:0000000014391569

Plastic deformation may cause reduced panel thickness and the panel may stretch. Even when it is repaired using a hammer and dolly, the panel tends to bulge, losing its original shape.


In such cases, it must be shrunk to its original shape. This is called shrinking the sheet metal.

### SHRINKING THE SHEET METAL : Shrinking Methods

INFOID:0000000014391570

#### (1) HAMMER AND DOLLY


A shrinking hammer and shrinking dolly are used by the hammer-on-dolly method. Many tiny dents are formed on the panel surface. This method is suitable for shrinking comparatively small areas of panel deformation.



#### (2) SHRINKING ROD

This method is used to shrink stretched sheet metal edges. The sheet metal is inserted into the shrinking rod slit and bent in a "V" shape. The convex area of the sheet metal is then worked flat with a wooden hammer.


Hammer blows should begin at the edge and should gradually move outward to shrink the sheet metal.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

### (3) ELECTRIC WELDING MACHINE


The body panel is connected to the negative power supply terminal and the tip is connected to the positive terminal. Then, an electric current is supplied to heat the panel. The shrinking principle is the same as that of gas welding. This method features no hammering and greater workability than gas welding and is suitable for repairing local panel deformations.



E  
F  
G  
H  
I  
J

### (4) CARBON ROD

The panel is connected to the negative power supply terminal and a carbon rod is connected to the positive terminal. The panel is heated so that heat is conducted from the outside to the center of the dent. Wet rags are then applied to cool it quickly, thus shrinking the panel. This method is suitable for repairing wide, shallow panel deformations.



BRM


L  
M  
N  
O  
P

### (5) GAS WELDING (OXY-ACETYLENE TORCH)

#### (a) Heating and expansion

### < SERVICE INFORMATION >

As the sheet metal is heated with a gas welding torch, it stretches. However, stretching is restricted in the unheated surrounding portion. As a result, the heated portion bulges.




JSKIA6311GB

### (b) Sudden cooling

When the bulge is cooled suddenly, it shrinks.

This shrinking is accelerated by tapping with a wooden hammer.




JSKIA6312ZZ

## SHRINKING THE SHEET METAL : How to Heat Sheet Metal

INFOID:000000014391571

- Use a carburizing flame when shrinking sheet metal with a gas welding torch.
- Hold the torch at a right angle to the center of the sheet metal.
- Maintain a distance of 3 mm - 5 mm (0.12 in - 0.20 in) between the inner core and sheet metal.
- Heat the sheet metal to approximately 800°C (1,472°F) (until the heated portion turns red). Increase the temperature if sheet metal stretching is insufficient.




JSKIA6313GB

# SHEET METAL WORK

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

- Locate the stretched portion of the panel.  
Press the surface being repaired in several places.  
The point where the largest elastic dent is formed is the center, where the stretch is the maximum. The highest portion of the panel being repaired can also be considered the most stretched portion.




- The area heated with a welding torch must be approximately 3 mm - 5 mm (0.12 in - 0.20 in) in diameter if the panel shape is complex, and approximately 6 mm - 15 mm (0.24 in - 0.59 in) in diameter if it is flat.
- Small stretch
- Apply a dolly to the back of the heated panel. Tap the panel with a wooden hammer using the hammer-on-dolly method in the sequence shown in the figure.

(A) and (B) → 1 - 8  
(C) → 9



- Excessive stretch  
Shrink the panel, starting with the most stretched portion, and proceed toward the edge of the dent so that the dent surface is lower than the original surface.

Using a gas welding torch makes the panel concave.  
To correct this, strike the concave portion using the hammer-on-dolly method to stretch the panel bit by bit until the original surface is restored.



- Apply wet cloths to the shrunken portion of the panel to cool it quickly.

## CORRECTING A DEFORMED PANEL

### CORRECTING A DEFORMED PANEL : Determining Panel Damage


INFOID:0000000014391572

Panel damage must be examined carefully to select the most suitable repair method.

### < SERVICE INFORMATION >

(A) In the figure is the plastic deformed area and the surrounding portions are elastic deformed areas.

Correction of (A) will automatically remove the elastic deformation.



JSKIA63172Z

Removing the cause of the dent can simplify the entire repair operation. Plastic deformation can be recognized by sharp bending, a nick, or cracked or peeled paint.


### SHEET METAL DEFORMATION ANALYSIS

(a) When external force is applied, sheet metal deformation begins. Elastic deformation is generated around the point where the external force is applied.

(b) As the external force increases, areas surrounding the dent yield to the pressure, and local cracking or small breaks in the paint occur. This indicates plastic deformation.

(c) If the external force continues to increase, breaks around the dent enlarge, and the sheet metal at the center of the dent stretches.


(d) When the external force is removed, the "spring back" causes the plastic deformed portion of the dent to swell above the original surface.



JSKIA6318GB

### CORRECTING A DEFORMED PANEL : Basic Types of Damage

- Plastic deformation forms at the center of portion (A) of the dent. The surrounding area remains in elastic deformation.
- Plastic deformation occurs at one or several portions around the dent. Other areas remain in elastic deformation.
- Both plastic and elastic deformation are generated throughout the damaged panel.



JSKIA63192Z


### CORRECTING A DEFORMED PANEL : Examination of Panel Damage

INFOID:000000014391574

It is difficult to find minor deformation or panel irregularity, particularly, at the final stage of repair. This section explains how to determine if a vehicle has minor panel deformation.

### (1) VISUAL CHECK

Check the affected portion of the panel by carefully examining the deformation in the light reflected on the surface.




### (2) TOUCH CHECK

Lightly place a hand on the surface of the panel and move it forward/backward and right/left to judge by touch with the palm of a hand. Slide and move a hand from an undamaged surface to a damaged part, all the way to the undamaged surface on the other side.

#### NOTE:


Wearing work gloves makes it easier to tell the difference.



### (3) CHECK WITH TOOLS


- Use of chalk: Rub the panel surface with a piece of chalk held lengthwise.

Dents or concave areas in the panel will remain uncolored.




- Use of hacksaw blade: Scrape the panel surface with the blade teeth.

Dents or concave areas will not be scratched.




- Use of body file: Scrape a body file lightly on the panel. Dents or concave areas will not be scratched. The body file should not be used for grinding. Thickness and strength of the panel will be reduced.




## CORRECTING A DEFORMED PANEL : Elastic VS. Plastic Deformation

INFOID:0000000014391575

- Elastic deformation: If pressed, the deformed portion will move or further deform.



- Plastic deformation: If pressed, the deformed portion will remain unchanged, and other portions will move.




## CORRECTING A DEFORMED PANEL : Basic Repair Procedure

INFOID:0000000014391576


### (1) WHEN PLASTIC DEFORMATION OCCURS AT THE CENTER OF THE DAMAGED PORTION

- (a) Using a hammer or dolly, strike the lowest portion of the dent from behind until it becomes flat.




### < SERVICE INFORMATION >


(b) Using the hammer-off-dolly method as shown in the figure, raise the concave portion and lower the convex portion. Then smooth the surface a little lower than the original. Using a wooden hammer and dolly, correct the irregularities in the panel.



(c) Existence of plastic deformation can be determined by the stretched panel. The original surface can be restored by shrinking that portion with a gas welding torch.




(d) Use a hammer and dolly by the hammer-on-dolly method. Stretch the panel while striking the outer area of the damaged portion. The entire panel surface should be formed somewhat higher than the original surface. Note that, in this case, the stretched portion of the panel must not be hit with the hammer.



If the concave portion is shallow and if the working face of the wooden hammer matches it, the repair work can be completed quickly by directly shrinking the portion with a gas welding torch.


### (2) WHEN PLASTIC DEFORMATION EXISTS AROUND THE DAMAGED PORTION

(a) Apply the dolly to the elastic deformation area behind the panel. Hit the plastic deformation area with a hammer so that the elastic deformation area is lower than the original surface.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P

(b) Repair the plastic deformed portion using the hammer-off-dolly method. If a shrinking hammer is available, the stretched portion can be easily shrunk.




### (3) WHEN PLASTIC DEFORMATION EXISTS AT THE CENTER AND AROUND THE DAMAGED PORTION

(a) Using a hammer and dolly, flatten the lowest portion (A) where the plastic deformation exists, so that the flattened surface is not higher than the original surface.




(b) Flatten the highest points (B) where plastic deformation exists.



(c) Flatten portion (A) so that the panel surface is not higher than the original surface.

Correct irregularities using a wooden hammer and dolly. If the panel has been stretched, repair by shrinking.




### (4) CORRECTING PANEL DISTORTION

# SHEET METAL WORK

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

(a) Panel distortion occurs when panel damage is repaired. The panel is deformed within the range of elastic deformation. If pressed with a finger, the deformed area bends inward and outward. Panel irregularities occurring over a wide range other than the repaired portion may also indicate panel distortion.




(b) Cause of panel distortion

Expansion stress due to damage repair is confined inside the panel because the outer area is bent and work hardened. Thus, it does not allow the panel to expand. The stress is released in the form of panel distortion.



(c) How to correct panel distortion


Panel distortion can be removed by shrinking the stretched portion or by stretching the side of the press line using the hammer-on-dolly method.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

The front fender repair procedure is explained below:



When repairing the body panel, paint and anti-corrosive wax must be thoroughly removed from the damaged area by sanding.

## COLORED SHEET METAL WORK

## COLORED SHEET METAL WORK : Colored Sheet Metal Work

INFOID:0000000014391577

Colored sheet metal work is one type of panel repair technique. This technique is used to repair irregularities on painted outer panels without damaging the painted surface.

### COLORED SHEET METAL WORK : Confirmation of The Panel


INFOID:0000000014391578

It is not possible to correct all convex/concave portions in colored sheet metal work.

Whether or not the parts need to be removed/installed, and tools that can be inserted must be checked for each repair location.

When checking the convex/concave location, determine whether or not the colored sheet metal work is possible. It is also important to determine the most suitable repair method.

COLORED SHEET METAL WORK FLOWCHART




JSKIA6340GB

# SHEET METAL WORK

## < SERVICE INFORMATION >


## [FUNDAMENTALS]



## COLORED SHEET METAL WORK : Selection of Repair Tools

INFOID:0000000014391579

Tools for colored sheet metal work are hammers, spoons, dollies and punches. Some popular hand tools for colored sheet metal work and application examples are described below.



Choose suitable tools to repair the panel.

JSKIA6343GB

## COLORED SHEET METAL WORK : Panel Repair Methods

INFOID:0000000014391580

### (1) CORRECTION OF CONCAVE PANEL WITH SPOONS


# SHEET METAL WORK

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


Convex panels can be repaired with a hammer and punch. Concave panels can be repaired with a spoon if the following conditions are satisfied:

- The spoon must be able to be inserted behind the concave panel.  
A closed construction portion or mating panel cannot be repaired.




- Use of lever action should be allowed.

If the surrounding portion of panel can be used to support a spoon as a lever, the concave area can be repaired. Otherwise, corrective force cannot be transmitted to the desired portion.




- The concave portion should be visible from outside.

This work is performed visually, and dents in concealed areas cannot be repaired.




## (2) KEY POINTS IN COLORED SHEET METAL REPAIR WORK

- Repairing a smoothly rounded concave section:  
Raise the concave portion little by little, beginning with the outside.



## &lt; SERVICE INFORMATION &gt;

- Repairing a concave section bent sharply at the center:  
First, raise the concave portion 60% - 70%, beginning with the outside. Next, raise the sharply bent portion slightly higher than the surrounding panel surface.  
Then flatten the high point by tapping with a hammer.



A  
B  
C  
D  
E  
F  
G

H  
I

J

BRM

L  
M  
N

O  
P

- Do not attempt to correct panel deformation all at once.  
Use the step-by-step repair method, such as roughing → smoothing → finishing.
- After repairing, visually check the repaired portion from all directions.

## COLORED SHEET METAL WORK : Polishing of Panel Surface and Anti-corrosive Treatment


INFOID:000000014391581

## (1) POLISH-FINISHING OF CORRECTED SURFACE

If the painted surface is scratched during repair, polish with compound to remove scratches.

## (2) ANTI-CORROSIVE TREATMENT OF BACK OF PANEL

The spoons may cause scratches. Apply anti-corrosive wax to the back of panel.



## COLORED SHEET METAL WORK : Examination of Panel

INFOID:000000014391582

Irregularities in the panel must be examined carefully to see whether or not they can be repaired, and also to determine the most suitable repair method.

Refer to [BRM-26, "CORRECTING A DEFORMED PANEL : Examination of Panel Damage".](#)

## BODY WELDING AND PRECAUTIONS

### OUTLINE OF WELDING

#### OUTLINE OF WELDING : Features of Welding

INFOID:000000014391583

- No restrictions on the shape of joint
- Reduction in weight compared to using of bolts or rivets
- Great strength
- Airtight and watertight
- High working efficiency
- Some welding processes require higher welding skills.
- The welded parts can be separated only by breaking the weld. (Except when brazing)

#### OUTLINE OF WELDING : Welding of Automobile Body

INFOID:000000014391584

The automobile body is fabricated by welding 0.6 mm - 1.4 mm (0.024 in - 0.055 in) thick sheet steel. Spot welding is most suitable in terms of cost, quality and working efficiency. On the automobile production line, spot welding is widely used, except for some special areas which cannot use this procedure. Today, spot welding is mostly performed by robots.

In addition to spot welding CO<sub>2</sub> arc welding and brazing are also used.

Soldering is not used in the automobile production line. Brazing is used on the roof joints, front pillar and rear pillar, and on the sealing surface of the center pillar.


# BODY WELDING AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

Automobile assembly line welding processes are shown below.

Automobile assembly line welding processes are shown below.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L

JSKIA6355GB

## ELECTRIC RESISTANCE SPOT WELDING

### ELECTRIC RESISTANCE SPOT WELDING : Principles of Spot Welding

INFOID:0000000014391585

Resistance spot welding is a kind of electric resistance welding. It is classified as pressure welding. Two or three sheets of metal are overlapped and pressed, and current is passed through the mating surfaces. As the current flows, the metals melt due to Joule heat at the mating surfaces and are joined by the pressure.

### ELECTRIC RESISTANCE SPOT WELDING : Features of Spot Welding

INFOID:0000000014391586

- Short welding time and high efficiency compared to other welding processes
- Minimum thermal strain due to partial heating
- No need to finish the welded surface
- Less rust formation compared to other welding processes due to application of conductive sealer
- Great welding skill is not needed. Uniform weld strength can be obtained regardless of worker's skill
- Heavy welding machine is required to produce high current
- Most suitable for welding thin sheet metals
- The condition of the weld is difficult to check from the outside
- Paint must be removed from the surfaces to be welded

M

N

O

P

# BODY WELDING AND PRECAUTIONS


< SERVICE INFORMATION >

[FUNDAMENTALS]

## ELECTRIC RESISTANCE SPOT WELDING : Construction of Spot Welder

INFOID:0000000014391587


The spot welding machine consists of a transformer unit which supplies the voltage and current required for welding, a timer unit which controls the current passing time, and a welding gun.



The separate transformer type includes a multi-functional type for welding of pins and washers.


JSKIA6356GB

### BUILT-IN TRANSFORMER TYPE SPOT WELDER



JSKIA6357GB

### SEPARATE TRANSFORMER TYPE SPOT WELDER



JSKIA6358GB

## ELECTRIC RESISTANCE SPOT WELDING : Cooling Methods


INFOID:0000000014391588

1. Air cooling: Forced air cooling with fan
2. Water cooling: Cooling by circulating the water

## ELECTRIC RESISTANCE SPOT WELDING : Spot Welding Gun

INFOID:0000000014391589

### (1) TYPES OF CLAMP



### (2) ATTACHMENT ARM


- In spot welding, 2 or 3 panels to be welded must be clamped directly at electrodes. Therefore, the disadvantage of spot welding is that there are some points at which welding cannot be performed.

# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


- In order to make up for this weakness, various types of attachment arms have been created.



JSKIA63602Z

### (3) HANGING UNIT

- The weight of guns, arms and cables has been reduced to minimize the burdens on workers.
- Depending on the unit type, the cable can simply be hung, or the gun can be hung with a cylinder.



JSKIA6361ZZ


## ELECTRIC RESISTANCE SPOT WELDING : Mult-functional Type Spot Welder

INFOID:000000014391590

In addition to the ordinary spot welding function, sheet metal can be pulled with the sliding hammer.

Major functions:

- Both sided spot welding
- One sided spot welding (Pre tack welding)
- Spot hammer welding
- Nuts and bolts welding
- Carbon shrinking
- Contact shrinking
- Washer and pin or stud welding



JSKIA6362ZZ

## ELECTRIC RESISTANCE SPOT WELDING : Process of Spot Welding

INFOID:000000014391591

It takes 3 processes, "pressurization", "energization", and "retention", to complete the spot welding.


# BODY WELDING AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]


## (1) PRESSURIZATION

- The welding points of overlapped panels are pressurized with the tip (electrode) for close contact.
- With the panels contacting closely, the current can run intensively.




## (2) ENERGIZATION

- With the panels being pressurized, heavy current is applied.
- Joule heat is generated at panel mating areas, and the temperature rises sharply.
- The panel mating areas are melted and fused together by welding pressure.



## (3) RETENTION

- Even after the current is turned off, pressure is still applied until the welded point cools down.
- The nugget system becomes delicate by pressurization, resulting in better mechanical properties.
- Therefore, the retention process must not be omitted.



## ELECTRIC RESISTANCE SPOT WELDING : Condition of the Panel


INFOID:000000014391592

Before beginning, thoroughly check the panel and make any necessary corrections.

### (1) CLEARANCE BETWEEN WELDING SURFACES

Gaps between the surfaces to be welded cause poor current flow. Even if welding could be done without removing such gaps, the welded area would be smaller, resulting in poor strength.

Flatten the two surfaces to remove the gaps, and clamp them tightly before welding.




### (2) PANEL SURFACES TO BE WELDED

# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

Paint, rust, dust, or any other contamination on the panel surfaces to be welded cause insufficient current flow and poor results. Remove such foreign matter from the surfaces to be welded by sanding or wiping clean. Do not remove electrodeposited coatings.




### (3) CORROSION PREVENTS PROPER WELDING OF PANEL SURFACES.

Coat the surfaces to be welded with an anticorrosion agent that has high conductivity.

It is important to evenly apply the agent to the panel including the end face.

Perform the spot welding before the anticorrosion agent gets dry, as the agent has generally low conductivity.

Because the wet agent can move from the welding portion due to the welding pressure, that leads to the good quality of spot welding by high conductivity.




## ELECTRIC RESISTANCE SPOT WELDING : Precautions when Performing Spot Welding

INFOID:000000014391593

### (1) SELECTION OF SPOT WELDING MACHINE

Use the direct welding method whenever possible.

(When direct welding cannot be applied, use MIG/MAG plug welding.)



### (2) APPLICATION OF ELECTRODE TIPS

Apply electrodes at right angles to the panel. If they are not applied properly, the current density will be low, resulting in poor welding strength.

### (3) LAP WELDING OF MORE THAN TWO PANELS

Where three or more panels overlap, spot welding should be done twice.

### (4) NUMBER OF SPOT WELDING POINTS

Generally, the capacity of repair shop spot welding machines is smaller than that of factory welding machines. Accordingly, the number of points of spot welding should be increased by 20% - 30%.

### (5) WELDING CORNERS

# BODY WELDING AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

Do not weld the curved corner. Welding this portion results in stress concentration, which leads to cracks.

Examples:

- Upper corner of front and center pillars
- Front upper portion of rear fender
- Corner portion of front and rear windows




JSKIA6371GB

## (6) MINIMUM WELDING PITCH

The minimum welding pitch varies with the thickness of panels to be welded. In general, observe the values in the following table.


Unit: mm (in)	
Thickness (t)	Minimum pitch ( $\ell$ )
0.6 (0.024)	10 (0.39)
0.8 (0.031)	12 (0.47)
1.0 (0.039)	18 (0.71)
1.2 (0.047)	20 (0.79)
1.6 (0.063)	27 (1.06)
1.8 (0.071)	31 (1.22)



JSKIA6372GB

### NOTE:


The excessively small pitch allows the current to flow through surrounding portions, resulting in poor welding strength.



JSKIA6835GB

Avoid welding over previously welded areas.

- ① **Old Spot Locations**
- ② **New Spot Locations**



JSKIA6836ZZ

## (7) MINIMUM LAP OF PANELS


# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

Observe the following values for the lap distance of panels. Too short of a lap distance results in reduced strength and also in a strained panel.

Unit: mm (in)	
Thickness (t)	Minimum pitch ( $\ell$ )
0.6 (0.024)	11 (0.43)
0.8 (0.031)	11 (0.43)
1.0 (0.039)	12 (0.47)
1.2 (0.047)	14 (0.55)
1.6 (0.063)	16 (0.63)
1.8 (0.071)	17 (0.67)




JSKIA6373GB

### NOTE:

Be sure to spot weld at the center of the overlapped portion.

### (8) SPOTTING SEQUENCE

Do not spot weld continuously in one direction only. This causes weak welding due to the shunt effect of the current. If the welding tips become red-hot, stop welding and cool the tips.



## ELECTRIC RESISTANCE SPOT WELDING : Inspection of Welded Portion

INFOID:000000014391594

Spot welded portions can be checked by the destructive inspections explained below. They can be easily adopted when welding. Before and after welding, you should perform these destructive inspections to check the strength of the welded portions.

The welding spots should be equally spaced and arranged at the center of the flange to be welded.


### (1) CHECK BY USING TEST PIECE (Confirmation before operation)

#### NOTE:

Clamp both test pieces together so that they will not slip or move during welding.

(a) Weld together test pieces with the same thickness as the panel to be welded.

Break the weld by twisting, and examine the break.




# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

(b) With this test, a hole should be made on one test piece by tearing at the welded portion. If no hole is formed, it indicates that the welding conditions are incorrect. Adjust the pressure, welding current, current passing time and other conditions, and repeat test until the best result is obtained.



### (2) CHECK BY USING CHISEL AND HAMMER (Confirmation after welding)


(a) Insert a chisel tip between the welded panels, and tap the end until a clearance 3 mm - 4 mm (0.12 in - 0.16 in) [when the panel thickness is 0.8 mm - 1.0 mm (0.031 in - 0.039 in)] is formed between the panels. If the welded portions do not separate, it indicates that the welding has been done properly.



This clearance varies with the location of the welded spots, length of the flange, panel thickness, welding pitch, and other factors. Note that the value shown above is only for reference.

(b) If the thickness of the panels is different, the clearance must be limited to 1.5 mm - 2.0 mm (0.059 in - 0.079 in). Further opening of the panels can become a destructive test.

(c) Be sure to repair the deformed portion of the panel after inspection.



## ARC WELDING

### ARC WELDING : Arc Welding

INFOID:0000000014391595

Arc welding uses the heat of an electric arc to join two pieces of metal by fusing both the metal and the electrode. For auto repair, MIG (Metal Inert Gas) and MAG (Metal Active Gas) are the types of arc welding most often used.

### ARC WELDING : Principles of MIG and MAG Arc Welding


INFOID:0000000014391596

The welding electrode consists of a wire wound on a reel. This welding wire is fed by an electronically controlled motor.

The welding zone is shielded from the atmosphere by injecting a shielding gas. This prevents oxidation and nitriding so that greater weld strength and a good weld bead can be obtained. The shielding gas is argon, CO<sub>2</sub>, or a mixture of both.

MIG arc welding uses argon gas as a shield. If CO<sub>2</sub> is used, the method is called MAG arc welding. Use of argon gas permits most metals, including aluminum, copper, stainless steel, titanium, to be welded.

The following figure shows the welding procedure.



JSKIA6379QB

## ARC WELDING : Features of MIG and MAG Welding

INFOID:0000000014391597

- Less slag
- Less thermal strain
- Comparatively easy to master
- Greater weld strength than gas or spot welding
- Suitable for thin sheet metal
- Less influence of welding position to the strength of weld
- Not suitable for windy locations

## ARC WELDING : Structure of MIG and MAG Welding Machine

INFOID:0000000014391598

The welding machine consists of a power supply unit composed of a transformer and rectifier which converts the source voltage to welding voltage and rectifies the current. A controller which controls the voltage, current

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM


L  
M  
N  
O  
P

# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

and welding wire feed speed corresponding to the thickness of the welding panel. Welding wire which is wound around the wire spool, wire feed motor, welding torch, gas cylinder, and regulator.




JSKIA6380GB

## ARC WELDING : Condition of Panel to be Welded

INFOID:0000000014391599

Paint, rust, or oils on the surface of the panel cause blowholes and spatter when the panel is welded. Thoroughly remove any foreign matter with a belt sander or wire brush.

Do not remove electrodeposited coatings.



## ARC WELDING : Inspection of Welded Portions

INFOID:0000000014391600






Refer to the inspection method for spot welding. Refer to [BRM-43. "ELECTRIC RESISTANCE SPOT WELDING : Inspection of Welded Portion"](#).

Sample defects and welding conditions of MIG, MAG welding.

# BODY WELDING AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

Defect	Check points	Remarks
Blowhole  JSKIA6382GB	<ul style="list-style-type: none"> <li>• Is correct wire selected?</li> <li>• Is gas sealed properly?</li> <li>• Is weld joint surface clean?</li> <li>• Is weld zone quickly cooled?</li> </ul>	A hole is made when gas is trapped in the weld metal.
Improper fusion  JSKIA6383GB	<ul style="list-style-type: none"> <li>• Is torch feed operated properly?</li> <li>• Is voltage low?</li> <li>• Is the area to be welded clean?</li> </ul>	This is an unfused condition between weld metals or between deposited metals.
Undercut  JSKIA6384GB	<ul style="list-style-type: none"> <li>• Is current too great?</li> <li>• Is torch feed too fast?</li> <li>• Is torch angle correct?</li> </ul>	<ul style="list-style-type: none"> <li>• Undercut is a condition where the overmolten metal has made grooves or an indentation.</li> <li>• Metal's section is made thinner, and therefore the weld zone's strength is severely lowered.</li> </ul>
Penetration shortage  JSKIA6385GB	<ul style="list-style-type: none"> <li>• Is current too little?</li> <li>• Is wire feed out of order?</li> <li>• Is extrude extension too long?</li> <li>• Is groove face too small?</li> </ul>	This is a condition where there is poor deposition made under the panel.
Overlap  JSKIA6386GB	<ul style="list-style-type: none"> <li>• Is torch feed too slow?</li> <li>• Is current too little?</li> </ul>	<ul style="list-style-type: none"> <li>• Overlap is apt to occur in fillet weld rather than in butt weld.</li> <li>• Overlap causes stress concentration and results in premature corrosion.</li> </ul>
Spatter (short throat)  JSKIA6387GB	<ul style="list-style-type: none"> <li>• Is current too great?</li> <li>• Is correct wire selected?</li> </ul>	Spatter is prone to occur in fillet weld.
Vertical crack  JSKIA6388GB	Are there any stains on welded surface (paint, oil, rust)?	Cracks usually occur on top surface only.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L

M

N

O

P

# BODY WELDING AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

## ARC WELDING : Types of MIG and MAG Welding

INFOID:000000014391601


### (1) CONTINUOUS WELDING

This welding process is suitable for sheet steel 2 mm (0.08 in) thick or over. If applied to thinner panels, it will cause melt-through.

### (2) SPOT WELDING

Replace the torch nozzle with a spot welding nozzle.

Grind the surfaces to be welded and press tightly together.




### (3) PLUG WELDING

(a) Make a hole 5 mm - 6 mm (0.20 in - 0.24 in) in diameter in the upper of the two panels to be welded. Keep the upper panel and lower panel tightly together.

(b) Apply the torch at a right angle to the panel and quickly fill the hole with the molten metal. Intermittent welding generates oxide film, causing blowholes. If this occurs, remove the oxide film with a wire brush or belt sander.

(c) Weld the upper and lower panels together tightly.




### (4) INTERMITTENT (STEP) WELDING


This method is suitable for thin or rusted panels to prevent thermal deformation and melt-through. In body repair, it is used as butt welding on partial panel replacements.

- Before step welding, tack weld the panels to be welded to prevent strain and to align panel surfaces.

To do this, point weld and then fill in the spaces with short welding beads.



- Long weld line will cause strain. Use the method as shown in the figure to reduce strain.




# BODY WELDING AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

- To fill the spaces between intermittently placed beads, grind the beads using a sander, then fill with molten metal. If this is done without grinding the surface of the beads, blowholes may result.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O  
P

&lt; SERVICE INFORMATION &gt;

**SAFETY AND HEALTH****PRECAUTIONS FOR OPERATION****PRECAUTIONS FOR OPERATION : Precautions for Operation**


INFOID:0000000014391602

In body repair, great importance is attached to quality, efficiency and cost. Consideration for workers' safety and health should, however, be deemed as the most important item. In reality, it is essential that measures be established to prevent accidents and to make the work environment safer and healthier.

**PRECAUTIONS FOR OPERATION : Protectors**

INFOID:0000000014391603

- While working, suitable work clothes, a work cap and safety shoes must be worn. To prevent burns, a long sleeve shirt and trousers must also be worn and must not be taken off under any circumstances.
- Keep work clothes clean. Do not keep a lighter or other flammable materials in pockets.
- During oxygen and acetylene gas welding, to protect eyes wear goggles according to the quantity of infrared rays.
- During arc welding, to protect eyes wear a safety goggles with a shading plate according to the quantity of ultraviolet rays.
- Gloves, apron, foot covers, earplugs and arm covers should be used to prevent burns.

**PRECAUTIONS FOR OPERATION : Safety Stand**


INFOID:0000000014391604

After jacking up a vehicle body, be sure to support it with the safety stand. For the supporting positions, refer to "Lifting Points" in the Service Manual for each model.

**PRECAUTIONS FOR OPERATION : Inflammables**


INFOID:0000000014391605

- Before starting repair work, be sure to disconnect the negative terminal of the battery.
- When welding parts near the fuel tank fuel filler, be sure to remove the fuel tank. Plug the filler port of the tank.
- Plug the fuel pipe and brake pipes to avoid leakage when removing connectors from the pipes.

**PRECAUTIONS FOR OPERATION : Working Environment**

INFOID:0000000014391606

- Pay attention to ventilation and the health of workers.
- Paint and sealant may generate poisonous gases when heated by fire. To prevent this, do not use a gas welder for cutting off damaged portions.
- Use an air saw or an air chisel.
- Use a belt sander or rotary wire brush for removing paint from the panel.

**PRECAUTIONS FOR OPERATION : Handling of Welding Equipment**


INFOID:0000000014391607

**(1) STORAGE OF GAS CYLINDERS**

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

- In a well ventilated area, post a "No Fire" sign.
- Avoid the direct rays of the sun. Maintain temperature below 40°C (104°F).
- Inflammable gas cylinders and oxygen cylinders must not be stored in the same place.
- Acetylene cylinders must be stored upright. Check that they cannot fall down.



### (2) MOVEMENT AND TRANSPORTATION OF CYLINDERS

- Be sure to properly close the valve and securely install the cap.
- Do not drag or roll the cylinder.
- Use a cylinder transportation cart.
- When moving, tilt the cylinder slightly and roll it carefully on the bottom edge with one hand while supporting its cap with the other hand.



### (3) USE OF CYLINDERS

- The cylinder valve must be kept clean and free from oil.
- After opening the cylinder, leave the open-end wrench attached to the valve so it can be turned off quickly in an emergency.
- When the cylinder is replaced, open the valve of the new cylinder slightly and remove dust from around the valve seat.
- To check the cylinder for leakage, apply soapy water.
- The valve should be fully open for oxygen and open 1.5 turns or so for acetylene.
- To prevent the cylinder from falling down, ensure that it is properly secured.
- And never give a shock to the cylinder.




### (4) HANDLING OF THE PRESSURE REGULATOR

- Always handle the pressure regulator with care and avoid impact.
- Inspect the regulator periodically (at least once a year).
- After use, purge the gas, and set the gauge to "0" (except the indoor type pressure regulator).

### (5) HANDLING OF WATER-SEALED SAFETY DEVICES

- This device must be installed vertically. Check the water level every morning.
- In case of freezing, antifreeze solution can be added.



### (6) HANDLING OF HOSES

- All hoses must be checked before use for flaws or leaks.
- Never use the pipe coupling made of copper or 70% copper alloy for the acetylene hose.
- Do not use compressed oxygen to clean the gas hose.
- Do not use any hose that has experienced backfire.

## &lt; SERVICE INFORMATION &gt;

## (7) HANDLING OF THE TORCH

- Keep the torch clean and free from oil.
- To replace the nozzle, use a special tool.
- Do not use the torch as a hammer, etc..
- Do not place it directly on the ground or on the floor.
- Check suction of the torch at the end of the inflammable gas pipe coupling.



## (8) DANGER OF ARC WELDING ELECTRICAL SHOCK

- Keep cables and connections in good shape.
- Do not place machine in a wet place. Do not stand in a wet place when welding.
- Electrically ground welder. The vise clamp is not an electrical ground connection.

## WORKING WITH BODY STRAIGHTENING EQUIPMENT

## WORKING WITH BODY STRAIGHTENING EQUIPMENT : Use of Protectors


INFOID:0000000014391608

- Use of work clothes should be the same as for "PROTECTORS". Refer to [BRM-50, "PRECAUTIONS FOR OPERATION : Protectors"](#).
- Wear a safety helmet and safety shoes.
- When working under a vehicle or when using a grinder, wear goggles.


## WORKING WITH BODY STRAIGHTENING EQUIPMENT : Precautions while Working

INFOID:0000000014391609

- To prevent danger in case the clamp slips or the panel breaks, be sure to apply a safety chain. Be careful not to stand near the area where the chain is stretched.




- To prevent danger, any excessive slack in the safety chain must be taken up and properly wound.
- Do not wear a working glove on the hand that is hammering.
- Cracked glass must be removed or taped to prevent separation.
- Any cut panels must be protected with cloth or tape.



## WORKING WITH BODY STRAIGHTENING EQUIPMENT : Protection of Vehicle

INFOID:0000000014391610

- The seats and glass must be removed or covered with incombustible material, according to the type of work to be done, to prevent contamination and welding spatter.
- When removing parts, utilize padding (cloth) or protective tape.



## WORKING WITH GRINDING THE BODY FILLER (PUTTY)

## WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Danger from Dust

INFOID:0000000014391611

If workers continue to inhale dust generated during paint film removal or body filler grinding work for long periods, they may suffer from respiratory insufficiency, which results in pneumoconiosis or asthma.

## WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Precautions during Dust Generating Work

INFOID:0000000014391612

- Workers must use a sander equipped with a dust collecting function.
- Workers must work in the facilities where a dust collector is installed on the floor or the wall.

## WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Protector and Equipment

INFOID:0000000014391613

## (1) DUSTPROOF RESPIRATOR

- This is an important protector to prevent workers from inhaling dust.
- The cup type, gauze type, and other types of respirators are available.
- The respirators with the deodorizing function which utilizes activated carbons, or with the exhaust valve to release air can be selected.
- In order to maximize the respirator performance, be sure to cover your nose and mouth.
- Do not use the respirator whose useful life has expired. This is because the function of the respirator has been deteriorated.

BRM

## (2) DUSTPROOF GOGGLES

- Dustproof goggles prevent dust from entering workers' eyes.
- Goggles which can be worn on top of ordinary eyeglasses are also available.

L

M



## (3) DUST COLLECTOR

N

O

P

Dustproof sander equipped with dust collecting bag	Dustproof sander hose connected to the industrial cleaner
<p>JSKIA6412GB</p>	<p>JSKIA6413GB</p>

Dust collector installed on the floor or the wall	<ul style="list-style-type: none"><li>Dust collected through the filter</li><li>Ambient air forcibly circulated</li></ul>
 JSKIA6414GB	 JSKIA6415GB

## WORKING WITH GRINDING THE BODY FILLER (PUTTY) : Precautions during Air Blow

INFOID:0000000014391614

- Workers must wear dustproof goggles and dustproof respirators, even during cleaning work after grinding.
- Adjust the pressure for air blow duster gun to prevent dust from being scattered all over the place.
- Be sure not to disturb other workers.

## PAINT SAFETY PRECAUTIONS

### PAINT SAFETY PRECAUTIONS : Paint Safety Precautions

INFOID:0000000014391615

Observe the following precautions to maintain a safe painting work area.

- Wear an approved respirator and eye protection when painting.
- Wear approved gloves and appropriate clothing when painting. Avoid contact with skin.
- Spray paint only in a well-ventilated area.
- Cover spilled paint with sand or another absorbent material, or wipe it up at once.
- If paint gets in your mouth or on your skin, rinse and wash thoroughly with water. If paint gets in your eyes, flush with water and get prompt medical attention.
- After the painting work is finished, wash your face and gargle with water.
- Paint is flammable. Store it in a safe place, and keep it away from sparks, flames, or cigarettes.

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]


## REPAIRING PROCEDURES AND PRECAUTIONS FUNDAMENTALS OF BODY REPAIR

### FUNDAMENTALS OF BODY REPAIR : Fundamentals of Body Repair

INFOID:000000014391616

There are many kinds of damage caused by collisions. Therefore, the appropriate repair method for the damage should be selected. This section outlines repair methods of major damage and how to use the main tools.

#### BODY REPAIR FLOWCHART



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P

#### DAMAGE DIAGNOSIS

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

## DAMAGE DIAGNOSIS : Damage Diagnosis

INFOID:000000014391617

The damage must be diagnosed using the following criteria.

- Location of damage
- Range of affected area
- Degree of damage

These three points relate directly to the quality, efficiency and cost of damage repair, and they must be determined correctly.

## DAMAGE DIAGNOSIS : Determining Various Conditions of the Collision

INFOID:000000014391618

- Size, shape, position, rigidity, etc. of the other vehicle involved in the collision
- Speed of both vehicles at the time of collision
- Collision angle and direction
- Number of occupants and their positions at the time of collision
- Size, shape, hardness, etc. of load in the vehicle
- History of damaged portion, date of occurrence, and range of affected area

## DAMAGE DIAGNOSIS : External Appearance

INFOID:000000014391619


In body repair work, be careful not to overlook indirect damage. To avoid this, mechanical and structural analysis of the vehicle body is essential.

### (1) OBSERVATION OF OVERALL VEHICLE

- The extent of the impact damage
- Twisting, bending, and inclination of the whole vehicle
- Amount and location of damage: Check by examining the whole vehicle


Examples

- Cracked or stressed paint
- Cracked or broken glass



### (2) DETAILED OBSERVATION OF VEHICLE

Check for any gaps or dislocation at the welded seams of panels, or cracks in paint film, undercoating or sealing material.




### (3) OBSERVATION OF FITTING

Examine the fit of various portions without lifting them.

Estimate the damage in the pillar and hinge portions.

- Door alignment
- Alignment of hood and trunk lid
- How doors, hood, and trunk lid open and close
- Smooth operation of windows



# REPAIRING PROCEDURES AND PRECAUTIONS


< SERVICE INFORMATION >

[FUNDAMENTALS]

## (4) CHECKING FOR MECHANICAL DAMAGE

Damage analysis also involves inspecting mechanical, steering and suspension parts for damage. When inspecting mechanical parts, look for signs of damage such as


- Bent or damaged parts
- Fluid leaks
- Binding or noise when turning the steering wheel



## (5) DAMAGE BY INERTIA

Check indirect damage such as a concave roof in frontend collisions, load damage and damage to the engine, which is insulated by rubber mounts.

- Damaged or misaligned mounting points.



## DAMAGE DIAGNOSIS : Key Points in Choosing Repair Methods


INFOID:0000000014391620

- Do not reduce strength when repairing panels. Avoid excessive hammering which may lead to extending the panel.  
Also avoid prolonged heating.
- Do not increase the strength of impact absorbing portions unnecessarily. Do not patch these parts.
- Choose a method for properly aligning the body.  
For example, if changing the front side member of an FF car, it is recommended that the front suspension mounting member be left alone.
- Examine carefully how past collision damage was repaired. This is necessary to properly decide the range to be repaired.

## DAMAGE DIAGNOSIS : Parts to be Replaced

INFOID:0000000014391621

- High-strength steel parts: The strength of these parts will be reduced if repaired by heating.
- Parts relating to body alignment and wheel alignment: Replacement of such parts would not provide proper alignment.
- When repair costs exceed replacement cost.
- Availability of service parts.
- When asked by customer.
- Repair of door side impact beam and bumper reinforcement is prohibited: Beams and reinforcements must be their original shape to perform as designed. Always replace door side impact beams and bumper reinforcements if damaged.



# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

When performing repair work, it is necessary to consider quality, efficiency and cost, as well as safety and health. It is also important to gain the customer's confidence.

## CHECKING DAMAGE

### CHECKING DAMAGE : Checking Damage

INFOID:000000014391622

When completing body and frame repairs, the front body and underbody dimensions must be correct, because these dimensions directly affect wheel alignment and steering angles.

The degree of damage should be determined by using a steel tape, tram tracking gauge and centering gauge or other measuring device. The measuring points are shown in the Body Repair Manual for each model. Wheel alignments are shown in the Service Manual for each model.


### CHECKING DAMAGE : Centering Gauge

INFOID:000000014391623

Suspend the body so that it is symmetrical to the frame member. Check for bending or twisting in the body.


#### (1) TYPES

Chain type



JSKIA6422GB

Bar type




Z: Distance shown is the underbody point in the BRM for each model.

JSKIA6423GB

#### (2) DETERMINING STATE OF DEFORMATION


- Normal state

The horizontal bar and center target are in their correct positions.



- Twist

The horizontal bar is tilted on both ends.




# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


- Sag

One of the horizontal bars is lower in the vertical direction than the others.



- Side-sway

The horizontal bars are correctly aligned, but the center target is displaced.



## CHECKING DAMAGE : Tracking Gauge and Steel Tape


INFOID:000000014391624

Measure the distance between two points. Before using the tracking gauge, check the measuring points with the steel tape.

### (1) TRACKING GAUGE


- Fit the tracking gauge correctly to the measuring point.
- The dimension is indicated between the hole center.

If measurement is unavailable, use the method shown below.



### (2) STEEL TAPE


- Shape the end of the rule for ease of measurement.
- If the measuring point hole diameter is different, use the following measuring method.



# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]



## BODY STRAIGHTENING EQUIPMENT


### BODY STRAIGHTENING EQUIPMENT : Comparison of Pulling Methods

INFOID:0000000014391625

#### (1) HYDRAULIC RAM TYPE

In this method, the pressing force of a hydraulic ram is converted to a pulling force by a chain.


- Pulling points on the body may be added easily, and there is more freedom to select the pulling direction.
- The pulling direction changes during pulling.
- Difficult to simultaneously pull several points on a vertical line.



#### (2) TOWER TYPE I

In this type, force is applied by the hydraulic ram pushing the post.


- A strong force is obtained because a large ram is used, creating much leverage.
- The chain can be hooked to the post in many ways.
- Leverage can be increased or decreased by changing the position of the hook.
- The pulling direction is not restricted by the shape of the bench or a floor anchor.
- The pulling direction changes during pulling.
- Difficult to increase the number of pulling points on the body because the pulling tool itself is large.



#### (3) TOWER TYPE II

The chain is wound up through the tower by an electric or hydraulic motor.

- The direction of force does not change during pulling.
- The chain is easily set on the post because the pulling direction is constant.
- Provides great flexibility in pulling direction.
- Pulling points on the body are restricted by the number of posts.
- Pulling force is relatively strong.



## BODY STRAIGHTENING EQUIPMENT : Clamps

INFOID:0000000014391626

Generally speaking, when a body has to be straightened, the pulling device and the body must be attached to each other and the body itself must remain stationary. For this purpose, various clamps are used. Common types of clamps and their characteristics are listed below:


# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


### DIRECTIONAL CHARACTERISTICS

When pulling the clamp, the line of pulling force must extend through the center of the clamp teeth. Otherwise, the clamp may come off or damage the body panel as the clamp rotates.




JSKIA6442GB

- The figure shows how the direction of the chain's pulling force is at a downward angle from the center of the teeth. This generates a turning force on the entire clamp in the direction of the arrow. This force is amplified because of leverage, but only some of its teeth are engaged. Thus, the clamp tends to slip, which results in deformation of the body panel.




JSKIA6443GB

- Clamp direction is important in creating the pulling force. Fundamentally, three directions are considered, "X", "Y" and "Z".



BRM

- Directional ("X", "Y" and "Z") characteristics are shown below for several kinds of clamps.



JSKIA6445GB

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >


[FUNDAMENTALS]

## BODY STRAIGHTENING EQUIPMENT : Hooks and Other Tools

INFOID:000000014391627


### (1) HOOKS

- Unlike clamps which grab an object, hooks are curved tools that pull on the body. When a hook is used, it must be set so that the point where the body is pulled and the position of the hook's chain are lined up straight.



JSKIA6446ZZ

- When a hook is used, a piece of wood, etc. should be inserted between the hook and body in order to prevent damage to the body.




JSKIA6447GB

### (2) SPECIFIC-USE PULLING TOOL

Specific-use pulling tools are special jigs which are used to repair a specific part of the vehicle.

An example of a specific-use pulling tools, a strut puller, is shown in the figure.



JSKIA6448GB

## BODY STRAIGHTENING EQUIPMENT : High Intensity Cabin Structure

INFOID:000000014391628

In recent years, the body construction of vehicles is changing for the purpose of protecting passengers at the time of the collision.

A greater use of high strength sheet steel reinforcements and the adoption of sheet steels of different thicknesses are good examples of securing survival space for passengers. Deformation caused when the vehicle body is damaged is controlled through modification of the body construction.

The following points must be kept in mind when high intensity cabin structure bodies need to be repaired.

- No special skills are necessary in body straightening work.
- Body technicians must have a good understanding of the construction of the vehicle body to be repaired.
- Understanding the accurate damage range (performing accurate measuring work) is necessary.
- A greater force is required for straightening because of an increased use of high strength steel plate reinforcements.

It is necessary to perform additional anchoring for the frame straightening equipment with which multiple jig anchoring is not possible in order to prevent secondary damage.

- Pulling force must be applied evenly to prevent welded points from breaking. (Simultaneous pulling in multiple directions, etc..)


# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

- The anchoring jig specific to each vehicle model is used for vehicles which cannot be anchored at the sill lower flange.


## (1) HIGH INTENSITY CABIN STRUCTURE



- When a front or rear end collision occurs, the crushable zone provided at the front and rear of the vehicle effectively absorbs impact energy and cushions the shock to the passengers. In addition, the safety zone securely maintains a survival space.
- Energy absorbing beads and high strength sheet steel reinforcements are used as front side members.
- Outrigger construction. (Distributes impact energy from front side members.)

## (2) HIGH INTENSITY CABIN STRUCTURE (SIDE IMPACT)

- To improve the lateral strength of the occupant compartment, lateral strength such as crossmembers, steering member and reinforcements for roof side, center pillars and body sills are redesigned.
- When a side collision occurs, the side door beams and doors minimize deformation of the body by absorbing impact energy subjected from the lateral direction, and by distributing energy over the reinforced body side.



## REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT

### REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT : Securing the Vehicle

INFOID:000000014391629

To prevent the movement of vehicle, use a suitable method that can resist the pulling force required for repair.


#### (1) ANCHORING POINT

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >


[FUNDAMENTALS]

For passenger vehicle




JSKIA6451ZZ

For van model




JSKIA6452GB

For frame model



JSKIA6453GB



JSKIA6454GB


## CAUTION:

- Choose the foundation of a rigid pillar or a member for anchoring point.
- Set the equipment so that the direction of claw clamp is opposite to the direction of pull.

## (2) ATTACHMENT OF CHAINS


- Pulling to the front of vehicle

The vehicle will be secure if it is pulled in the range indicated by the arrows in the figure. The rear side is the opposite of this.



- Pulling to the left or right side

Pull the vehicle within the range indicated by arrows.




## (3) ANCHORING POINT FOR FRAME MODEL USING FRAME CLAMPING

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

If the frame cannot be anchored to the straightening equipment with the basic anchoring method the frame can be directly anchored by using frame clamping system. The figure shows an example in which the spring shackle is anchored without the spring being removed.




## REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT : Securing and Pulling

INFOID:000000014391630

In principle, the pulling force must be applied in the exact opposite direction of the impact force (input). The securing method must match this pulling direction.


### (1) DOWNWARD PULL

Secure as close to the damaged portion as possible. If there is a separation between the pulling point and damaged point, the undamaged portion will also be pulled.




### (2) UPWARD PULL

Set the supporting so that undamaged portions will not be affected by pulling.



### (3) FIXING AND PULLING METHOD FOR SIDE BEND

To pull the front part of vehicle, secure the vehicle body to avoid movement by the moment of rotation caused by pulling.



### (4) FIXING AND PULLING METHOD FOR DIAMOND


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

If only points (A) and (B) are secured, a moment of rotation may result. Establish another supporting point at portion (C).




### (5) SIMULTANEOUS PULLING IN MULTIPLE DIRECTIONS

This method can shorten repair time, and also prevent secondary damage.



### (6) SIMULTANEOUS PUSH-PULL METHOD


This method may be used when stress is concentrated at the front side member. The front of the front side member is bent inward while the rear is bent outward.



### (7) ROOF DAMAGE

Connect an extension tube to the ram.

Positioning it near the vehicle body will result in increased pulling length.



## REPAIR PROCEDURE FOR PULLING

### REPAIR PROCEDURE FOR PULLING : Repair Sequence

INFOID:0000000014391631

In general, no single bend or twist is produced in a collision. Body deformation results from a combination of bending and twisting and other types of damage.

Repair should start where the damage is most deeply propagated.

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

If concentrating only on apparent damage while overlooking the propagation of impact to the whole body, it is impossible to obtain correct body alignment.




Repair work should basically be performed in this order of damage.

JSKIA6465GB


## REPAIR PROCEDURE FOR PULLING : Key Points in Actual Repair Work INFOID:000000014391632

### (1) STRETCHING SHRUNK PORTIONS

- The repair of a bent closed cross-sectional structure, such as a side member, is done by clamping the surface of the bent-in side and pulling. The pulling direction should be such that force is applied in the direction of an imaginary straight line extending through the original position of the part.




- Sometimes a load of approximately 5,000 kg (11,025 lb) is applied during repair work. Accordingly, the clamp must be tightened securely. Be sure to use safety chain.



### (2) GRADUAL PULL

- Pull step by step.  
The damaged portion may be work hardened.  
Pulling all at once may cause cracking.




# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

- Reduce the hardness of the work-hardened portion.

Locally heat the panel to 400°C - 500°C (752°C - 932°F) to the extent that the panel is not colored. Do not heat above 700°C (1,292°F), or strength will be reduced. Do not raise to a temperature of more than 550°C (1,020°F) for HSS parts.




### (3) CONSIDER SPRING-BACK

When pulling force is applied to a panel, spring-back is generated by the residual stress.


- Proper amount of pull

Pull 2 mm - 3 mm (0.08 in - 0.12 in) more than the required dimension. Adjust the amount of pull corresponding to the spring-back.




- Use of hammer

Residual stress caused by kinetic energy of the collision can be removed by hammering.



### (4) DETERMINING PROPER AMOUNT OF PULL BY OBSERVING DOOR FIT

The proper amount of pull can be determined by observing the clearance at the door or trunk lid.



### (5) PULLING UPPER PORTIONS FROM UNDERBODY CLAMP


Note that if there is distance between the pulling point and the underbody clamp, as indicated by (A) in the figure, a moment of rotation is produced.

# REPAIRING PROCEDURES AND PRECAUTIONS


< SERVICE INFORMATION >

[FUNDAMENTALS]

This may cause secondary damage to the clamped portion.




Provide a supporting point under the side member to prevent generation of this moment of rotation.



## (6) ADDITIONAL ANCHORING

Pulling work must be performed with care taken not to damage the anchoring points or undamaged area of the body. If area not targeted for repair is affected by the excessive pulling force or the direction of pulling, additional anchoring points need to be provided to protect undamaged areas. Side sills are strong enough against longitudinal force, however, they are easily damaged by downward or lateral force. For this reason, additional anchoring should be provided by supporting side members with the port power, or attaching a clamp and chain.



## (7) PURPOSE OF BODY ALIGNMENT

This operation is necessary to obtain correct alignment of parts to be used again. Therefore, the damage caused by propagated impact is recovered by pulling out the first input point.

## REPLACEMENT OF PANEL

### REPLACEMENT OF PANEL : Replacement of Panel

INFOID:0000000014391633

Panel replacement work includes replacement of the front fenders and hood which are installed by bolts, and replacement of rear fenders and the roof which are welded. This section explains panel replacement procedures after adjusting body alignment.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# REPAIRING PROCEDURES AND PRECAUTIONS


< SERVICE INFORMATION >

[FUNDAMENTALS]

## REPLACEMENT OF PANEL : Door Hemming


INFOID:000000014391634

(a) Sand the edge part of door outer panel using belt sander.




JSKIA6851ZZ

(b) Insert the tip of a sharp-edged tool, such as a chisel, into the clearance at door outer panel. Use a hammer to tap the tool inserted into the clearance from the side to separate the door inner panel and door outer panel.



JSKIA6852ZZ

(c) Remove the adhesive adhering to the door inner panel flange area surface.




JSKIA6853ZZ

(d) Adjust the position where the new door outer panel and door inner panel overlap. Once these are positioned correctly, fix them with clamps to prevent them from being displaced.

Apply new adhesive to both door outer panel and door inner panel.

**<Adhesive> 3M™ Automix™ Panel Bond 8115 or equivalent**




JSKIA6854ZZ

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

(e) Hold the dolly on the corners of the flange at door outer panel. Tap the dolly with a hammer to bend the door outer panel flange area gradually.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J

(f) Bend with hammer until the angle of the whole circumference of the door outer panel flange area becomes approximately 45°.



F  
G  
H  
I  
J


(g) Check that the position of the door outer panel and door inner panel is not displaced while tapping it with a hammer to bend it until the angle of whole circumference of the door outer panel flange area becomes approximately 15°.



BRM

L  
M  
N  
O  
P

(h) Check that the position of the door outer panel and door inner panel is not displaced while tapping it with a hammer to bend it until the angle of the whole circumference of the door outer panel flange area becomes approximately 0°.




# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


(i) Use the hemming tool [SST: KV991-10000] to adjust the shape of the whole circumference of the door outer panel flange area.



JSKIA6859ZZ

(j) Seal up the area around the hemmed end of the flange.

- ① **Door inner panel**
- ② **Door outer panel**
- ③ **Adhesive**
- ④ **Sealant**



JSKIA6860ZZ


## REPLACEMENT OF PANEL : Adjustment Fitting of Front Fender

INFOID:000000014391635

Fitting adjustment means adjustment of clearance or gradient of the hood, door, front fender, etc. with respect to its adjacent part, and adjustment of gradient at the press line.

Adjustment of front fender is described as an example.

- Adjust the fitting at the front fender mounting position. Tighten the front fender mounting bolts loosely, and adjust the fit by moving the front fender sideways or in the up-down direction while observing the clearance with the hood and door.



JSKIA6476GB





- Adjust the front fender bend angle.

If a proper fit cannot be obtained by step (1) above, change the bending angle of the front fender.

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]


Explanation	Condition	Correction method
When the clearance between the front fender and hood is too small: Apply a flat wood plate to the upper corner of front fender, and correct by hammering. Before hammering, securely tighten the front fender mounting bolts.	 <p>JSKIA6477GB</p>	 <p>JSKIA64782Z</p>
When the clearance between the front fender and hood is too large: Apply a scribing chisel to the bend at the base of the front fender. Tap with a hammer to adjust the clearance. Securely tighten the front fender mounting bolts before tapping. Apply the scribing chisel along the press line.	 <p>JSKIA6479GB</p>	 <p>JSKIA6480GB</p>

## REPLACEMENT OF PANEL : Adjustment Fitting of Door Assembly


INFOID:000000014391636

When there is excessive clearance on the upper part of door:

- Apply a wood block between the outer sill and the lower side of door, and push the upper part of door.



- When there is excessive clearance on the lower part of door.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL)

### PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Partial Replacement of Panel (Welded Panel)

INFOID:000000014391637

If damage occurs in a welded panel, it can be entirely replaced by a service panel or partial replacement can be done by cutting and replacing damaged portion with a service panel.

### PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Welded Panel Replace-


# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

## ment Procedure

INFOID:0000000014391638



JSKIA6483GB

### NOTE:


When welding and dressing the parts, cover up holes of these parts with tape to prevent debris from entering.

- Assembly panel replacement or partial panel replacement

Assembly panel replacement means replacement of a complete panel by cutting all the welded portions.

Partial panel replacement is a method by which only the damaged portion of a panel is replaced. Partial panel replacement can be used when assembly panel replacement is too costly and time consuming, and when the damage is localized.

- Cutting positions for partial replacement



JSKIA6484GB

Cutting panels for partial replacement is not allowed on some portions. If panels are cut in improper portions, body strength cannot be maintained. The allowable positions vary with body structure, panel strength or shape and differ from model to model. They are indicated in the Body Repair Manual of each model. In principle, the following portions may be cut:

- Portions without reinforcement or ducting
- Portions where no stress concentration occurs
- Portions with small finish area where finishing can be easily accomplished (where the connected portions can be covered by garnish or moulding)
- Portions where work area or disassembling of parts is minimized

## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Rough Cutting of Panel

INFOID:0000000014391639

Most body panels are joined by spot welding. It is difficult to cut them at the welded portion.

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

To shorten work time, pull the damaged portion roughly, then cut near the panel joint in advance so that tools can be used properly to cut the spot welded portion. It is commonly used on panels having complicated structures.

Cutting body panel and service panels by leaving an overlap tolerance is also called rough cutting. Use the cutting tools properly according to the portion to be cut, panel thickness, and panel structure. Tools commonly used for this purpose and their features are described below:


### (1) ROUGH CUTTING USING AN AIR SAW

#### (a) Major application

Members and pillars including side member, cross member, rear pillar, etc..

#### (b) Features

Clear cut line. Suitable for cutting both thin and comparatively thick sheet metal.



### (2) ROUGH CUTTING USING AN AIR CHISEL

#### (a) Major application

Thin sheet metal including the rear fender and rear floor

#### (b) Features


Faster cutting speed

High noise level

Not applicable to thick sheet metal

Irregular cut line

Excessive sparking




### (3) ROUGH CUTTING WITH AN OXY-ACETYLENE CUTTING TORCH

#### (a) Major application

Thick sheet metal including side member, cross member, hoodledge, etc..

#### (b) Features

Faster cutting speed



### (4) ROUGH CUTTING WITH A PLASMA CUTTER

#### (a) Major application

Floor, door, rear fender, roof, flat panels.

#### (b) Features

Faster cutting speed


Only small will be affected by heat.

This is suitable for cutting conductive materials.

Aluminum, stainless, and carbon steel can be cut.

Cut off damaged portion as shown in the figure.

Be careful not to cut inner rear pillar reinforcement.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Cutting Off Welded Por-

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

tions

INFOID:000000014391640

A vehicle body is constructed by using three different welding methods [spot welding, gas shielded arc (GSA) welding and brazing]. Cutting welded portion by these methods is described below.


Spot welding is generally used on two or more overlapped panels. The tool or cut off method must be changed according to whether the panel to be removed is on the top, in the middle or on the bottom.

## (1) CONFIRMING THE SPOT WELDED POSITION

Remove paint, undercoat, and sealer from the panel to confirm the spot welded positions.


(a) Using air sander or rotary wire brush:

When using this method, do not grind too much of the panel. Sand or brush the panel while confirming the spot welded portion.



(b) Using a chisel:

If the spot welded portion is indiscernible even after removing paint, insert the chisel blade between the panels and tap lightly with a hammer for confirmation.




## (2) CUTTING OFF SPOT WELDED PORTION


(a) Using a spot cutter:

There are two types of spot cutters (a drill type and a hole saw type). When using the spot cutter, be careful not to cut the lower panel.

Spot cutter (drill type)



Spot cutter (hole saw type)




# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]



If it is difficult to weld from behind the lower panel, the spot cutter may be used to cut the spot welded portions without drilling the bottom panel.

The hole saw type spot cutter requires grinding of the spot weld after cutting. This requires additional work time.




### (b) Using drill:

The drill may be used to cut welds from any portion welded by plug welding, by drilling out the plug welded portion.



### (3) CUTTING SPOT WELDED PORTIONS WITH AN AIR SANDER


If the spot cutter cannot be used, use the air sander (or belt sander) to cut off the spot welded portion.



### (4) REMOVING PANEL WITH A CHISEL

After cutting the spot welded portions, separate the panel using the chisel.

By doing this, spot welded portions will separate from their mating surfaces. Thus, work can proceed while confirming the separation of spot-welded portions.



### (5) CUTTING GSA WELDED PORTIONS


# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

The GSA welding method is divided into two types (plug welding and seam welding). The plug weld portion can be cut off with a spot cutter or the like. To cut off the seam welded portion, grind the seam-weld bead with an air grinder to cut the welded portion. Be careful to grind from the replacement panel. Do not grind the reused panel excessively.

GSA = Gas Shielded Arc welding



### (6) CUTTING OFF BRAZED PORTION OF PANEL


Brazing is used to improve the external appearance of the joined portion (roof and fender) of the body outer panel as well as to improve sealing. Brazed portions can be generally disconnected by dissolving the braze with an oxy-acetylene torch.

If arc brazing was used, cut off the welded portion with an air sander or the like. The melting temperature of arc brazed metal is higher than that of ordinary brazing, and the panel may be damaged by this high temperature. Ordinary brazing and arc brazing may be discriminated by observing the color of the brazed metal. Ordinary brazing looks like a brass, while arc brazing has a copper color.

#### (a) Cutting with an oxy-acetylene torch


Melt the filler metal with the oxy-acetylene torch.

Remove the metal with a wire brush and separate the panel. While the filler metal is still hot, insert the tip of a screwdriver or the like between panels to prevent re-adhesion.



#### (b) Cutting with an air grinder

Cut off the brazed portion with the air grinder. Do not grind excessively the panel to be reused.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Precautions for High Strength Steel (HSS)

INFOID:0000000014391641


High strength steel (HSS) means the steel from 440 MPa - 979 MPa.

# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]


(a) The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon-type and other similar type thermometer are appropriate.)




(b) When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points, and carefully pull the HSS panel.



(c) When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97 in).



(d) When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use GSA welding. Do not use gas (torch) welding because it is inferior in welding strength.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
BRM  
L  
M  
N  
O  
P


# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(e) The spot weld on HSS panels is harder than that of an ordinary steel panel.

Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 rpm - 1,200 rpm) to increase drill bit durability and facilitate the operation.




INFOID:000000014391642

## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Prohibition for Ultra High Strength Steel (UHSS)

Ultra high strength steel (UHSS) means the steel from 980 MPa or higher.

Never cut and joint the panel, plate and reinforcement made of ultra high strength steel (UHSS).

If such part is damaged, replace the part.



INFOID:000000014391643

## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Rear Fender Hemming Process

When the rear fender and the outer wheel housing have been joined with adhesive, the panel replacement method described below is used.

1. A wheel arch is to be installed and hemmed over left and right outer wheel house.
2. In order to hem the wheel arch, it is necessary to repair any damaged or defaced parts around outer wheel house.

### CAUTION:

Ensure that the area that is to be glued around outer wheelhouse is undamaged or defaced.


### Procedure of the hemming process

(a) Peel off old bonding material on the surface of outer wheelhouse and clean thoroughly.

(b) Peel off a primer coat in the specified area where new adhesive is to be applied on rear fender. (the replacing part.)

(c) Apply new adhesive to both specified areas of outer wheelhouse and rear fender.

**<Adhesive> 3M™ Automix™ Panel Bond 8115 or equivalent**




# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]


(d) Attach rear fender to the body of the car, and weld the required part except the hemming part.  
(e) Bend the welded part starting from the center of the wheel arch gradually with a hammer and a dolly. (Also hem the end of the flange.)  
(f) Hemming with a hammer is conducted to an approximate angle of 80°.



(g) Starting from the center, hem the wheel arch gradually, using slight back and forth motion with a hemming tool [SST: KV991-10000].




(h) Seal up the area around the hemmed end of the flange.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Welding Method for Stud Bolt and Nut

INFOID:000000014391644

When stud bolts and weld nuts are not welded on the part acquired for repair, and are supplied as separate parts, use the following method to perform welding.



### (1) FLANGE BOLT

# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

1. Remove paint, rust, or oils on the surface of the panel.
2. Insert the bolt, temporarily tighten the matching nut of the bolt, and perform centering.
3. Weld 3 points evenly by MIG weld. [approximately 3 mm (0.12 in)]
4. Apply an appropriate anti-corrosive treatment to the respective locations.


**NOTE:**

The same welding method is also applied when welding on a panel surface without a through hole. Welding is performed with the bolt head surface and panel contact surface contacting.



### (2) WELD NUT

1. Remove paint, rust, or oils on the surface of the panel.
2. Put the nut on the panel center of the hole, temporarily tighten the matching bolt of the nut, and perform centering.
3. Weld 3 or 4 points evenly by MIG weld. [approximately 3 mm (0.12 in)]
4. Apply an appropriate anti-corrosive treatment to the respective locations.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Preparation for Service Panel Installation

INFOID:0000000014391645


After removing the damaged panel, two operations are needed. Preparation for service panel installation and finishing of the panel mounting portion of the body.

### (1) FINISHING BODY


(a) Grind clean around the area where the spot-welded panel has been removed. Thoroughly remove rust and other contamination from the mating surface.

Also, remove paint from the portion to be welded.

Any brazing metal should be thoroughly removed, otherwise welding will be impaired.



(b) Irregularities on the panel mating surface prevent the panel from being welded correctly. Using a hammer and dolly, correct the shape of the mating surface.




# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(c) Apply conductive anti-corrosive treatment [spot sealer for spot welding or weld through primer (metallic solution) for GSA welding] in places that cannot be painted in the subsequent painting process.




(d) If it is impossible to apply sealer after welding the service panel, sealer should be applied before welding.



## (2) PREPARATION FOR SERVICE PANEL INSTALLATION

(a) The service panel is coated with primer. Remove the primer and apply spot sealer at the portions to be welded. Do not allow the spot sealer to be forced out of the mating surface of the panel.




(b) Drill the service panel for plug welding, if necessary.

Refer to the Body Repair Manual of applicable model for the number of holes to be drilled for plug welding. The number of holes must be the same as the number of original spot welds. The drill holes must be spaced equally. Drill hole diameter must be changed according to panel thickness to maintain welding strength.

Plug hole diameter and panel thickness

Panel thickness	Plug hole dia.
Below 1.0 mm (0.039 in)	Below 5 mm (0.20 in)
1.0 mm - 2.4 mm (0.039 in - 0.094 in)	6.5 mm - 10 mm (0.256 in - 0.394 in)
Over 2.4 mm (0.094 in)	Over 10 mm (0.39 in)



## (3) UNDERSTANDING SERVICE PARTS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# REPAIRING PROCEDURES AND PRECAUTIONS



## < SERVICE INFORMATION >

## [FUNDAMENTALS]

This is important in judging when the panel should be replaced, or in determining conditions for efficient operation.

Service parts should be prepared with reference to the Parts Catalog for each model.

The integral type outer body side panel consists of two types of service panels. These service panels need to be cut for use depending on the location and degree of the damage.



## PARTIAL REPLACEMENT OF PANEL (WELDED PANEL) : Anti-corrosive Treatment


INFOID:0000000014391646

Anti-corrosive treatment may be performed on three different occasions (before welding, before painting, and after painting). This section explains anti-corrosive treatment for the latter two occasions.

### (1) ANTI-CORROSION TREATMENT BEFORE PAINTING


#### • Application of body sealer

Body sealer prevents water or mud from entering through the mating surface of the panel. It also prevents formation of corrosion. The sealer nozzle hole should be small. Use a finger or brush to shape the applied sealer. Refer to the Body Repair Manual for body sealer application points.



#### • Application of undercoating

Apply undercoating to the underbody and inside of wheelhouse. Do not apply it to the exhaust pipe, suspension or driving portions.




### (2) ANTI-CORROSION WAX AFTER PAINTING

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

Apply anti-corrosive wax to the back of the panel where painting is difficult. Insert the nozzle of anti-corrosive wax into the holes in the inner panel. Apply until the anti-corrosive wax bleeds out from panel mating surface.



JSKIA6568GB

## USE OF BODY FILLER (PUTTY) AND GRINDING

### USE OF BODY FILLER (PUTTY) AND GRINDING : Use of Body Filler (Putty) and Grinding

INFOID:000000014391647

Panel irregularities may be corrected with a hammer and dolly. However, exact restoration of the original shape with these tools takes a long time. Body filler may be used to restore the original panel profile. For this purpose, the panel surface is finished slightly lower than the original surface.

Filler is applied to finish the shape and also to reduce the time needed for repair.

In body repair shops, the most commonly used materials are body filler, polyester putty, and detail putty.

This section mainly describes the body filler.

Polyester putty is described in the paint manual.

### USE OF BODY FILLER (PUTTY) AND GRINDING : Types of Filler and Putty

INFOID:000000014391648

Type (Standard thickness limits)	Characteristics		
Body Filler Putty (For repairing of large dents or scratches) [10 mm (0.39 in)]	Surform type	<ul style="list-style-type: none"><li>This type of filler requires surforming (rough grinding). It will clog sandpaper if it is sanded only.</li><li>Can be thickly applied to panel.</li><li>After drying, grindability is poor as it is harder than other types.</li></ul>	
	Light Type	<ul style="list-style-type: none"><li>This type of filler contains tiny hollow beads. It feels gritty when applied with a spatula.</li><li>Suitable for thick application to panel</li><li>Superior grindability after application</li><li>Forms blowholes easily</li></ul>	
	Glass Fiber or Aluminum Powder Type	<ul style="list-style-type: none"><li>Excellent thick application to panel</li><li>Superior corrosion prevention and durability</li><li>Suitable for repairing rusty holes in panel</li></ul>	
Intermediate Filler Putty [10 mm (0.39 in)] (For repairing of large dents or scratches)	<ul style="list-style-type: none"><li>Good sanding characteristics.</li><li>It is difficult for fine grain pores to form in it, so poly putty can be eliminated and surfacer can be applied directly over intermediate filler.</li></ul>		
Polyester Putty (For filling pores and sand scratches in body filler)	Spatula Type [3 mm (0.12 in)]	<ul style="list-style-type: none"><li>Not very much thickness can be built up.</li><li>It has fine grain and good flexibility.</li><li>Since no volatile content remains, there is no depletion after baking.</li><li>Sanding characteristics are good.</li></ul>	
	Spray Type [1 mm (0.04 in)]	<ul style="list-style-type: none"><li>Not very much thickness can be built-up.</li><li>Since a spray gun is used, it can be applied easily to any location.</li><li>Drying time is approximately two times as long as putty applied with a spatula.</li></ul>	

A  
B  
C  
D  
E

F  
G  
H

BRM

I

J

L

M

N

O

P

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

Type (Standard thickness limits)	Characteristics
Lacquer Putty [0.1 mm (0.004 in)] (Detail putty)	<ul style="list-style-type: none"><li>It is soft and flexible.</li><li>It cannot be used to built up low areas.</li><li>Standing characteristics are extremely good.</li><li>The thicker the built-up, the longer the drying time.</li></ul>
Ultraviolet Curing Putty	<ul style="list-style-type: none"><li>Since the drying time is short (approximately 20 seconds after UV irradiation), body work can be completed in a short period of time.</li><li>This is often used for minor repairs.</li><li>Putty becomes very hard after hardening, therefore its grindability with sandpaper is not good.</li><li>It is expensive.</li></ul>

## NOTE:

Putty film thickness limits should be decided with putty manufacturer because limits vary from maker to maker.

## USE OF BODY FILLER (PUTTY) AND GRINDING : Procedure for Applying Body Filler


INFOID:000000014391649

### (1) REMOVAL OF PAINT

Using an air sander, remove old paint from the panel surface for better filler adhesion. Form a featheredge on the panel surface approximately 20 mm (0.79 in) wider than the correction area in order to eliminate traces of body filler application.

### (2) CHEMICAL CONVERSION COATING

Body skin panels of NISSAN vehicles use anti-corrosive steel. These panels should be coated with chemical conversion coating before applying common body filler.




If body filler has been developed for anti-corrosive steel, chemical conversion coating will not be needed. (Please confirm this with the body filler supplier.)

JSKIA6569GB

### (3) SPATULA MOVEMENT

Move the spatula lengthwise when applying to an oval shaped area.

If applying to a round area, move the spatula in many directions as shown in the figure.




JSKIA6570GB

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]




A  
B  
C  
D

## (4) APPLYING TECHNIQUE

Apply body filler in several thin layers.

(a) Hold spatula well balanced and hold slightly standing position, then squeeze putty into scratches.

**a :  $60^{\circ} - 90^{\circ}$**




E  
F  
G  
H

(b) Put a large amount of filler on the spatula.

Hold spatula slightly lean, then apply several times (do not put much in once) until covered above datum level.

**b :  $30^{\circ} - 45^{\circ}$**




I  
J

BRM

(c) Use the spatula to smooth the applied filler.

Perform finishing work for smoothening the surface. The filler surface should be slightly higher than the panel surface.

**c : Less than  $30^{\circ}$**



L  
M  
N  
O  
P


## (5) PRECAUTION FOR APPLYING

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

Be careful not to place body filler over the old lacquer type paint. If this is done, the paint will be softened by the thinner when painting. This causes the body filler to shrink and concave will result.




### (6) APPLICATION OF BODY FILLER TO FLAT SURFACE


(a) Apply filler so that the corrected surface is flush with the surrounding panel surface.



(b) Apply another layer of filler to overlap 1/3 - 2/3 of the previous application to eliminate the step.



(c) Repeat (b) until the filler is correctly applied to the desired portion.




### (7) APPLICATION OF BODY FILLER TO CURVED SURFACE

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

Use of a flexible rubber spatula is recommended for application to curved surfaces.



### (8) APPLICATION OF BODY FILLER TO PRESS LINE


- (A) Apply tape along the press line. Then apply filler to only one side of the press line.
- (B) Peel the tape from the half-dried filler.
- (C) Apply tape along the filled and half-dried filler line.
- (D) Apply filler to the other side of the press line.



## USE OF BODY FILLER (PUTTY) AND GRINDING : Drying the Body Filler

INFOID:0000000014391650

When the hardener is mixed with the base, the filler begins to harden. Heat is also generated, which accelerates hardening. For this reason, filler drying speed varies with the applied thickness. If a thick coat of filler is applied, the generated heat remains inside, hence it hardens quickly. Where the filler is not so thick, it hardens rather slowly because heat dissipates to the outside.



Approximately 10 - 20 minutes (at 20°C or 68°F) after application, the filler becomes hard enough to permit grinding with a surform. When the ambient temperature is low, use a panel heater or adjust the drying time. To check whether the filler is dry or not, press a thin portion with finger. If it is dry, then it is suitable for grinding.

## USE OF BODY FILLER (PUTTY) AND GRINDING : Grinding the Filled Area

INFOID:0000000014391651

Grind the filler when it is half-dried. Half-dried filler means the condition where the surface, if ground lightly with a surform, will produce continuous linear chips. Grinding with the surform will be difficult after the filler hardens completely.

### (1) ROUGH GRINDING BY SURFORM


A vertical column of letters from A to P, likely representing a table of contents or a navigation menu.

# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]


Smooth the filler surface by grinding with the surform or the like. Grind in many different directions. Better results may be obtained if the surform is inclined 30° - 40° with respect to the direction of movement. Be careful not to damage the surrounding panel surface.



### (2) ROUGH GRINDING BY AIR SANDER


Smooth the filler surface by grinding with the dual action sander or orbital sander. Grind in many different directions.

This grinding method is faster than the method using a surform. However, if the worker is not accustomed to performing this type of grinding, an uneven surface may result from excessive grinding. #60 - #80 sandpaper is used.




### (3) SHAPING THE ENTIRE PANEL

Using an orbital sander or dual action sander, trim the shape of the filled panel. Leave the amount required for final finishing. #120 - #180 sandpaper is used.



### (4) FINAL FINISH BY HAND FILE

Using a hand file, orbital sander or dual action sander, smooth and form featheredge on the filler surface until it is flush with the surrounding panel. #240 - #320 sandpaper is used.




# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

## USE OF BODY FILLER (PUTTY) AND GRINDING : Sandpaper Grits

INFOID:000000014391652



Select a sandpaper with a grit, appropriate to the putty used. Sanding marks that occur due to sanding are removed with further sanding.

### SWITCHING TO A SANDPAPER OF A DIFFERENT GRIT

Sanding marks that occur during sanding are sanded with a sandpaper of the next finer grit. When doing this, do not sand using a sandpaper of a grit two grades or more finer than the previously applied sandpaper.

**NG** : #80 ⇒ #180 ⇒ #320 ⇒ #400

\*: Note that, if sanding with a sandpaper of a grit two grades or more finer than the last one used, removing deep sanding marks that occur during sanding with a coarser sandpaper, as well as removing any remaining deep sanding marks may take longer.

**OK** : #120 ⇒ #180 ⇒ #240 ⇒ #320 ⇒ #400


## USE OF BODY FILLER (PUTTY) AND GRINDING : Grinding Power of Air Sander

INFOID:000000014391653

The diameter (shown in the figure) of a circle traced by a part of the dual action sander and the orbital sander is called an orbit diameter. The larger the area shown with diagonal lines, the greater the grinding power is.

When surface accuracy is required, a sander with a smaller orbit diameter should be selected. When grinding power is required, a sander with a larger orbit diameter should be selected.

Work content	Orbit diameter
Sanding a body filler	7 mm - 10 mm (0.28 in - 0.39 in)
Sanding a primer surfacer	4 mm - 5 mm (0.16 in - 0.20 in)
Roughing surface before topcoating	3 mm - 4.5 mm (0.118 in - 0.177 in)



## REPAIR OF RUST AND CORROSION

# REPAIRING PROCEDURES AND PRECAUTIONS

< SERVICE INFORMATION >

[FUNDAMENTALS]

## REPAIR OF RUST AND CORROSION : Repair of Rust and Corrosion

INFOID:0000000014391654


Rust on sheet metal is the result of the chemical reaction of steel to oxygen in the air, which is called oxidation. This rust, if left untreated, will increase and finally corrode and damage the sheet metal. If the vehicle is used for a long time under severe environmental conditions, rust or corrosion may form on body surfaces. When repairing rust and corrosion, it is necessary to keep rust from spreading from the repaired portion.

### REPAIR OF RUST AND CORROSION : Removal of Rust Limited to the Skin Panel Surface

INFOID:0000000014391655

Grind the rusted portion with an air sander or the like.

Rust may be more extensive than it appears from the outside. Therefore, it is necessary to grind the area around rusted portion. Repair the ground out portion using body filler.




## REPAIR OF RUST AND CORROSION : Repair of Corroded Panel


INFOID:0000000014391656

### (1) FILLING WITH FIBERGLASS

(a) Grind off the corroded portion of the panel with an air sander. If corrosion is severe, cut off the affected portion with a chisel or tin-man's shears. Remove the paint from the surrounding areas.



(b) Hollow the area surrounding the repair hole by tapping with a hammer and bending the panel.




# REPAIRING PROCEDURES AND PRECAUTIONS

## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(c) Cut a piece of fiberglass cloth. The cloth should be large enough to overlap the repair hole.


Apply fiberglass putty to the cloth using a spatula until the mesh is filled. Prepare the fiberglass putty by mixing 100 parts of base with 2 to 3 parts of hardener.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

(d) Apply a thin coat of fiberglass putty to the panel where the piece of fiberglass cloth is to be attached.


Apply putty also to the edge and back of the repair hole.



F  
G  
H  
I  
J

(e) Apply the piece of fiberglass cloth to the surrounding portion and the back of the repair hole.

This is necessary to prevent rust.




BRM  
L  
M  
N  
O  
P

# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(f) Apply the piece of fiberglass cloth prepared in step (c) above to the repair hole. Press the periphery of the cloth to the panel for better adhesion. If the repair hole is large and the cloth sags in the center, support the cloth with tape applied behind the panel.




(g) Apply the fiberglass putty to the piece of fiberglass cloth. The fiberglass putty surface should be below the surrounding panel surface. If the area to be repaired is deep, use two or more piece of fiberglass cloth. In such a case, avoid thick application of fiberglass putty. Thick fiberglass putty will crack after drying.



(h) Dry the fiberglass putty, and grind the surface with an air sander. Then trim the entire panel using body filler.

When force drying fiberglass putty, allow the putty to sit for approximately 20 minutes. Then heat at a temperature below 60°C (140°F). Rapid heating which causes the putty to change color must be avoided, as it will lead to cracked putty. Fiberglass putty forms blow-holes easily. Body filler must be used to finish the surface of fiberglass putty.



## (2) PATCHING

# REPAIRING PROCEDURES AND PRECAUTIONS


## < SERVICE INFORMATION >

## [FUNDAMENTALS]

(a) Remove the corroded portion of the panel.


Remove paint from the panel around the repair hole.

Make a flange by bending the surrounding panel with pliers and hammer, then apply anti-corrosive treatment (Metallic solution).




JSKIA6598GB

(b) Using tinman's shears, cut a patch large enough to overlap the repair hole. Apply the anti-corrosive treatment to the portion to be welded. Use of stainless steel is recommended to avoid rusting. If the repair hole is large, use a panel having the same thickness as the original panel to retain the original strength.



JSKIA6599GB

(c) Weld the patch to the repair hole. If stainless steel is used, use the MIG welding or spot welding method.




JSKIA6600GB

BRM

### NOTE:

When welding the patch by GSA welding, use the plug welding method.



JSKIA6601GB

L

M

N

O


P

# REPAIRING PROCEDURES AND PRECAUTIONS


< SERVICE INFORMATION >

[FUNDAMENTALS]


(d) Apply the body filler to the repaired portion of the panel.



(e) Apply the anti-corrosive treatment to the back of the panel. If accessible from behind, apply a sealer to the panel-to-patch mating section.



(f) If inaccessible from behind, apply an anti-corrosive wax from an inner panel opening or the like. It is also important to apply the anti-corrosive treatment to other portions in addition to the repaired portion.



&lt; SERVICE INFORMATION &gt;

**FRAME REPAIR****GENERAL INFORMATION****GENERAL INFORMATION : General Information**

INFOID:0000000014391657


When repairing a damaged frame, pay special attention to the following contents.

**GENERAL INFORMATION : Checking Damage**

INFOID:0000000014391658


The most important point in damaged frame repair is to accurately identify the deformation status of a damaged frame by using an appropriate measurement method.

This manual describes appropriate measurement methods for various types of frame deformation, which must be referenced as a guideline for accurate measurement.

**GENERAL INFORMATION : Repair by Heating**


INFOID:0000000014391659

The repair of a damaged frame by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon type and other similar type thermometers are appropriate.)

**GENERAL INFORMATION : Frame Securing Method**

INFOID:0000000014391660

To straighten a damaged frame, the frame must be anchored securely. This manual describes examples of appropriate frame anchoring for each type of straightening equipment as well as additional anchoring for each type of damage, which must be referenced as a guideline for secure frame anchoring.

**GENERAL INFORMATION : Safety and Health**

INFOID:0000000014391661

Consideration for workers' safety and health should be deemed as the most important item. In reality, it is essential that measures be established to prevent accidents and to make the work environment safer and healthier.

When performing a frame repair work, always observe the instructions described in the section "SAFETY AND HEALTH". Refer to [BRM-50, "PRECAUTIONS FOR OPERATION : Precautions for Operation"](#).

**GENERAL INFORMATION : Elimination of Residual Stress**

INFOID:0000000014391662

When repairing a deformed frame, elimination of any residual stress should be given higher priority.

This manual describes the method for eliminating any residual stress, which must be referenced as a guideline for elimination of residual stress.


## GENERAL INFORMATION : Repairable Frame Damages

INFOID:0000000014391663

In general, the following types and degrees of frame damages are considered repairable though the repairability may differ depending on the capacity of the frame straightening equipment in use.


### (1) LONGITUDINAL DEFORMATION

Deformation located ahead of the lower link mount, the length of which is 100 mm (3.94 in) or less in the longitudinal direction.




### (2) SIDE-SWAY DEFORMATION

Deformation at the end of the frame that sways either leftward or rightward from the vehicle body centerline up to 100 mm (3.94 in) in length.



### (3) DEFORMATION IN HEIGHT LENGTH

Deformation at the upper link mount that sways either upward or downward up to 30 mm (1.18 in).



### (4) FRAME PARTIAL REPLACEMENT

If some portion in a repairable frame deformation is difficult to restore due to work hardening caused by the deformation, such a portion can be repaired by performing butt joint weld at the point specified in the Service Manual and/or the Body Repair Manual. Do not perform a butt joint weld at any points other than those specified in the Service Manual and/or the Body Repair Manual.

### (5) FRAME ASSEMBLY REPLACEMENT

If the damage exceeds the repairable limits specified above, replace the frame assembly.

## FRAME VEHICLE CONSTRUCTION

### FRAME VEHICLE CONSTRUCTION : Frame Vehicle Construction

INFOID:0000000014391664

### (1) FEATURES OF FRAME TYPE VEHICLE


## &lt; SERVICE INFORMATION &gt;

The body is bolted to the frame via rubber bushings. Unlike uni-bodies, the suspensions and power train units are assembled to independent frames. The frames support the weights of these components and absorb any incoming impact from outside, providing a structure that prevents any vibrations and impacts from being transmitted to the body.

The frames are categorized into some types by their shapes (ladder type, backbone type, perimeter type, pipe type). Of these, the ladder type frame often used in SUVs and pickups is described below.

### (2) LADDER TYPE

The basic configuration of a ladder frame is shown in the figure. A ladder frame is composed of two side frames with a box type cross section and multiple crossmembers.




The ladder frames are classified into the following two types according to the cross-sectional shape.

#### (a) Channel type


- Easy to manufacture compared to closed cross section type
- Easier unit installation
- The torsional rigidity is lower than the closed cross section type
- Used for heavy to medium duty trucks

#### (b) Closed box type

- Higher torsional rigidity due to closed cross section
- Higher cost than channel type
- Used for small trucks such as SUVs and pickups



In general, a task to repair a frame damaged by a traffic accident (straightening and entire or partial replacement) is performed according to the following procedure.



JSKIA6631GB

## FRAME DEFORMATION

### FRAME DEFORMATION : Frame Deformation

INFOID:0000000014391666


In a frame type vehicle, an independent body and frame are joined at the body mount points. Therefore, when the vehicle suffers impact from the front or rear in a collision, most of the impact is absorbed by deformation of the frame and deformation in the body is minimized. Another point different from the uni-body is that the frame and the body can be repaired separately.

Basically, frame deformations are classified into the following types.

## FRAME DEFORMATION : Sagging

INFOID:000000014391667


This refers to upward or downward bending of a side frame due to strong impact from the front or rear that occurs when the vehicle receives a rear-end collision or performs sudden braking with an excessive load. In the body alignment dimensions, the height dimensions and diagonal dimensions at each measurement point will be changed.



## FRAME DEFORMATION : Side-sway

INFOID:000000014391668

This refers to deviation of the frame centerline due to left or right sway of side frames at the bases of cross-members, which is caused by a large sidewise impact during a collision. In the body alignment dimensions, sidewise differences in the diagonal dimensions will occur.




## FRAME DEFORMATION : Twisting

INFOID:000000014391669

This refers to deformation of side frame-to-crossmember joints due to rollover caused by a collision accident. The right and left frames/members are twisted in the axially opposite direction to each other. In the body align-

## &lt; SERVICE INFORMATION &gt;


ment dimensions, the height values of the side frame measurement points located ahead of the torsional axis and those behind the torsional axis will largely differ in the laterally opposite direction to each other.



## FRAME DEFORMATION : Diamond

INFOID:000000014391670


This refers to deformation at the bases of crossmembers due to a parallelism difference between the left and right frames, which is caused by a longitudinal impact upon either frame during a collision. Generally, this results in a typical diamond deformation where the frames are kept almost straight. However, if the side frames have curved structures, the frames often suffer sagging and side-sway as well. In the body alignment dimensions, the overall diagonal dimensions will change due to the parallelism difference.



## FRAME DEFORMATION : Buckling

INFOID:000000014391671

This refers to compound sagging where the side frames are crushed and crimped resulting in shortened length. It often occurs at the front end of a frame.



## FRAME DEFORMATION MEASURING METHOD

### FRAME DEFORMATION MEASURING METHOD : Frame Deformation Measuring Method

INFOID:000000014391672


There are several methods available for measuring frame deformations, which must be selected appropriately according to the type of the straightening equipment in use, anchoring method, workshop equipment status and working environment. Typical measuring methods are outlined below.


### FRAME DEFORMATION MEASURING METHOD : Measurement with Manual Gauges

INFOID:000000014391673


#### (1) MEASUREMENT WITH TRACKING GAUGES

Three types of deformations, side-sway, diamond and buckling, can be measured.




**(a) Side-sway**


This is checked by measuring the dimensions of the respective crossmember diagonal lines and comparing them to see if any differences are present.

**(b) Diamond**

Measure the dimensions of the respective crossmember diagonal lines. If any gap is present in the length, a diamond deformation is present.

**(c) Buckling**

This is checked by measuring the height dimensions and length dimensions according to the vehicle body alignment section in the Service Manual or the Body Repair Manual.



**(2) MEASUREMENT WITH CENTERING GAUGES**

# FRAME REPAIR

## < SERVICE INFORMATION >


## [FUNDAMENTALS]

Four types of deformations, sagging, side-sway, twisting, and diamond, can be measured.



### (a) Sagging

This is checked by looking through the horizontal bars of centering gauges.




A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

### (b) Side-sway

This is checked by looking through the center pins of centering gauges attached on the frame.



L  
M  
N  
O

P

### (c) Twisting

Twisting can be checked by judging whether the horizontal bar of a centering gauge attached on the frame is inclined.

### (d) Diamond

Diamond deformation can be checked by identifying any displacement of the side pin of a diamond attachment attached to the center of a centering gauge on the frame or to the horizontal bar located nearby.

FRAME DEFORMATION MEASURING METHOD : Measurement with Three-dimen-

## sional Measuring Equipment

INFOID:000000014391674

Measure the dimensions using three-dimensional measuring equipment and compare the measurements with the vehicle body alignment dimensions to identify any deformation in each direction. Several types of equipment are available, such as universal jig type, universal measuring type, laser type, computer measuring type and ultrasonic type.


## JIG TYPE

When jig type straightening equipment is used, the jig side gauge and pins are used as the dimensional references.

Three axis directions, "X" (width), "Y" (length), and "Z" (height) can be measured simultaneously.


The equipment also allows the worker to utilize any measuring point for the anchoring jig as soon as it is given reference dimensions. Therefore, even a novice can perform body repair with a high level of body alignment precision.

Example 1: Measurement before repair




JSKIA664622

Example 2: Measurement before repair



JSKIA6647GB

Example 3: Measurement after repair



JSKIA664822

## FRAME SECURING

## FRAME SECURING : Frame Securing

INFOID:000000014391675


Frame repair work requires larger straightening force than uni-bodies. Therefore, the frame to be repaired must be anchored stably and securely to withstand such large force. The anchoring methods used for the frame and straightening equipment (puller) must be carefully selected according to the degree of the damage and the facility environment of the body shop. Typical frame anchoring methods are explained below.

## FRAME SECURING : Anchoring by Rigid Racks and Chains

INFOID:000000014391676

Place the frame on rigid racks and pull the high strength/rigidity portions with chains. Thus, secure the frame tightly in the vertical direction. The rigid racks sustain the frame from below and the tensioned chains restrict any upward movement.

The figure shows a typical anchoring method.



This method allows easier anchoring of a frame. Therefore, the method is often used for slight frame deformation, in other words, when the required pulling force is relatively small. It is useful to perform short-time pulling with the cabin mounted on the frame. However, to transmit the pulling force efficiently and thus perform effective repair, another method is recommended. Remove the tires from the frame and sustain the frame with rigid racks from below.

## FRAME SECURING : Anchoring with Frame Attachments

INFOID:000000014391677

A difference between the frame anchoring and the uni-body anchoring is that the frame itself is held down. (For the basic anchoring methods for uni-bodies, refer to [BRM-63, "REPAIR TECHNIQUES USING BODY STRAIGHTENING EQUIPMENT : Securing the Vehicle".](#))


Frame straightening equipment makers offer the attachments for frame anchoring including those intended for any vehicle model and those dedicated for particular vehicle models. Generally speaking, an attachment allows the clamp height/position/angle, etc. to be adjusted so that it can be aligned at any desirable position.

The attachments are largely divided into the following two types.


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


BRM

- Side frame clamp type



- Suspension bracket clamp type





The use of attachments with jig type straightening equipment allows accurate positioning of suspension components, which are considered difficult to repair.

However, you should not completely rely on anchoring with attachments. Supplemental anchoring with chains and belts should also be used as necessary according to the required straightening.

## FRAME STRAIGHTENING WORK


### FRAME STRAIGHTENING WORK : Frame Repair Method according to Deformation Type

INFOID:000000014391678

The basic repair procedures are described below for the respective frame deformation types previously outlined.

#### (1) SAGGING REPAIR METHOD


For sagging, any vertical bending of the frame must be straightened. The entire frame must be measured accurately to see if only a single side of the frame is distorted or both sides are distorted.



#### (2) SIDE-SWAY REPAIR METHOD

For side-sway, any lateral bending of the frame at the bases of crossmembers must be straightened.


When straightening side-sway at the front end of the frame, first anchor the frame so that it does not move rearward during straightening work, by placing hydraulic equipment appropriately as shown in the figure.



#### (3) TWISTING REPAIR METHOD


## &lt; SERVICE INFORMATION &gt;

To straighten twisting, proceed as shown in the figure.  
While pulling, eliminate any residual stress by hammering.




## (4) DIAMOND REPAIR METHOD

For diamond deformation of a frame, any longitudinal bending at the crossmember-to-frame joints must be straightened. Specifically, push one side of the frame and pull the other side. To prevent lateral sway of the frame during straightening, support the frame sides with hydraulic equipment.



## (5) BUCKLING REPAIR METHOD

For buckling, anchor the undamaged portion behind the damage point with as many jigs or anchoring devices as possible and then pull out the front portion of the damaged area in the horizontal direction. It is important to measure and identify the damaged range accurately and set up the frame anchoring points appropriately.




## (6) REPAIRING PROCEDURE FOR COMPOUND DEFORMATION

If multiple types of deformations such as sagging, side-sway, twisting and diamond occur in the frame, first straighten the sagging and side-sway, then straighten the twisting and diamond. It should also be noted that side frames generally must be straightened before crossmembers are straightened.

## FRAME STRAIGHTENING WORK : Precautions for Frame Repair

INFOID:0000000014391679

To eliminate any residual stress from the frame, always perform hammering during straightening work. This is extremely important because residual stress removal is more difficult in frames than in side members of uni-body vehicles. Any wrinkles generated in the frame and residual stress in the frame must be eliminated by tapping on the applicable portions with a hammer during straightening work. Complete elimination of residual stress is particularly important for straightening of twisting.



## FRAME STRAIGHTENING WORK : Cut and Butt Joint Weld

INFOID:0000000014391680

Damages that are considered difficult to repair by frame straightening work, such as a deformed crash horn, may be restored by a butt joint weld only if the Service Manual and/or the Body Repair Manual instructs so.


## &lt; SERVICE INFORMATION &gt;

As an example, the butt joint weld procedure for A60 is outlined below.

## (1) CRASH HORN (Partial replacement)

(Work after 1st crossmember has been removed.)

Service Joint




Portions to be welded:

A: Inner side rail crash horn (a), inner side rail crash horn (b) and outer side rail crash horn (c)


B: Outer side rail crash horn (c), outer side rail crash horn (d) and inner side rail crash horn (b)

## (2) REMOVAL


(a) Scribe a straight line on the outer side rail crash horn and inner side rail crash horn along the hole center as shown in the figure.



(b) Cut off the outer side rail crash horn and inner side rail crash horn along scribed line (A). Do not cut on the hole.



(c) Cut the inner side rail crash horn at 45 mm (1.77 in) backward from cut position of cut line (A) [along line (B)].




After removing the outer panel, dress the area on the inner panel surface with a sander or equivalent.

### (3) INSTALLATION


(a) Scribe a straight line on the inner side rail crash horn along the hole center as shown in the figure.

Cut off the inner side rail crash horn along the scribed line.




(b) Scribe a straight line on the outer side rail crash horn along the hole center as shown in the figure.

Cut off the outer side rail crash horn along the scribed line.



## &lt; SERVICE INFORMATION &gt;

(c) Weld part to be butt joint welded and seam-welded corner to corner as shown in the figure.



**(4) PRECAUTIONS FOR WELDING**

(a) When tack welding is finished, always verify that the crash horn is assembled in the proper dimensions before starting final welding.

(b) Before starting welding work, always remove the components around the weld points. If it is difficult to remove the components, cover them with a fireproof sheet to avoid attachment of any weld spatters and subsequent damage to the surrounding portions.

(c) After painting, spray a sufficient amount of anti-corrosive wax to the rear side of the weld points through the holes near the weld points.

**CONCLUSION**

**CONCLUSION : Conclusion**

INFOID:000000014391681

When repairing a frame deformed by a collision, every body repair technician must always keep in mind that the original frame performance of the vehicle (running performance and anti-collision safety) should be restored so as to offer the maximum customer satisfaction. For that purpose, we hope that every technician reads and understands this manual as well as the Service Manual and the Body Repair Manual so as to repair appropriately and safely. In particular, extreme care must be taken when an oxy-acetylene welder flame is used for repairing a frame deformed by a collision. Careless work on any heated portions without temperature control may result in deterioration of the running performance and anti-collision safety. To prevent such problems, every body repair technician should be aware of the importance of understanding the contents of this manual before frame repair, identifying the frame deformation accurately, and adopting an appropriate repair procedure.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BODY EXTERIOR PAINT COLOR

< VEHICLE INFORMATION >


[REPAIR INFORMATION - XD]

## VEHICLE INFORMATION

### BODY EXTERIOR PAINT COLOR

#### Body Exterior Paint Color

INFOID:0000000014391682



AWKIA382222

Component		Color code	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
		Description	Brown	Orange	Yellow	Black	Silver	Gray	Red	White	White	Blue
		Paint type	M	M	M	M	M	M	M	P	S	P
		Clear coat	x	x	x	x	x	x	x	x	x	x
1.	Roof spoiler	Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
	Door mirror	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
	Front grille outer	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Body color	—	—	EAZ	G41	K23	KAD	NAH	QAB	—	RAY
	Front grille insert	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome (satin)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray
5.	Front bumper upper fascia	Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
	Front bumper lower fascia	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
	Overfender	Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	—	—	—	—	—	KAD	—	—	—	—
	Door outside handle	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
9.	Running board	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr

# BODY EXTERIOR PAINT COLOR

< VEHICLE INFORMATION >

[REPAIR INFORMATION - XD]

Component		Color code	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
		Description	Brown	Orange	Yellow	Black	Silver	Gray	Red	White	White	Blue
		Paint type	M	M	M	M	M	M	P	S	P	
		Clear coat	x	x	x	x	x	x	x	x	x	
10	Rear bumper fascia	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
11	Tailgate outer finisher	Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
12	Tailgate handle	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black

M: Metallic; S: Solid; P: Pearl; x: Standard Clear Coat

A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P

&lt; PRECAUTION &gt;

## PRECAUTION

### PRECAUTIONS

#### Precautions for Body Repair

INFOID:000000014391683

**WARNING:**

- The repair information in this section is intended for trained body repair technicians who have attained a high level of skill and experience (e.g. ASE Collision Repair Certification, I-CAR Professional Development Program [PDP] training, etc.) in repairing collision damaged vehicles using appropriate tools and equipment. Performing repairs without the proper training, tools or equipment could damage the vehicle or cause personal injury or death to you or others.
- The information in this Body Repair Manual is a guideline for repairing collision damaged vehicles. However, this information cannot cover all possible ways that a vehicle can be damaged. As such, the body repair technician is responsible for making sure that the repair does not affect the structural integrity or safety of the vehicle. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.
- Nissan recommends using only new genuine Nissan replacement body parts. Use of used, salvaged or aftermarket body parts is not recommended by Nissan. Non-genuine Nissan components may affect the vehicle's structural integrity and crash safety performance, which could result in serious personal injury or death in an accident.

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000014391684

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

# HANDLING PRECAUTIONS FOR PLASTICS

[REPAIR INFORMATION - XD]

< PRECAUTION >

## HANDLING PRECAUTIONS FOR PLASTICS

### Precautions For Plastics

INFOID:0000000014391685

Abbre- viation	Material name	Heatresisting temperature °C (°F)	Resistance to gasoline and solvents	Other cautions
PE	Polyethylene	60 (140)	Gasoline and most solvents are harmless if applied for a very short time (wipe up quickly).	Flammable
PVC	Poly Vinyl Chloride	80 (176)	Same as above.	Poison gas is emitted when burned.
EPM/ EPDM	Ethylene Propylene (Diene) co- polymer	80 (176)	Same as above.	Flammable
TPO/ TPR	Thermoplastic Olefine/ Thermoplastic rubber	80 (176)	Same as above.	Flammable
PP	Polypropylene	90 (194)	Same as above.	Flammable, avoid bat- tery acid.
UP	Unsaturated Polyester	90 (194)	Same as above.	Flammable
PS	Polystyrene	80 (176)	Avoid solvents.	Flammable
ABS	Acrylonitrile Butadiene Styrene	80 (176)	Avoid gasoline and solvents.	—
PMMA	Poly Methyl Methacrylate	85 (185)	Same as above.	—
EVAC	Ethylene Vinyl Acetate	90 (194)	Same as above.	—
ASA	Acrylonitrile Styrene Acrylate	100 (222)	Same as above.	Flammable
PPE	Poly Phenylene Ether	110 (230)	Same as above.	—
PC	Polycarbonate	120 (248)	Same as above.	—
PAR	Polyarylate	180 (356)	Same as above.	—
PUR	Polyurethane	90 (194)	Same as above.	—
PPC	Polypropylene Composite	115 (239)	Same as above	Flammable
POM	Poly Oxymethylene	120 (248)	Same as above.	Avoid battery acid.
PBT+ PC	Poly Butylene Terephthalate + Polycarbonate	120 (248)	Same as above.	Flammable
PA	Polyamide (Nylon)	140 (284)	Same as above.	Avoid immersing in wa- ter.
PBT	Poly Butylene Terephthalate	140 (284)	Same as above.	—
PET	Polyester	180 (356)	Same as above.	—
PEI	Polyetherimide	200 (392)	Same as above.	—

#### CAUTION:


- When repairing and painting a portion of the body adjacent to plastic parts, consider their characteristics (influence of heat and solvent) and remove them if necessary or take suitable measures to protect them.
- Plastic parts should be repaired and painted using methods suiting the materials' characteristics.

# HANDLING PRECAUTIONS FOR PLASTICS

[REPAIR INFORMATION - XD]

< PRECAUTION >

LOCATION OF PLASTIC PARTS



ALKIA41912Z

Item	Component		Abbreviation	Material
1.	Satellite antenna base (if equipped)		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
2.	Front fender duct		ABS	Acrylonitrile Butadiene Styrene
3.	Front grille outer		ABS	Acrylonitrile Butadiene Styrene
4.	Front grille insert (low gloss black)		ASA	Acrylonitrile Styrene Acrylate
	Front grille insert		ABS	Acrylonitrile Butadiene Styrene
5.	Front bumper upper fascia		PP	Polypropylene
6.	Front fog lamp (if equipped)		PBT + ASA	Poly Butylene Terephthalate + Acrylonitrile Styrene Acrylate
7.	Front air spoiler (if equipped)		PP + EPDM	Polypropylene + Ethylene Propylene (Diene) copolymer
8.	Front combination lamp	Housing	PP	Polypropylene
		Lens		
9.	Overfender (front/ rear) (if equipped)		PC + PBT	Polycarbonate + Poly Butylene Terephthalate
10.	Door outside handle (black)	Handle	PA	Polyamide (Nylon)
		Escutcheon		
	Door outside handle (chrome)	Handle	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
		Escutcheon		
11.	Running board step pad (if equipped)		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
12.	Rear mudguard		PP	Polypropylene
13.	Rear combination lamp	Housing	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
		Lens	PMMA	Poly Methyl Methacrylate
14.	Rear bumper step		TPO	Thermoplastic Olefine
15.	Tailgate outside handle	Handle	PC + PET	Polycarbonate + Polyester
		Escutcheon		
16.	Tailgate finisher	Outer	ABS	Acrylonitrile Butadiene Styrene
		Inner	TPO	Thermoplastic Olefine

# HANDLING PRECAUTIONS FOR PLASTICS


[REPAIR INFORMATION - XD]

< PRECAUTION >

Item	Component	Abbreviation	Material
17.	Tailgate trim	TPO	Thermoplastic Olefine
18.	Bedside finisher	TPO	Thermoplastic Olefine
19.	High mount stop lamp	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
20.	Roof spoiler	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
21.	Door mirror	Base	Acrylonitrile Styrene Acrylate
		Housing	
		Cover (black)	
		Cover (chrome)	ABS
			Acrylonitrile Butadiene Styrene

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM



ALKIA419522

L  
M  
N  
O  
P

Item	Component	Abbreviation	Material	
1.	Center pillar finisher	Upper	PP	Polypropylene
		Lower		
2.	Rear pillar finisher	Upper	PET	Polyester
		Lower	PP	Polypropylene
3.	Back panel finisher	PP	Polypropylene	
4.	Kicking plate	Front	PP	Polypropylene
		Rear		
5.	Center console	PP	Polypropylene	
6.	Dash side finisher	PP	Polypropylene	
7.	Instrument panel	Skin	TPO	Thermoplastic Olefine
		Pad	PUR	Polyurethane
		Core	PPC	Polypropylene Composite
8.	Front pillar finisher	PET	Polyester	
9.	Steering column covers	Upper	PP	Polypropylene
		Lower		

## REPAIRING HIGH STRENGTH STEEL

## High Strength Steel (HSS)

INFOID:0000000014391686

High strength steel is used for body panels in order to reduce vehicle weight.


Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

Tensile strength	Major applicable parts
590 MPa	<ul style="list-style-type: none"> <li>Front side member</li> <li>Roof front rail</li> <li>Roof side rail inner</li> <li>Front pillar inner upper</li> <li>Center pillar inner</li> <li>Center pillar hinge brace</li> <li>Front side member extension</li> <li>Sill outer reinforcement</li> <li>Rear pillar outer reinforcement</li> </ul>
980 MPa	<ul style="list-style-type: none"> <li>Sill inner reinforcement</li> <li>Front pillar outer reinforcement</li> <li>Center pillar inner reinforcement</li> <li>Roof side rail outer</li> <li>Sill outer brace</li> </ul>


Read the following precautions when repairing HSS:

1. Additional points to consider:

- The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon-type and other similar type thermometers are appropriate.)



- When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points and carefully pull the HSS panel.




# REPAIRING HIGH STRENGTH STEEL


## [REPAIR INFORMATION - XD]

### < PRECAUTION >


- When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97 in).



- When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use MIG welding. Do not use gas (torch) for welding because it is inferior in welding strength.




- The spot weld on HSS panels is harder than that of an ordinary steel panel. Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 to 1,200 rpm) to increase drill bit durability and facilitate the operation.



### 2. Precautions in spot welding HSS

This work should be performed under standard working conditions. Always note the following when spot welding HSS:

- The electrode tip diameter must be sized properly according to the metal thickness.




# REPAIRING HIGH STRENGTH STEEL

## < PRECAUTION >

## [REPAIR INFORMATION - XD]

- The panel surfaces must fit flush to each other, leaving no gaps.




PIIA0147E

- Follow the specifications for the proper welding pitch.

Thickness (T)	Minimum pitch (L)
0.6 (0.024)	10 (0.39) or over
0.8 (0.031)	12 (0.47) or over
1.0 (0.039)	18 (0.71) or over
1.2 (0.047)	20 (0.79) or over
1.6 (0.063)	27 (1.06) or over
1.8 (0.071)	31 (1.22) or over

Unit: mm (in)



JSKIA0781ZZ

## Handling of Ultra High Strength Steel Plate Parts

INFOID:000000014391687

### PROHIBITION OF CUT AND CONNECTION

Do not cut and join the lower lock pillar reinforcement (center pillar reinforcement inside frame parts) because its material is high strength steel plate (ultra high strength steel plate).

The center pillar reinforcement must be replaced if this part is damaged.

## Welding of Ultra High Strength Steel

INFOID:000000014391688

### SPOT WELDING

Spot welding is limited to ultra high strength steel of (tensile strength: 980 MPa) according to the welding conditions listed below.

#### CAUTION:

- If the below welding conditions cannot be met, then perform plug welding.
- Never spot weld ultra high strength steel of tensile strength more than 980 MPa. For this type of ultra high strength steel, perform plug welding.
- The below welding condition is applicable only to this vehicle. Never apply these same conditions to other vehicles.

#### Welding condition

<b>Welder tip diameter</b>	<b>6 MM</b>
<b>Welding pressure (Gun force)</b>	<b>3425 N</b>
<b>Welding current</b>	<b>8035 A</b>
<b>Weld time*</b>	<b>.24 sec (12 cyc: 50 Hz) .23 sec (14 cyc: 60 Hz)</b>

# REPAIRING HIGH STRENGTH STEEL

< PRECAUTION >

[REPAIR INFORMATION - XD]

## Panel configuration

Combination of a plate of tensile strength of 980 MPa and that of tensile strength less than 980 MPa. (Up to 3 plates)

\* Select weld time based on the frequency (Hz) of the electrical power supplied in your area.

## PLUG WELDING

To weld ultra high strength steel of tensile strength 980 MPa or more, perform plug welding observing the welding hole diameter described in the manual.

### CAUTION:

- To perform plug welding, use fuel mixture (Ar 80% + CO<sub>2</sub> 20%) for shielding gas of welder.
- Never use carbon dioxide gas (CO<sub>2</sub> 100%) as shielding gas of welder. Using CO<sub>2</sub> 100% gas results in inadequate weld strength.
- When welding hole diameter cannot be met, make multiple holes (smaller diameter) so that the sum of the holes areas equals the area of the original weld hole.

A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P

# PREPARATION

## REPAIRING MATERIAL

### Foam Repair

INFOID:000000014391689

During factory body assembly, foam insulators are installed in certain body panels and locations around the vehicle. Use the following procedure(s) to replace any factory-installed foam insulators.

#### URETHANE FOAM APPLICATIONS

Use commercially available urethane foam for sealant (foam material) repair of material used on vehicle.


##### <Urethane foam for foaming agent>

##### 3M™ Automix™ Flexible Foam 08463 or equivalent

Read instructions on product for fill procedures.

Example of foaming agent filling operation procedure:

1. Fill procedures after installation of service part.
  - a. Eliminate foam material remaining on vehicle side.
  - b. Clean area after eliminating form insulator and foam material.
  - c. Install service part.
  - d. Insert nozzle into hole near fill area and fill foam material or fill enough to close gap with the service part.



JSKIA0129GB

1. Urethane foam

A. Nozzle insert hole

Front

2. Fill procedures before installation of service part:
  - a. Eliminate foam material remaining on vehicle side.
  - b. Clean area after eliminating foam insulator and foam material.
  - c. Fill with enough foam material on the wheelhouse outer side to close the gap with the service part while avoiding the flange area.


1. Urethane foam
- A. Fill while avoiding flange area

Front

- d. Install service part.

**NOTE:**

Refer to the label on the urethane foam container for information on working times.




JSKIA0130GB

## BODY COMPONENT PARTS

### Underbody Component, Engine Compartment Parts

INFOID:0000000014391690



AWKIA40142Z

■■■ : Both sided anti-corrosive precoated steel portions

■■ : Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

< PREPARATION >

[REPAIR INFORMATION - XD]

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Rear floor	Under 440	x	—
2.	Rear seat mounting brackets (LH/RH)	Under 440	x	—
3.	Front floor	Under 440	x	—
4.	Upper dash	Under 440	x	—
5.	Cowl top	Under 440	x	—
6.	Lower dash	Under 440	x	—
7.	Front floor reinforcement	440	x	—
14.	Hoodledge assembly (Cummins 5.0L)	8. Radiator core support upper (LH/RH)	Under 440	x
		9. Radiator core support side (LH/RH)	440	x
		10. Air cleaner bracket lower (LH)	Under 440	x
		11. Hoodledge (LH/RH)	Under 440	x
		12. Air cleaner bracket (LH)	Under 440	x
		13. Hoodledge reinforcement (LH/RH)	Under 440	x
19.	Hoodledge assembly (VK56VD)	8. Radiator core support upper (LH/RH)	Under 440	x
		9. Radiator core support side (LH/RH)	440	x
		11. Hoodledge (LH/RH)	Under 440	x
		12. Air cleaner bracket (LH)	Under 440	x
		13. Hoodledge reinforcement (LH/RH)	Under 440	x
		15. Battery mounting bracket lower 1 (RH)	Under 440	x
		16. Battery mounting bracket lower 2 (RH)	Under 440	x
		17. Air cleaner bracket lower (LH)	Under 440	x
		18. Hoodledge reinforcement lower (LH)	Under 440	x
20.	Dash side (LH/RH)	Under 440	x	—
21.	Cab mounting crossmember 2nd	Under 440	x	—
22.	Front seat mounting crossmember 1st	Under 440	x	—
23.	Front side member (LH/RH)	590	x	—
24.	Sill inner (LH/RH)	980	x	—
25.	Sill inner extension (LH/RH)	Under 440	x	—
26.	Rear side member bracket (LH/RH)	Under 440	x	—
27.	Parking brake bracket rear	Under 440	x	—
28.	Front seat mounting crossmember 2nd	Under 440	x	—
29.	Rear seat mounting crossmember 1st	Under 440	x	—
30.	Rear seat mounting crossmember 2nd	440	x	—
31.	Rear floor reinforcement	Under 440	x	—

**CAUTION:**

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

**NOTE:**

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.


# BODY COMPONENT PARTS

< PREPARATION >

[REPAIR INFORMATION - XD]

## Body Component Parts

INFOID:000000014391691



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O  
P

AWKIA3844ZZ

■ :Both sided anti-corrosive precoated steel portions

■ :Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

< PREPARATION >

[REPAIR INFORMATION - XD]

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Rear body floor assembly	Under 440	X	—
2.	Rear body floor tail bolster	Under 440	X	—
3.	Roof	Under 440	X	—
4.	Roof rear rail	440	X	—
5.	Roof bow 2nd	Under 440	X	—
6.	Roof bow 1st bracket (LH/RH)	Under 440	X	—
7.	Roof bow 1st	440	X	—
8.	Roof front rail	590	X	—
9.	Roof side rail inner (LH/RH)	590	X	—
10.	Front pillar inner upper (LH/RH)	590	X	—
11.	Front pillar outer reinforcement (LH/RH)	980	X	—
12.	Front pillar hinge brace (LH/RH)	440	X	—
13.	Center pillar inner (LH/RH)	980	X	—
14.	Roof side rail outer (LH/RH)	980	X	—
15.	Center pillar hinge brace (LH/RH)	590	X	—
16.	Sill outer (LH/RH)	980	X	—
17.	Hoodledge rear reinforcement (LH/RH)	Under 440	X	—
18.	Hood	Under 440	X	—
19.	Front fender (LH/RH)	Under 440	X	—
20.	Front door assembly (LH/RH)	1470	X	—
21.	Front door outer (LH/RH)	Under 440	X	—
22.	Rear door assembly (LH/RH)	1470	X	—
23.	Rear door outer (LH/RH)	Under 440	X	—
24.	Body side outer (LH/RH)	Under 440	X	—
25.	Rear pillar outer reinforcement (LH/RH)	590	X	—
26.	Rear pillar inner (LH/RH)	440	X	—
27.	Back panel	Under 440	X	—
28.	Rear body header panel assembly	Under 440	X	—
29.	Rear body front strut outer (LH/RH)	Under 440	X	—
30.	Rear body outer panel (LH/RH)	Under 440	X	—
31.	Rear body floor bolster 1st	Under 440	X	—
32.	Rear body floor bolster 2nd	Under 440	X	—
33.	Rear body inner panel (LH/RH)	Under 440	X	—
34.	Rear body floor bolster 4th	Under 440	X	—
35.	Tail gate assembly	Under 440	X	—

**CAUTION:**

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

**NOTE:**

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.

# BODY COMPONENT PARTS

< PREPARATION >


[REPAIR INFORMATION - XD]

## Frame Component Parts

INFOID:000000014391692

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

BRM



AWKIA4198ZZ

■ :Both sided anti-corrosive precoated steel portions

■ :Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

< PREPARATION >

[REPAIR INFORMATION - XD]

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Frame assembly	590	X	—
2.	Exhaust bracket	Under 440	X	—
3.	Front crossmember	440	X	—
4.	Front side member extension (LH/RH)	590	X	—
5.	Cab mounting bracket 1st (LH/RH)	Under 440	X	—
6.	Front lower link rear mounting (LH/RH)	440	X	—
7.	Front stabilizer mounting bracket (LH/RH)	440	X	—
8.	Front brake hose bracket (LH/RH)	Under 440	X	—
9.	Engine mounting bracket (LH/RH)	440	X	—
10.	Cab mounting bracket 2nd (LH/RH)	440	X	—
11.	Front shock absorber mounting bracket (LH/RH)	440	X	—
12.	Rear engine mounting gusset	440	X	—
13.	Cab mounting bracket 3rd (LH/RH)	440	X	—
14.	Cab mounting bracket 4th (LH/RH)	440	X	—
15.	Leaf spring front bracket (LH/RH)	Under 440	X	—
16.	Rear body mounting bracket 1st (LH/RH)	Under 440	X	—
17.	Rear bumper bound bracket (LH/RH)	Under 440	X	—
18.	Leaf spring rear bracket 1st (LH/RH)	Under 440	X	—
19.	Leaf spring rear bracket 2nd upper (LH/RH)	Under 440	X	—
20.	Leaf spring rear bracket 2nd lower (LH/RH)	Under 440	X	—
21.	Rear body mounting bracket 2nd (LH/RH)	Under 440	X	—
22.	Hitch member mounting bracket (LH/RH)	440	X	—
23.	Gooseneck hitch	540	X	—

**CAUTION:**

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

**NOTE:**

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.

# REMOVAL AND INSTALLATION

## CORROSION PROTECTION

### Description


INFOID:000000014391693

To provide improved corrosion prevention, the following anti-corrosive measures have been implemented in NISSAN production plants. When repairing or replacing body panels, it is necessary to use the same anti-corrosive measures.

#### Anti-Corrosive Precoated Steel (Galvannealed Steel)

To improve repairability and corrosion resistance, a new type of anti-corrosive precoated steel sheet has been adopted, replacing conventional zinc-coated steel sheet.

Galvannealed steel is electroplated and heated to form zinc-iron alloy, which provides excellent and long term corrosion resistance with cationic electrodeposition primer.




NISSAN Genuine Service Parts are fabricated from galvannealed steel. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain the anti-corrosive performance built into the vehicle at the factory.

#### Phosphate Coating Treatment and Cationic Electrodeposition Primer

A phosphate coating treatment and a cationic electrodeposition primer, which provide excellent corrosion protection, are employed on all body components.

#### CAUTION:

Confine paint removal during welding operations to an absolute minimum.




NISSAN Genuine Service Parts are also treated in the same manner. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain anti-corrosive performance built into the vehicle at the factory.

#### Anti-Corrosive Wax

INFOID:000000014391694

To improve corrosion resistance, anti-corrosive wax is applied inside the body sill and inside other closed sections. Accordingly, when replacing these parts, be sure to apply anti-corrosive wax to the appropriate areas of the new parts. Select an excellent anti-corrosive wax which will penetrate after application and has a long shelf life.



AWKIA3823ZZ

1. Anti-corrosive wax	2. Body caulk	3. Panel adhesive
B. 100 mm (3.94 in)	C. 10 mm (0.39 in)	D. 2 mm (0.08 in)


## Undercoating

INFOID:0000000014391695

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

### Precautions in Undercoating

1. Never apply undercoating unless specified. Avoid areas such as the areas above the muffler and three-way catalyst which are subjected to heat.
2. Never undercoat the exhaust pipe or other parts which become hot.
3. Never undercoat rotating parts.
4. Apply bitumen wax after applying undercoating.
5. After putting seal on the vehicle, put undercoating on it.





AWKIA4158ZZ

Undercoated areas are shaded.

## Stone Guard Coat

INFOID:000000014391696

To prevent damage caused by stones, the lower outer body panel (fender, door, etc.) have an additional layer of Stone Guard Coating over the ED primer coating. When replacing or repainting these panels, apply Stone Guard coating to the same portions as before. Use a coating which is rust preventive, durable, shock-resistant and has a long shelf life.



AWKIA40472Z

Stone guard areas are shaded.



1. Stone guard

A. 195 mm (7.68 in.)

**BODY SEALING****Description**

INFOID:0000000014391697

The following figure shows the areas which are sealed at the factory. Sealant which has been applied to these areas should be smooth and free from cuts or gaps. Care should be taken not to apply an excess amount of sealant and not to allow other unaffected parts to come into contact with the sealant.




ALKIA4247ZZ

◀ Front

# BODY SEALING

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA3846ZZ


◀ Front

# BODY SEALING


< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]


J




K




L




M



N



P




AWKIA3847ZZ

◀ Front

# BODY SEALING

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O



ALKIA4258ZZ

◀ Front

## BODY CONSTRUCTION

## Body Construction

INFOID:0000000014391698



- 1. Front pillar inner
- 2. Front pillar reinforcement
- 3. Front pillar bracket
- 4. Body side outer
- 5. Front pillar hinge brace
- 6. Front pillar brace
- 7. Sill outer
- 8. Sill outer brace
- 9. Sill inner

- 10. Sill inner reinforcement
- 11. Center pillar hinge brace
- 13. Sill outer extension
- 14. Sill inner extension
- 16. Rear pillar reinforcement
- 17. Center pillar brace

- 12. Center pillar inner
- 15. Rear pillar inner
- Front


## Rear Body

INFOID:000000014391699


### REMOVAL AND INSTALLATION

#### Removal

1. Remove rear bumper. Refer to [EXT-29, "Removal and Installation"](#).
2. Remove rear fender protectors. Refer to [EXT-42, "Exploded View - Rear Fender Protector"](#).
3. Remove rear cargo power socket (if equipped). Refer to [PWO-50, "Removal and Installation - Rear"](#).
4. Using a suitable tool disconnect the bed rail lamp harness connectors.
5. Using a suitable tool release all harness clips from rear body and disconnect the rear combination lamp harness connectors (LH/RH) (A).




6. Remove DEF filler tube nuts (A) and place DEF filler tube aside (Diesel only).




7. Remove fuel filler tube (A) and place fuel tank filler pipe aside.

- a. Diesel:




b. Gas:



ALKIA4531ZZ

8. Using a suitable tool release pawls and remove fuel tank vent (A) from rear body (Diesel only).

 Pawl



ALKIA4264ZZ

9. Remove rear body mounting bolts and rear body. Refer to [BRM-174, "Body Mounting"](#).

Installation

Installation is in the reverse order of removal.

## REPLACEMENT OPERATIONS

## Precautions for Body Repair

INFOID:0000000014391700

**WARNING:**





- The repair information in this section is intended for trained body repair technicians who have attained a high level of skill and experience (e.g. ASE Collision Repair Certification, I-CAR Professional Development Program [PDP] training, etc.) in repairing collision damaged vehicles using appropriate tools and equipment. Performing repairs without the proper training, tools or equipment could damage the vehicle or cause personal injury or death to you or others.
- The information in this Body Repair Manual is a guideline for repairing collision damaged vehicles. However, this information cannot cover all possible ways that a vehicle can be damaged. As such, the body repair technician is responsible for making sure that the repair does not affect the structural integrity or safety of the vehicle. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.
- Nissan recommends using only new genuine Nissan replacement body parts. Use of used, salvaged or aftermarket body parts is not recommended by Nissan. Non-genuine Nissan components may affect the vehicle's structural integrity and crash safety performance, which could result in serious personal injury or death in an accident.

## Description

INFOID:0000000014391701

- Technicians are encouraged to read the Body Repair Manual (Fundamentals) in order to ensure that the original functions and quality of the vehicle are maintained. The Body Repair Manual (Fundamentals) contains additional information, including cautions and warnings, that are not included in this manual. Technicians should refer to both manuals to ensure proper repair.
- Please note that this information is prepared for worldwide usage, and as such, certain procedures might not apply in some regions or countries.

The symbols used in this section for welding operations are shown below.

Symbol marks	Description	
"Number"	<p>"Number" after symbol mark is the total number of welds to apply.            Example 1: ■"4" A = 4 MIG plug welds for 3-panel plug weld method.            Example 2: mm"1" x20 (0.79) = 1 MIG seam weld by length 20 mm (0.79 in).</p>	
	2-panel spot weld	 JSKIA004922
	3-panel spot weld	 JSKIA005022





A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRM


# REPLACEMENT OPERATIONS

## < REMOVAL AND INSTALLATION >


## [REPAIR INFORMATION - XD]

Symbol marks	Description
 JSKIA0051ZZ	<b>MIG plug weld</b>  JSKIA0054ZZ <p>For 3-panel plug weld method</p>  JSKIA0055ZZ
 JSKIA0052ZZ	<b>MIG seam weld / Point weld</b>  JSKIA0056ZZ

- Front pillar butt joint can be determined anywhere within shaded area as shown in the figure. The best location for the butt joint is at position A due to the construction of the vehicle.



- Determine cutting position and record distance from the locating indent. Use this distance when cutting the service part. Cut outer front pillar over 60 mm (2.36 in) above the inner front pillar cut position.




## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >


### [REPAIR INFORMATION - XD]

- Prepare a cutting jig to make outer pillar easier to cut. Also, this will permit the service part to be accurately cut at the joint position.



- An example of cutting operation using a cutting jig is as per the following.

1. Mark cutting lines.
  - A: Cut position of outer pillar
  - B: Cut position of inner pillar
2. Align cutting line with notch on jig. Clamp jig to pillar.
3. Cut outer pillar along groove of jig (at position A).
4. Remove jig and cut remaining portions.
5. Cut inner pillar at position B in same manner.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O  
P


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

## Radiator Side Support

INFOID:0000000014391702



ALKIA4169ZZ

### Replacement parts

- Radiator side support

◀ Front

## Hoodledge


INFOID:0000000014391703

## REAR REINFORCEMENT

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA38432Z

Replacement parts

- Hoodledge rear reinforcement      A. MIG weld


Front

REINFORCEMENT

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



ALKIA4199ZZ

## Replacement parts

- Hoodledge reinforcement


◀ Front

## HOODLEDGE

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



BRM

## Replacement parts

- Hoodledge assembly

Front

ALKIA42002Z

## Front Pillar

INFOID:000000014391704

O

## OUTER


- Work after hoodledge rear reinforcement has been removed.

P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA3853ZZ

## Replacement parts

- Front pillar section of front body side outer      A. Sectioning location
- Adhesive    B. MIG weld
- ← Front


## HINGE BRACE

- Work after front pillar outer has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



BRM

## Replacement parts

- Front pillar hinge brace

A. MIG weld

Front

AWKIA385522


## OUTER REINFORCEMENT

- Work after front pillar hinge brace has been removed.
- Work after roof panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA4159ZZ

## Replacement parts

- Front pillar outer reinforcement    ← Front

## Dash Side


INFOID:0000000014391705

- Work after front pillar outer reinforcement has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA41602Z

Replacement parts

- Dash side

A. MIG weld

Front

Center Pillar

INFOID:0000000014391706


OUTER

O  
P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA3857ZZ

mm (in)

## Replacement parts

- Center pillar portion of front body side outer
- A. Sectioning location
- C. 90.0 (3.54)
- D. 100.0 (3.94)
- B. 70.0 (2.76)
- ◀ Front

\* For spot welding of steel plate of strength 980 MPa, observe the indicated welding conditions. Refer to [BRM-123, "Welding of Ultra High Strength Steel"](#).


## REINFORCEMENT

- Work after center pillar outer has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA38582Z

## Replacement parts

- Center pillar reinforcement

A. Mig weld

Front


INNER

O  
P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



ALKIA4256ZZ

## Replacement parts

- Center pillar inner

A. MIG weld

◀ Front

## Rear Pillar

INFOID:000000014391707


### OUTER

- Work after back panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA38992Z

## Replacement parts

- Rear pillar portion rear body side outer A. Sectioning location

Front


## OUTER REINFORCEMENT

- Work after the rear outer body side panel and roof have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA3861ZZ

## Replacement parts

- Rear pillar outer reinforcement    ↙ Front

\* For spot welding of steel plate of strength 980 MPa, observe the indicated welding conditions. Refer to [BRM-123, "Welding of Ultra High Strength Steel"](#).


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

Back Panel

INFOID:000000014391708



Replacement parts

- Back panel

A. MIG weld

Front

AWKIA3863ZZ


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

Roof

INFOID:0000000014391709



AWKIA4162ZZ

## Replacement parts

- Roof panel


Perform plug welding instead of laser welding    Front

## FRONT ROOF RAIL

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA38592Z

Replacement parts

- Front roof rail


Front

ROOF BOWS

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



AWKIA3821ZZ

Replacement parts

- Roof bows


◀ Front

REAR ROOF RAIL

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA38492Z

## Replacement parts

- Rear roof rail

Front

## Sill Outer

INFOID:000000014391710


O  
P

- Work after the front pillar hinge brace and the center pillar reinforcement and rear pillar reinforcement have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



ALKIA4276ZZ

## Replacement parts

- Sill outer

◀ Front

# REPLACEMENT OPERATIONS



## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - XD]

### Sill Inner

INFOID:000000014391711

- Work after sill outer has been removed.



BRM

#### Replacement parts

- Sill inner

◀ Front

ALKIA4280ZZ


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

## Rear Body Outer Panel

INFOID:0000000014391712



AWKIA4217ZZ

Replacement parts

- Rear body outer panel

A. Rivet

◀ Front

## Rear Body Rear Wheel House Outer


INFOID:0000000014391713

- Work after rear body outer panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



## Replacement parts

- Rear body rear wheel house outer

◀ Front

## Rear Body Inner Panel

INFOID:000000014391714


- Work after rear body outer panel has been removed.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



ALKIA4289ZZ

## Replacement parts

- Rear body inner panel

◀ Front


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

## Rear Body Header Panel

INFOID:000000014391715



A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

ALKIA4288ZZ

### Replacement parts

- Rear body header panel

◀ Front

P

## Rear Body Floor Tail Bolster


INFOID:000000014391716

- Work after rear body outer panel and rear body inner panel have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]



ALKIA4291ZZ

Replacement parts

- Rear body floor tail bolster

◀ Front

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - XD]

## Rear Body Floor

INFOID:0000000014391717

A

B

C

D

E

F

G

H

I

J

BRM



L

M

N

O

P



ALKIA4290ZZ

### Replacement parts

- Rear body floor


◀ Front

## Front Side Member Extension

INFOID:0000000014391718

### NOTE:

Frame with gooseneck hitch shown.



ALKIA4293ZZ

## Replacement parts

A. Sectioning location

1. Front side member extension  Front

## Removal

**NOTE:**


LH side shown, RH side similar.

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >


### [REPAIR INFORMATION - XD]

- Using a suitable tool cut MIG weld (A) and remove front crossmember (1).



◀ Front

- Using a suitable tool cut MIG welds (A) and remove front stabilizer bar mounting bracket (1).



◀ Front


- Using a suitable tool (A) cut off front side member extension (1) forward of MIG weld (B).

# REPLACEMENT OPERATIONS

## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - XD]

- Grind remaining MIG weld (B) flush to frame (2) removing inner portion of front side member.



ALKIA4296ZZ

◀ Front

### Installation

- Installation is in the reverse order of removal.
- Assemble front side member extension as shown.

### WARNING:


To maintain vehicle structural integrity, always apply proper welds to all frame repair locations. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.

### CAUTION:

- Install front side member extension into frame allowing a 14.0 mm (0.55 in) overlap.
- Inspect parts for damage before welding.

### NOTE:

Replace radiator core support mounting bracket and front stabilizer bar mounting bracket when replacing front side member extension.



ANKIA3851ZZ

Unit: mm (in)


1. Front side member extension inner	2. Front side member extension outer	3. Frame outer
4. Frame inner	A. 14.0 (0.55)	B. 7.5 (0.30)
C. 10.0 (0.39)	D. 2.5 (0.10)	◀ Front

## SERVICE DATA AND SPECIFICATIONS (SDS)


## BODY ALIGNMENT

## Body Mounting


INFOID:000000014391719




A - A




B - B



C - C



D - D



A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P


# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]

1. Cab mounting insulator (1st)	2. Cab mounting spacer	3. Cab mounting insulator (2nd)
4. Cab mounting washer	5. Cab mounting insulator (3rd)	6. Cab mounting insulator (4th)

◀ Front



ALKIA4721ZZ

7. Rear body shim      8. Rear body mounting spacer      9. Rear body mounting washer

# BODY ALIGNMENT

## < SERVICE DATA AND SPECIFICATIONS (SDS)

## [REPAIR INFORMATION - XD]

10. Rear body crossmember shim G-G. Without gooseneck hitch      H-H. With gooseneck hitch

◀ Front


### CAUTION:

- Before installation, be sure to replace bolts and nuts (sealant applied bolts or self-lock nuts are used for all mounting).
- Unless otherwise noted, the bushings and insulators have paint marks that are to be installed facing outward.

## Body Center Marks

INFOID:000000014391720

A mark is placed on each part of the body to indicate the vehicle center. When repairing the vehicle frame (members, pillars, etc.) damaged in an accident, the most accurate and effective repair will be achieved by using these marks together with body alignment specifications.



A

B

C

D

E

F

G

H

I

J

BRM


L

M

N

O

P



ALKIA4181ZZ

◀ Front

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)


[REPAIR INFORMATION - XD]

Points	Portion	Marks
A	Front roof	Positioning mark
B	Rear roof	Notch

## Description

INFOID:0000000014391721

- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (\*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".
- "Z": Imaginary base line [200 mm (7.87 in) below datum line ("0Z" at design plan)]



JSKIA0073GB

1. Vehicle center

2. Front axle center

3. Imaginary base line

## Engine Compartment

INFOID:0000000014391722


### MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the RH and LH sides of the vehicle.

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



AWKIA415722

Unit: mm (in)

## MEASUREMENT POINTS

BRM

L

M

N


O

P

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



ALKIA4537ZZ

Front

Unit: mm (in)

Point	Description
A, a	Hole in center dash upper 8.0 (0.31)
B, b	Hood hinge rear bolt hole 11.0 (0.43)
C, c	Fender hole 7.0 (0.28)
D, d	Headlamp hole 7.0 (0.28)
E, e	Radiator core support hole 9.0 (0.35)
F, f	Radiator core support hole 11.0 (0.43)
G, g	Reinforcement outer bolt hole 14.0 (0.55)
H, h	Reinforcement inner bolt hole 14.0 (0.55)

## Passenger Compartment

INFOID:0000000014391723


## MEASUREMENT

# BODY ALIGNMENT

## < SERVICE DATA AND SPECIFICATIONS (SDS)

## [REPAIR INFORMATION - XD]

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.



ALKIA41682Z

Unit: mm (in)



Coordinates	Measurement	Coordinates	Measurement
A-B	878.5 (34.59)	H-M*	1036.9 (40.82)
A-D*	1112.7 (43.81)	K-N*	869.8 (34.24)
A-E	880.1 (34.65)	H-K*	803.6 (31.64)
C-c	1314.6 (51.76)	J-Q*	1186.7 (46.72)
C-D	809.2 (31.86)	J-M*	432.1 (17.01)
C-d*	1631.6 (64.24)	J-P*	1236.6 (48.68)
C-B	1124.3 (44.26)	M-P*	1186.5 (46.71)
C-E	1050.1 (41.34)	M-Q*	1277.7 (50.30)
E-B	124.9 (4.92)	R-S*	796.0 (31.34)
F-G*	257.1 (10.12)	R-T*	950.9 (37.44)
F-H*	777.9 (30.63)	R-U*	951.4 (37.46)
F-K*	1325.0 (52.17)	R-V*	573.0 (22.56)
F-N*	580.1 (22.84)	S-T*	758.0 (29.84)
G-H*	586.8 (23.10)	S-U*	1014.2 (39.93)
G-K*	1252.9 (49.33)	S-V*	1111.4 (43.76)
G-N*	719.1 (28.31)		

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



ALKIA4173ZZ

Front


Point	Description	Point	Description
A	Roof front positioning mark	F,f G,g H,h K,k N,n	Front body side outer notch
B,E	Cowl top hole	J,j M,m P,p Q,q	Body side hinge hole
C,c	Outer body side joggle corner	R,r S,s T,t U,u V,v	Body side rear outer notch
D,d	Body side outer front hole		

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L

ALKIA41782Z


◀ Front

Unit mm (in)

Coordinates	Measurement
W,y*	826.2 (32.53)
W,X*	643.7 (25.34)
x,Y*	1415.8 (55.74)
X,Y	374.1 (14.61)
Y,y	1450.0 (57.09)

M  
N  
O  
P

MEASUREMENT POINTS



ALKIA4179ZZ

Front

Point	Description
W	Roof notch rear
X,x	Body side rear joggle
Y,y	Rear panel notch


## Roof

INFOID:0000000014391724

### MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.

### MEASUREMENT POINTS



← Front

Unit: mm (in)

Point	Description	Point	Description
A,a	Roof rail front center front locator hole 30.0 (1.18)	B,b	Rear body side rear hole locator hole 13.0 (0.51)

BRM

## Rear Body

INFOID:000000014391725


### MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.




# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



## MEASUREMENT POINTS



AWKIA416422

← Front

Unit: mm (in)

Point	Description
A,a	Front square stake pocket 55.0 (2.17) X 43.0 (1.69) front outer point
B,b	Rear square stake pocket 55.0 (2.17) X 43.0 (1.69) rear outer point
C,c	Rear body front upper outer bolt hole 9.0 (0.35)
D,d	Rear body front lower outer bolt hole 9.0 (0.35)

BRM

## Underbody

INFOID:000000014391726

### MEASUREMENT

The following figure shows a bottom view and a side view of the vehicle.


#### NOTE:

4WD shown, 2WD similar.

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



AWKIA4233ZZ

Unit: mm (in).

◀ Front





Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH sides of the vehicle.

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - XD]



Front

Unit: mm (in)

Points	Coordinates			Remarks
	X	Y	Z	
A, a	-428.2 (-16.86)	-887.7 (-34.95)	-181.4 (-7.14)	Front bolt hole 12.0 (0.67)
B, b	-359.0 (-14.13)	-441.0 (-17.36)	-206.0 (-8.11)	Sway bar bolt rear 12.0 (0.67)
C, c	-641.0 (-25.24)	748.0 (29.45)	-75.4 (-2.97)	Front body hole 70.0 (2.76)
D, d	-658.0 (-25.91)	1640.0 (64.57)	-82.0 (-3.23)	Middle body hole 30.0 (1.18)
E, e	-654.0 (-25.75)	2717.0 (106.97)	34.7 (1.37)	Rear body hole 70.0 (2.76)
F, f	-657.1 (-25.87)	3128.0 (123.15)	119.0 (4.69)	Front rear body hole 20.0 (0.79)
G, g	-642.6 (-25.30)	4610.0 (181.50)	-151.0 (-5.94)	Rear leaf spring hole 20.0 (0.79)
H, h	-625.0 (-24.61)	4813.0 (189.49)	205.0 (8.07)	Rear body rear hole 20.0 (0.79)
J, j	-559.0 (-22.01)	4846.0 (190.79)	37.0 (1.46)	Rear bumper rear hole 12.0 (0.67)

# BODY EXTERIOR PAINT COLOR

< VEHICLE INFORMATION >


[REPAIR INFORMATION - NON-XD]

## VEHICLE INFORMATION

### BODY EXTERIOR PAINT COLOR

#### Body Exterior Paint Color

INFOID:0000000014402216



AWKIA41552Z

Component		Color code	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
		Description	Brown	Orange	Yellow	Black	Silver	Gray	Red	White	White	Blue
		Paint type	M	M	M	M	M	M	M	P	S	P
		Clear coat	x	x	x	x	x	x	x	x	x	x
1.	Roof spoiler	Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
	Door outside handle	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
	Door mirror	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
	Front grille insert	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome (sat-in)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray	Gray
	Front grille outer	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Body color	—	—	EAZ	G41	K23	KAD	NAH	QAB	—	RAY
6.	Front bumper upper fascia	Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
	Front bumper lower fascia	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY

**BODY EXTERIOR PAINT COLOR**

&lt; VEHICLE INFORMATION &gt;

**[REPAIR INFORMATION - NON-XD]**

Component		Color code	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
		Description	Brown	Orange	Yellow	Black	Silver	Gray	Red	White	White	Blue
		Paint type	M	M	M	M	M	M	M	P	S	P
		Clear coat	x	x	x	x	x	x	x	x	x	x
8.	Overfender	Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	—	—	—	—	—	KAD	—	—	—	—
9.	Running board	Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
10.	Rear bumper fascia	Black (low gloss)	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black
		Chrome	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
		Bluish gray	KAC	KAC	KAC	KAC	KAC	—	KAC	KAC	—	KAC
		Body color	CAJ	CAU	EAZ	G41	K23	KAD	NAH	QAB	QAK	RAY
11.	Tailgate outer finisher	Chrome (dark)	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr	Cr
12.	Tailgate handle	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black	Black

M: Metallic; S: Solid; P: Pearl; x: Standard Clear Coat

A  
B  
C  
D  
E  
FG  
H  
I  
J

BRM

L  
M  
N  
O  
P

# PRECAUTION

## PRECAUTIONS

### Precautions for Body Repair

INFOID:000000014402217

**WARNING:**

- The repair information in this section is intended for trained body repair technicians who have attained a high level of skill and experience (e.g. ASE Collision Repair Certification, I-CAR Professional Development Program [PDP] training, etc.) in repairing collision damaged vehicles using appropriate tools and equipment. Performing repairs without the proper training, tools or equipment could damage the vehicle or cause personal injury or death to you or others.
- The information in this Body Repair Manual is a guideline for repairing collision damaged vehicles. However, this information cannot cover all possible ways that a vehicle can be damaged. As such, the body repair technician is responsible for making sure that the repair does not affect the structural integrity or safety of the vehicle. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.
- Nissan recommends using only new genuine Nissan replacement body parts. Use of used, salvaged or aftermarket body parts is not recommended by Nissan. Non-genuine Nissan components may affect the vehicle's structural integrity and crash safety performance, which could result in serious personal injury or death in an accident.

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000014402218

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

# HANDLING PRECAUTIONS FOR PLASTICS

[REPAIR INFORMATION - NON-XD]

< PRECAUTION >

## HANDLING PRECAUTIONS FOR PLASTICS

### Precautions For Plastics

INFOID:0000000014402219

Abbre- viation	Material name	Heat resisting temperature °C (°F)	Resistance to gasoline and solvents	Other cautions
PE	Polyethylene	60 (140)	Gasoline and most solvents are harmless if applied for a very short time (wipe up quickly).	Flammable
PVC	Poly Vinyl Chloride	80 (176)	Same as above.	Poison gas is emitted when burned.
EPM/ EPDM	Ethylene Propylene (Diene) co- polymer	80 (176)	Same as above.	Flammable
TPO/ TPR	Thermoplastic Olefine/ Thermoplastic rubber	80 (176)	Same as above.	Flammable
PP	Polypropylene	90 (194)	Same as above.	Flammable, avoid bat- tery acid.
UP	Unsaturated Polyester	90 (194)	Same as above.	Flammable
PS	Polystyrene	80 (176)	Avoid solvents.	Flammable
ABS	Acrylonitrile Butadiene Styrene	80 (176)	Avoid gasoline and solvents.	—
PMMA	Poly Methyl Methacrylate	85 (185)	Same as above.	—
EVAC	Ethylene Vinyl Acetate	90 (194)	Same as above.	—
ASA	Acrylonitrile Styrene Acrylate	100 (222)	Same as above.	Flammable
PPE	Poly Phenylene Ether	110 (230)	Same as above.	—
PC	Polycarbonate	120 (248)	Same as above.	—
PAR	Polyarylate	180 (356)	Same as above.	—
PUR	Polyurethane	90 (194)	Same as above.	—
PPC	Polypropylene Composite	115 (239)	Same as above	Flammable
POM	Poly Oxymethylene	120 (248)	Same as above.	Avoid battery acid.
PBT+ PC	Poly Butylene Terephthalate + Polycarbonate	120 (248)	Same as above.	Flammable
PA	Polyamide (Nylon)	140 (284)	Same as above.	Avoid immersing in wa- ter.
PBT	Poly Butylene Terephthalate	140 (284)	Same as above.	—
PET	Polyester	180 (356)	Same as above.	—
PEI	Polyetherimide	200 (392)	Same as above.	—

#### CAUTION:


- When repairing and painting a portion of the body adjacent to plastic parts, consider their characteristics (influence of heat and solvent) and remove them if necessary or take suitable measures to protect them.
- Plastic parts should be repaired and painted using methods suiting the materials' characteristics.

# HANDLING PRECAUTIONS FOR PLASTICS

[REPAIR INFORMATION - NON-XD]

< PRECAUTION >

LOCATION OF PLASTIC PARTS



AWKIA41662Z

Item	Component		Abbreviation	Material
1.	Satellite antenna base (if equipped)		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
2.	Front fender duct		ABS	Acrylonitrile Butadiene Styrene
3.	Front grille insert (low gloss black)		ASA	Acrylonitrile Styrene Acrylate
	Front grille insert		ABS	Acrylonitrile Butadiene Styrene
4.	Front grille outer		ABS	Acrylonitrile Butadiene Styrene
5.	Front bumper upper fascia		PP	Polypropylene
6.	Front fog lamp (if equipped)		PBT + ASA	Poly Butylene Terephthalate + Acrylonitrile Styrene Acrylate
7.	Front air spoiler (if equipped)		PP + EPDM	Polypropylene + Ethylene Propylene (Diene) copolymer
8.	Front combination lamp	Housing	PP	Polypropylene
		Lens		
9.	Overfender (front/rear) (if equipped)		PC + PBT	Polycarbonate + Poly Butylene Terephthalate
10.	Running board step pad (if equipped)		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
11.	High mount stop lamp		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
12.	Rear combination lamp	Housing	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
		Lens	PMMA	Poly Methyl Methacrylate
13.	Rear bumper step		TPO	Thermoplastic Olefine
14.	Tailgate finisher	Outer	ABS	Acrylonitrile Butadiene Styrene
		Inner	TPO	Thermoplastic Olefine
15.	Tailgate outside handle	Handle	PC + PET	Polycarbonate + Polyester
		Escutcheon		
16.	Tailgate trim		TPO	Thermoplastic Olefine
17.	Bedside finisher		TPO	Thermoplastic Olefine
18.	Roof spoiler		PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene


# HANDLING PRECAUTIONS FOR PLASTICS

[REPAIR INFORMATION - NON-XD]

< PRECAUTION >

Item	Component	Abbreviation	Material
19.	Door outside handle (black)	PA	Polyamide (Nylon)
	Escutcheon		
20.	Door outside handle (chrome)	PC + ABS	Polycarbonate + Acrylonitrile Butadiene Styrene
	Escutcheon		
20.	Door mirror	ASA	Acrylonitrile Styrene Acrylate
	Base		
	Housing		
	Cover (black)	ABS	Acrylonitrile Butadiene Styrene
	Cover (chrome)		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J



BRM

ALKIA4195ZZ

L  
M  
N  
O  
P

Item	Component	Abbreviation	Material
1.	Center pillar finisher	PP	Polypropylene
2.	Rear pillar finisher	PET	Polyester
3.	Back panel finisher	PP	Polypropylene
4.	Kicking plate	PP	Polypropylene
5.	Center console	PP	Polypropylene
6.	Dash side finisher	PP	Polypropylene
7.	Instrument panel	Skin	TPO
		Pad	PUR
		Core	PPC
8.	Front pillar finisher	PET	Polyester
9.	Steering column cover	PP	Polypropylene
	Upper		
	Lower		

&lt; PRECAUTION &gt;

## REPAIRING HIGH STRENGTH STEEL

## High Strength Steel (HSS)

INFOID:0000000014402220

High strength steel is used for body panels in order to reduce vehicle weight.


Accordingly, precautions in repairing automotive bodies made of high strength steel are described below:

Tensile strength	Major applicable parts
590 MPa	<ul style="list-style-type: none"> <li>Front side member</li> <li>Roof front rail</li> <li>Roof side rail inner</li> <li>Front pillar inner upper</li> <li>Center pillar inner</li> <li>Center pillar hinge brace</li> <li>Front side member extension</li> <li>Sill outer reinforcement</li> <li>Rear pillar outer reinforcement</li> </ul>
980 MPa	<ul style="list-style-type: none"> <li>Sill inner reinforcement</li> <li>Front pillar outer reinforcement</li> <li>Center pillar inner reinforcement</li> <li>Roof side rail outer</li> <li>Sill outer brace</li> </ul>


Read the following precautions when repairing HSS:

## 1. Additional points to consider:

- The repair of reinforcements (such as side members) by heating is not recommended since it may weaken the component. When heating is unavoidable, do not heat HSS parts above 550°C (1,022°F). Verify heating temperature with a thermometer. (Crayon-type and other similar type thermometers are appropriate.)



- When straightening body panels, use caution in pulling any HSS panel. Because HSS is very strong, pulling may cause deformation in adjacent portions of the body. In this case, increase the number of measuring points and carefully pull the HSS panel.




# REPAIRING HIGH STRENGTH STEEL


## [REPAIR INFORMATION - NON-XD]

### < PRECAUTION >


- When cutting HSS panels, avoid gas (torch) cutting if possible. Instead, use a saw to avoid weakening surrounding areas due to heat. If gas (torch) cutting is unavoidable, allow a minimum margin of 50 mm (1.97 in).



- When welding HSS panels, use spot welding whenever possible in order to minimize weakening surrounding areas due to heat. If spot welding is impossible, use MIG welding. Do not use gas (torch) for welding because it is inferior in welding strength.




- The spot weld on HSS panels is harder than that of an ordinary steel panel. Therefore, when cutting spot welds on a HSS panel, use a low speed high torque drill (1,000 to 1,200 rpm) to increase drill bit durability and facilitate the operation.



### 2. Precautions in spot welding HSS

This work should be performed under standard working conditions. Always note the following when spot welding HSS:

- The electrode tip diameter must be sized properly according to the metal thickness.




# REPAIRING HIGH STRENGTH STEEL

## < PRECAUTION >

## [REPAIR INFORMATION - NON-XD]


- The panel surfaces must fit flush to each other, leaving no gaps.



- Follow the specifications for the proper welding pitch.

Thickness (T)	Minimum pitch (L)
0.6 (0.024)	10 (0.39) or over
0.8 (0.031)	12 (0.47) or over
1.0 (0.039)	18 (0.71) or over
1.2 (0.047)	20 (0.79) or over
1.6 (0.063)	27 (1.06) or over
1.8 (0.071)	31 (1.22) or over

Unit: mm (in)



## Handling of Ultra High Strength Steel Plate Parts

INFOID:000000014402221

### PROHIBITION OF CUT AND CONNECTION

Do not cut and join the lower lock pillar reinforcement (center pillar reinforcement inside frame parts) because its material is high strength steel plate (ultra high strength steel plate).

The center pillar reinforcement must be replaced if this part is damaged.

## Welding of Ultra High Strength Steel

INFOID:000000014402222

### SPOT WELDING

Spot welding is limited to ultra high strength steel of (tensile strength: 980 MPa) according to the welding conditions listed below.

#### CAUTION:

- If the below welding conditions cannot be met, then perform plug welding.
- Never spot weld ultra high strength steel of tensile strength more than 980 MPa. For this type of ultra high strength steel, perform plug welding.
- The below welding condition is applicable only to this vehicle. Never apply these same conditions to other vehicles.

#### Welding condition

<b>Welder tip diameter</b>	<b>6 MM</b>
<b>Welding pressure (Gun force)</b>	<b>3425 N</b>
<b>Welding current</b>	<b>8035 A</b>
<b>Weld time*</b>	<b>.24 sec (12 cyc: 50 Hz) .23 sec (14 cyc: 60 Hz)</b>

## &lt; PRECAUTION &gt;

## Panel configuration

Combination of a plate of tensile strength of 980 MPa and that of tensile strength less than 980 MPa. (Up to 3 plates)

\* Select weld time based on the frequency (Hz) of the electrical power supplied in your area.

## PLUG WELDING

To weld ultra high strength steel of tensile strength 980 MPa or more, perform plug welding observing the welding hole diameter described in the manual.

**CAUTION:**

- To perform plug welding, use fuel mixture (Ar 80% + CO<sub>2</sub> 20%) for shielding gas of welder.
- Never use carbon dioxide gas (CO<sub>2</sub> 100%) as shielding gas of welder. Using CO<sub>2</sub> 100% gas results in inadequate weld strength.
- When welding hole diameter cannot be met, make multiple holes (smaller diameter) so that the sum of the holes areas equals the area of the original weld hole.

A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P

# PREPARATION

## REPAIRING MATERIAL

### Foam Repair

INFOID:000000014402223

During factory body assembly, foam insulators are installed in certain body panels and locations around the vehicle. Use the following procedure(s) to replace any factory-installed foam insulators.

#### URETHANE FOAM APPLICATIONS

Use commercially available urethane foam for sealant (foam material) repair of material used on vehicle.


<Urethane foam for foaming agent>

3M™ Automix™ Flexible Foam 08463 or equivalent

Read instructions on product for fill procedures.

Example of foaming agent filling operation procedure:

1. Fill procedures after installation of service part.
  - a. Eliminate foam material remaining on vehicle side.
  - b. Clean area after eliminating form insulator and foam material.
  - c. Install service part.
  - d. Insert nozzle into hole near fill area and fill foam material or fill enough to close gap with the service part.



JSKIA0129GB

1. Urethane foam

A. Nozzle insert hole

Front

2. Fill procedures before installation of service part:

- a. Eliminate foam material remaining on vehicle side.
- b. Clean area after eliminating foam insulator and foam material.

c. Fill with enough foam material on the wheelhouse outer side to close the gap with the service part while avoiding the flange area.

1. Urethane foam


A. Fill while avoiding flange area

Front

d. Install service part.

**NOTE:**

Refer to the label on the urethane foam container for information on working times.



JSKIA0130GB

# BODY COMPONENT PARTS


[REPAIR INFORMATION - NON-XD]

< PREPARATION >

## BODY COMPONENT PARTS

Underbody Component, Engine Compartment Parts

INFOID:0000000014402224



A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P

AWKIA4093ZZ

■■■ : Both sided anti-corrosive precoated steel portions

■■ : Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

< PREPARATION >

[REPAIR INFORMATION - NON-XD]

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Rear floor	Under 440	x	—
2.	Rear seat mounting brackets (LH/RH)	Under 440	x	—
3.	Front floor	Under 440	x	—
4.	Upper dash	Under 440	x	—
5.	Cowl top	Under 440	x	—
6.	Lower dash	Under 440	x	—
7.	Front floor reinforcement	440	x	—
8.	Hoodledge brace (RH)	Under 440	x	—
9.	Hoodledge reinforcement (RH)	Under 440	x	—
10.	Harness bracket (RH)	Under 440	x	—
11.	Battery mounting bracket 1st (RH)	Under 440	x	—
12.	Battery mounting bracket 2nd (RH)	Under 440	x	—
13.	Hoodledge assembly (RH)	440	x	—
14.	Hoodledge reinforcement (LH)	Under 440	x	—
15.	Hoodledge lower reinforcement (LH/RH)	Under 440	x	—
16.	Radiator core support upper (LH/RH)	Under 440	x	—
17.	Radiator core support side (LH/RH)	440	x	—
18.	Hoodledge (LH/RH)	440	x	—
19.	Hoodledge assembly (LH)	440	x	—
20.	Dash side (LH/RH)	Under 440	x	—
21.	Cab mounting crossmember 2nd	Under 440	x	—
22.	Front seat mounting crossmember 1st	Under 440	x	—
23.	Front side member (LH/RH)	590	x	—
24.	Sill inner (LH/RH)	980	x	—
25.	Sill inner extension (LH/RH)	Under 440	x	—
26.	Rear side member bracket (LH/RH)	Under 440	x	—
27.	Parking brake bracket rear	Under 440	x	—
28.	Front seat mounting crossmember 2nd	Under 440	x	—
29.	Rear seat mounting crossmember 1st	Under 440	x	—
30.	Rear seat mounting crossmember 2nd	440	x	—
31.	Rear floor reinforcement	Under 440	x	—

**CAUTION:**

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

**NOTE:**

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.


# BODY COMPONENT PARTS

[REPAIR INFORMATION - NON-XD]

< PREPARATION >

## Body Component Parts

INFOID:000000014402225



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N  
O  
P

AWKIA4094ZZ

■ : Both sided anti-corrosive precoated steel portions

■ : Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

## [REPAIR INFORMATION - NON-XD]

### < PREPARATION >

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Rear body floor assembly	Under 440	X	—
2.	Rear body floor tail bolster	440	X	—
3.	Roof	Under 440	X	—
4.	Roof rear rail	440	X	—
5.	Roof bow 2nd	Under 440	X	—
6.	Roof bow 1st bracket (LH/RH)	Under 440	X	—
7.	Roof bow 1st	440	X	—
8.	Roof front rail	590	X	—
9.	Roof side rail inner (LH/RH)	590	X	—
10.	Front pillar inner upper (LH/RH)	590	X	—
11.	Front pillar outer reinforcement (LH/RH)	980	X	—
12.	Front pillar hinge brace (LH/RH)	440	X	—
13.	Center pillar inner (LH/RH)	980	X	—
14.	Roof side rail outer (LH/RH)	980	X	—
15.	Center pillar hinge brace (LH/RH)	590	X	—
16.	Sill outer (LH/RH)	980	X	—
17.	Hoodledge rear reinforcement (LH/RH)	Under 440	X	—
18.	Hood	Under 440	X	—
19.	Front fender (LH/RH)	Under 440	X	—
20.	Front door assembly (LH/RH)	1470	X	—
21.	Front door outer (LH/RH)	Under 440	X	—
22.	Rear door assembly (LH/RH)	1470	X	—
23.	Rear door outer (LH/RH)	Under 440	X	—
24.	Body side outer (LH/RH)	Under 440	X	—
25.	Rear pillar outer reinforcement (LH/RH)	590	X	—
26.	Rear pillar inner (LH/RH)	440	X	—
27.	Back panel	Under 440	X	—
28.	Rear body header panel assembly	Under 440	X	—
29.	Rear body front strut outer (LH/RH)	Under 440	X	—
30.	Rear body outer panel (LH/RH)	Under 440	X	—
31.	Rear body floor bolster 1st	Under 440	X	—
32.	Rear body floor bolster 3rd	Under 440	X	—
33.	Rear body inner panel (LH/RH)	Under 440	X	—
34.	Rear body floor bolster 4th	Under 440	X	—
35.	Tail gate assembly	Under 440	X	—

### CAUTION:

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

### NOTE:

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.


# BODY COMPONENT PARTS

[REPAIR INFORMATION - NON-XD]

< PREPARATION >

Frame Component Parts

INFOID:000000014402226



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRM

AWKIA41992Z

■ : Both sided anti-corrosive precoated steel portions

■ : Both sided anti-corrosive steel and HSS portions

# BODY COMPONENT PARTS

## [REPAIR INFORMATION - NON-XD]

< PREPARATION >

No.	Part name	Tensile strength (MPa)	Both sided anti-corrosive precoated steel sections	Aluminum portion
1.	Frame assembly	440	X	—
2.	Front crossmember assembly	440	X	—
3.	Front side member extension upper reinforcement (LH/RH)	Under 440	X	—
4.	Front crossmember	440	X	—
5.	Front bumper bracket (LH/RH)	440	X	—
6.	Front side member extension upper reinforcement (LH/RH)	440	X	—
7.	Front side member extension inner reinforcement (LH/RH)	440	X	—
8.	Front side member extension (LH/RH)	440	X	—
9.	Front crossmember reinforcement (LH/RH)	440	X	—
10.	Cab mounting bracket 1st (LH/RH)	Under 440	X	—
11.	Front side member extension lower reinforcement (LH/RH)	440	X	—
12.	Front side member extension outer lower reinforcement (LH/RH) (4WD only)	440	X	—
13.	Front side member assembly (LH/RH)	440	X	—
14.	Front shock absorber mounting bracket (LH/RH)	440	X	—
15.	Front engine mounting bracket (LH/RH)	440	X	—
16.	Front bumper bound mounting bracket (LH/RH)	440	X	—
17.	Front brake hose bracket (LH/RH)	Under 440	X	—
18.	Cab mounting bracket 2nd (LH/RH)	440	X	—
19.	Cab mounting bracket 3rd (LH/RH)	440	X	—
20.	Cab mounting bracket 4th (LH/RH)	440	X	—
21.	Rear leaf spring front mounting bracket (LH/RH)	Under 440	X	—
22.	Rear body mounting bracket 2nd (LH/RH)	Under 440	X	—
23.	Rear bumper bound mounting bracket (LH/RH)	Under 440	X	—
24.	Rear shock absorber bracket (LH/RH)	Under 440	X	—
25.	Rear leaf spring rear mounting bracket (LH/RH)	Under 440	X	—
26.	Rear body mounting bracket 5th (LH/RH)	Under 440	X	—

**CAUTION:**

If the high strength steel (ultra high strength steel) is bent or broken, replace by assembly for the supply part.

**NOTE:**

- For the parts without a number described in the figure, it is supplied only with the assembly part that the part is included with.
- Tensile strength column shows the largest strength value of a part in the component part.

# REMOVAL AND INSTALLATION

## CORROSION PROTECTION

### Description


INFOID:000000014402227

To provide improved corrosion prevention, the following anti-corrosive measures have been implemented in NISSAN production plants. When repairing or replacing body panels, it is necessary to use the same anti-corrosive measures.

#### Anti-Corrosive Precoated Steel (Galvannealed Steel)

To improve repairability and corrosion resistance, a new type of anti-corrosive precoated steel sheet has been adopted, replacing conventional zinc-coated steel sheet.

Galvannealed steel is electroplated and heated to form zinc-iron alloy, which provides excellent and long term corrosion resistance with cationic electrodeposition primer.



SIIA2294E


NISSAN Genuine Service Parts are fabricated from galvannealed steel. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain the anti-corrosive performance built into the vehicle at the factory.

#### Phosphate Coating Treatment and Cationic Electrodeposition Primer

A phosphate coating treatment and a cationic electrodeposition primer, which provide excellent corrosion protection, are employed on all body components.

#### CAUTION:

Confine paint removal during welding operations to an absolute minimum.




PIIA0095E

NISSAN Genuine Service Parts are also treated in the same manner. Therefore, it is recommended that GENUINE NISSAN PARTS or equivalent be used for panel replacement to maintain anti-corrosive performance built into the vehicle at the factory.

#### Anti-Corrosive Wax

INFOID:000000014402228

To improve corrosion resistance, anti-corrosive wax is applied inside the body sill and inside other closed sections. Accordingly, when replacing these parts, be sure to apply anti-corrosive wax to the appropriate areas of the new parts. Select an excellent anti-corrosive wax which will penetrate after application and has a long shelf life.



AWKIA3823ZZ

1. Anti-corrosive wax	2. Body caulk	3. Panel adhesive
B. 100 mm (3.94 in)	C. 10 mm (0.39 in)	D. 2 mm (0.08 in)


## Undercoating

INFOID:0000000014402229

The underside of the floor and wheelhouse are undercoated to prevent rust, vibration, noise and stone chipping. Therefore, when such a panel is replaced or repaired, apply undercoating to that part. Use an undercoating which is rust preventive, soundproof, vibration-proof, shock-resistant, adhesive, and durable.

### Precautions in Undercoating

1. Never apply undercoating unless specified. Avoid areas such as the areas above the muffler and three-way catalyst which are subjected to heat.
2. Never undercoat the exhaust pipe or other parts which become hot.
3. Never undercoat rotating parts.
4. Apply bitumen wax after applying undercoating.
5. After putting seal on the vehicle, put undercoating on it.





AWKIA4161ZZ

Undercoated areas are shaded.

## Stone Guard Coat

INFOID:000000014402230

To prevent damage caused by stones, the lower outer body panel (fender, door, etc.) have an additional layer of Stone Guard Coating over the ED primer coating. When replacing or repainting these panels, apply Stone Guard coating to the same portions as before. Use a coating which is rust preventive, durable, shock-resistant and has a long shelf life.



ALKIA4497ZZ

Stone guard areas are shaded.

1. Stone guard



A. 195 mm (7.68 in.)

## BODY SEALING

### Description

INFOID:0000000014402231

The following figure shows the areas which are sealed at the factory. Sealant which has been applied to these areas should be smooth and free from cuts or gaps. Care should be taken not to apply an excess amount of sealant and not to allow other unaffected parts to come into contact with the sealant.




◀ Front

ALKIA4498ZZ

# BODY SEALING

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA3846ZZ


◀ Front

# BODY SEALING


< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]


J




K




L




M



N



P




AWKIA4096ZZ

◀ Front

# BODY SEALING

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

O

AWKIA4097ZZ

◀ Front

# BODY CONSTRUCTION



< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## BODY CONSTRUCTION

### Body Construction

INFOID:0000000014402232



AWKIA4098ZZ

1. Front pillar inner
2. Front pillar reinforcement
3. Front pillar bracket
4. Body side outer
5. Front pillar hinge brace
6. Front pillar brace
7. Sill outer
8. Sill outer brace
9. Sill inner

# BODY CONSTRUCTION

## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - NON-XD]

- 10. Sill inner reinforcement
- 11. Center pillar hinge brace
- 13. Sill outer extension
- 14. Sill inner extension
- 16. Rear pillar reinforcement
- 17. Center pillar brace

- 12. Center pillar inner
- 15. Rear pillar inner
- Front


### Rear Body

INFOID:000000014402233


#### REMOVAL AND INSTALLATION

##### Removal

1. Remove rear bumper. Refer to [EXT-29, "Removal and Installation"](#).
2. Remove rear fender protectors. Refer to [EXT-42, "Exploded View - Rear Fender Protector"](#).
3. Remove rear cargo power socket (if equipped). Refer to [PWO-50, "Removal and Installation - Rear"](#).
4. Using a suitable tool disconnect the bed rail lamp harness connectors.
5. Using a suitable tool release all harness clips from rear body and disconnect the rear combination lamp harness connectors (LH/RH) (A).



6. Remove fuel filler tube bolt (A) and place fuel tank filler pipe aside.



7. Remove rear body mounting bolts and rear body. Refer to [BRM-250, "Body Mounting"](#).

##### Installation

Installation is in the reverse order of removal.

## REPLACEMENT OPERATIONS

## Precautions for Body Repair

INFOID:0000000014402234

**WARNING:**





- The repair information in this section is intended for trained body repair technicians who have attained a high level of skill and experience (e.g. ASE Collision Repair Certification, I-CAR Professional Development Program [PDP] training, etc.) in repairing collision damaged vehicles using appropriate tools and equipment. Performing repairs without the proper training, tools or equipment could damage the vehicle or cause personal injury or death to you or others.
- The information in this Body Repair Manual is a guideline for repairing collision damaged vehicles. However, this information cannot cover all possible ways that a vehicle can be damaged. As such, the body repair technician is responsible for making sure that the repair does not affect the structural integrity or safety of the vehicle. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.
- Nissan recommends using only new genuine Nissan replacement body parts. Use of used, salvaged or aftermarket body parts is not recommended by Nissan. Non-genuine Nissan components may affect the vehicle's structural integrity and crash safety performance, which could result in serious personal injury or death in an accident.

## Description

INFOID:0000000014402235

- Technicians are encouraged to read the Body Repair Manual (Fundamentals) in order to ensure that the original functions and quality of the vehicle are maintained. The Body Repair Manual (Fundamentals) contains additional information, including cautions and warnings, that are not included in this manual. Technicians should refer to both manuals to ensure proper repair.
- Please note that this information is prepared for worldwide usage, and as such, certain procedures might not apply in some regions or countries.






The symbols used in this section for welding operations are shown below.

Symbol marks	Description	
"Number"	<p>"Number" after symbol mark is the total number of welds to apply.            Example 1: ■"4"A = 4 MIG plug welds for 3-panel plug weld method.            Example 2: mm"1" x20 (0.79) = 1 MIG seam weld by length 20 mm (0.79 in).</p>	
 JSKIA004922	2-panel spot weld	
 JSKIA005022	3-panel spot weld	 JSKIA005322

# REPLACEMENT OPERATIONS

## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - NON-XD]

Symbol marks	Description	
 JSKIA0051ZZ	MIG plug weld	 For 3-panel plug weld method
 JSKIA0052ZZ	MIG seam weld / Point weld	 JSKIA0056ZZ
		 PIIA0150E
	<ul style="list-style-type: none"> <li>Front pillar butt joint can be determined anywhere within shaded area as shown in the figure. The best location for the butt joint is at position A due to the construction of the vehicle.</li> </ul>	 JSKIA0104GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
**BRM**  
L  
M  
N  
O  
P

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >


### [REPAIR INFORMATION - NON-XD]

- Prepare a cutting jig to make outer pillar easier to cut. Also, this will permit the service part to be accurately cut at the joint position.



- An example of cutting operation using a cutting jig is as per the following.

1. Mark cutting lines.
  - A: Cut position of outer pillar
  - B: Cut position of inner pillar
2. Align cutting line with notch on jig. Clamp jig to pillar.
3. Cut outer pillar along groove of jig (at position A).
4. Remove jig and cut remaining portions.
5. Cut inner pillar at position B in same manner.




# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Radiator Side Support

INFOID:000000014402236



### Replacement parts

- Radiator side support

A. Mig weld

◀ Front

AWKIA4156ZZ

O

P

## Hoodledge


INFOID:000000014402237

## REAR REINFORCEMENT

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



ALKIA4488ZZ

Replacement parts

- Hoodledge rear reinforcement

A. MIG weld


Front

HOODLEDGE

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

ALKIA44892Z

## Replacement parts

- Hoodledge assembly

◀ Front

## Front Pillar

INFOID:000000014402238

O  
P


### OUTER

- Work after hoodledge rear reinforcement has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA3853ZZ

## Replacement parts

- Front pillar section of front body side outer      A. Sectioning location
- Adhesive    B. MIG weld
- ← Front


## HINGE BRACE

- Work after front pillar outer has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA385522

## Replacement parts

- Front pillar hinge brace

A. MIG weld

Front


## OUTER REINFORCEMENT

- Work after front pillar hinge brace has been removed.
- Work after roof panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA4159ZZ

## Replacement parts

- Front pillar outer reinforcement     Front

## Dash Side


INFOID:000000014402239

- Work after front pillar outer reinforcement has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA41602Z

Replacement parts

- Dash side

A. MIG weld

Front

INFOID:000000014402240

Center Pillar


OUTER

O  
P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA3857ZZ

mm (in)

## Replacement parts

- Center pillar portion of front body side outer
- C. 90.0 (3.54)
- A. Sectioning location
- D. 100.0 (3.94)
- B. 70.0 (2.76)
- ↖ Front

\* For spot welding of steel plate of strength 980 MPa, observe the indicated welding conditions. Refer to [BRM-197, "Welding of Ultra High Strength Steel"](#).


## REINFORCEMENT

- Work after center pillar outer has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA38582Z

## Replacement parts

- Center pillar reinforcement

A. Mig weld

Front


INNER

O  
P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



ALKIA4256ZZ

## Replacement parts

- Center pillar inner

A. MIG weld

◀ Front

## Rear Pillar

INFOID:000000014402241


### OUTER

- Work after back panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

O  
P

AWKIA38992Z

## Replacement parts

- Rear pillar portion rear body side outer A. Sectioning location

◀ Front


## OUTER REINFORCEMENT

- Work after the rear outer body side panel and roof have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA3861ZZ

## Replacement parts

- Rear pillar outer reinforcement    ↙ Front

\* For spot welding of steel plate of strength 980 MPa, observe the indicated welding conditions. Refer to [BRM-197, "Welding of Ultra High Strength Steel"](#).


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

Back Panel

INFOID:000000014402242



Replacement parts

- Back panel

A. MIG weld

Front

AWKIA3863ZZ


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Roof

INFOID:000000014402243



AWKIA4162ZZ

### Replacement parts

- Roof panel


Perform plug welding instead of laser welding    Front

## FRONT ROOF RAIL

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



BRM

Replacement parts

- Front roof rail

Front


ROOF BOWS

AWKIA38592Z

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA3821ZZ

Replacement parts

- Roof bows


◀ Front

REAR ROOF RAIL

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L  
M  
N

AWKIA38492Z

## Replacement parts

- Rear roof rail

Front

## Sill Outer

INFOID:000000014402244


O  
P

- Work after the front pillar hinge brace and the center pillar reinforcement and rear pillar reinforcement have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



ALKIA4276ZZ

## Replacement parts

- Sill outer

◀ Front

# REPLACEMENT OPERATIONS



## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - NON-XD]

### Sill Inner

INFOID:000000014402245

- Work after sill outer has been removed.



BRM

#### Replacement parts

- Sill inner

◀ Front

ALKIA4280ZZ


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Rear Body Outer Panel

INFOID:0000000014402246



AWKIA4218ZZ

### Replacement parts

- Rear body outer panel

A. Rivet

◀ Front

## Rear Body Rear Wheel House Outer

INFOID:0000000014402247

- Work after rear body outer panel has been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

A

B

C

D

E

F

G

H

I

J


BRM

L

M

N

ALKIA449222



## Replacement parts

- Rear body rear wheel house outer

◀ Front

## Rear Body Inner Panel

INFOID:000000014402248

O


- Work after rear body outer panel has been removed.

P

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



AWKIA4100ZZ

Replacement parts

- Rear body inner panel

Front


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Rear Body Header Panel

INFOID:000000014402249



A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

ALKIA4288ZZ

### Replacement parts

- Rear body header panel

◀ Front

P

## Rear Body Floor Tail Bolster


INFOID:000000014402250

- Work after rear body outer panel and rear body inner panel have been removed.

# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]



ALKIA4291ZZ

Replacement parts

- Rear body floor tail bolster

◀ Front


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Rear Body Floor

INFOID:000000014402251



### Replacement parts

- Rear body floor

◀ Front

ALKIA4505ZZ


# REPLACEMENT OPERATIONS

< REMOVAL AND INSTALLATION >

[REPAIR INFORMATION - NON-XD]

## Front Side Member Extension

INFOID:000000014402252



ALKIA4499ZZ

### Replacement parts

- A. Sectioning location
- 1. Front bumper mounting bracket (LH/RH)
- 2. Front crossmember

↳ Front



### Removal

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >

### [REPAIR INFORMATION - NON-XD]

- Using a suitable tool cut MIG welds (A) and remove front bumper mounting bracket (LH/RH) (1) from front crossmember (2).



ALKIA4506ZZ

BRM

◀ Front

L

M

N

O



P

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >

### [REPAIR INFORMATION - NON-XD]

- Using a suitable tool cut MIG welds (A) and remove front crossmember (1).



ALKIA4507ZZ



◀ Front

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >

### [REPAIR INFORMATION - NON-XD]

- Using a suitable tool cut MIG welds (A) and remove front side member extension outer lower reinforcement (1) from front side member extension (2) (4WD only).



Front

L

M

N

O

P

A

B

C

D

E

F

G

H

I

J


BRM

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >

### [REPAIR INFORMATION - NON-XD]


- Using a suitable tool cut MIG welds (A) and remove front side member extension inner reinforcement (1) from front side member extension (2).



ALKIA4510ZZ

◀ Front

- Using a suitable tool cut MIG welds (A) and remove front side member extension lower reinforcement (2) from front side member extension (1).



ALKIA4511ZZ


◀ Front

## REPLACEMENT OPERATIONS

### < REMOVAL AND INSTALLATION >

### [REPAIR INFORMATION - NON-XD]


- Using a suitable tool cut MIG welds (A) and remove front side member extension upper reinforcement (2) from front side member extension (1).




ALKIA451322

⬅ Front

- Using a suitable tool cut off front side member extension (1) forward of MIG welds (A).
- Grind remaining MIG weld flush to frame removing inner portion of front side member extension.



BRM



ALKIA452122

# REPLACEMENT OPERATIONS

## < REMOVAL AND INSTALLATION >

## [REPAIR INFORMATION - NON-XD]

◀ Front

### Installation


- Installation is in the reverse order of removal.
- Assemble front side member extension as shown.

### WARNING:

To maintain vehicle structural integrity, always apply proper welds to all frame repair locations. Improper repair of a damaged vehicle may result in a collision, property damage, personal injury or death.

### CAUTION:

- Install front side member extension into frame allowing a 10.2 mm (0.40 in) overlap.
- Inspect parts for damage before welding.
- Always check 2nd crossmember position for proper alignment when replacing front side member extension. Refer to [BRM-262, "Underbody"](#).



ALKIA4522ZZ

Unit: mm (in)



1. Front side member extension inner	2. Front side member extension outer	3. Frame outer
4. Frame inner	A. 10.2 (0.40)	B. 8.6 (0.34)
C. 6.0 (0.24)	D. 10.5 (0.41)	◀ Front

## SERVICE DATA AND SPECIFICATIONS (SDS)

## BODY ALIGNMENT

## Body Mounting

INFOID:0000000014402253



A

B

C

D

E

F

G

H

I

J

BRM

L

M

N

O

P

AWKIA4136ZZ


# BODY ALIGNMENT

## < SERVICE DATA AND SPECIFICATIONS (SDS)

## [REPAIR INFORMATION - NON-XD]

1. Cab mounting insulator (1st)	2. Cab mounting spacer	3. Cab mounting insulator (2nd)
4. Cab mounting washer	5. Cab mounting insulator (3rd)	6. Cab mounting insulator (4th)

◀ Front



AWK1A4137ZZ

7. Rear body shim	8. Rear body mounting spacer	9. Rear body mounting washer
10. Rear body crossmember shim	◀ Front	

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



## CAUTION:

- Before installation, be sure to replace bolts and nuts (sealant applied bolts or self-lock nuts are used for all mounting).
- Unless otherwise noted, the bushings and insulators have paint marks that are to be installed facing outward.

## Body Center Marks

INFOID:0000000014402254

A mark is placed on each part of the body to indicate the vehicle center. When repairing the vehicle frame (members, pillars, etc.) damaged in an accident, the most accurate and effective repair will be achieved by using these marks together with body alignment specifications.



ALKIA4181ZZ


◀ Front

Points	Portion	Marks
A	Front roof	Positioning mark
B	Rear roof	Notch

## Description

INFOID:0000000014402255

- All dimensions indicated in the figures are actual.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (\*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".
- "Z": Imaginary base line [300.0 mm (11.81 in) below datum line ("0Z" at design plan)]



JSKIA0073GB

1. Vehicle center

2. Front axle center

3. Imaginary base line

## Engine Compartment

INFOID:0000000014402256


### MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the RH and LH sides of the vehicle.

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



ALKIA452322




## MEASUREMENT POINTS

BRM

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



ALKIA4524ZZ

◀ Front

Unit: mm (in)

Point	Description
A, a	Hood hinge rear bolt hole 9.0 (0.35)
B, b	Hood hinge front bolt hole 9.0 (0.35)
C, c	Bolt hole 6.0 (0.24)
D, d	Headlight hole 6.0 (0.24)
E, e	Upper radiator tie bar hole 8.0 (0.31)
F, f	Headlight lower bracket upper hole 6.0 (0.24)
G, g	Lower reinforcement inner bolt hole 10.0 (0.39)

## Passenger Compartment

INFOID:000000014402257


## MEASUREMENT

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.



ALKIA41682Z

Unit: mm (in)



Coordinates	Measurement	Coordinates	Measurement
A-B	878.5 (34.59)	H-M*	1036.9 (40.82)
A-D*	1112.7 (43.81)	K-N*	869.8 (34.24)
A-E	880.1 (34.65)	H-K*	803.6 (31.64)
C-c	1314.6 (51.76)	J-Q*	1186.7 (46.72)
C-D	809.2 (31.86)	J-M*	432.1 (17.01)
C-d*	1631.6 (64.24)	J-P*	1236.6 (48.68)
C-B	1124.3 (44.26)	M-P*	1186.5 (46.71)
C-E	1050.1 (41.34)	M-Q*	1277.7 (50.30)
E-B	124.9 (4.92)	R-S*	796.0 (31.34)
F-G*	257.1 (10.12)	R-T*	950.9 (37.44)
F-H*	777.9 (30.63)	R-U*	951.4 (37.46)
F-K*	1325.0 (52.17)	R-V*	573.0 (22.56)
F-N*	580.1 (22.84)	S-T*	758.0 (29.84)
G-H*	586.8 (23.10)	S-U*	1014.2 (39.93)
G-K*	1252.9 (49.33)	S-V*	1111.4 (43.76)
G-N*	719.1 (28.31)		

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



ALKIA4173ZZ

◀ Front


Point	Description	Point	Description
A	Roof front positioning mark	F,f G,g H,h K,k N,n	Front body side outer notch
B,E	Cowl top hole	J,j M,m P,p Q,q	Body side hinge hole
C,c	Outer body side joggle corner	R,r S,s T,t U,u V,v	Body side rear outer notch
D,d	Body side outer front hole		

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

BRM

L

ALKIA41782Z


Front

Unit mm (in)

Coordinates	Measurement
W,y*	826.2 (32.53)
W,X*	643.7 (25.34)
x,Y*	1415.8 (55.74)
X,Y	374.1 (14.61)
Y,y	1450.0 (57.09)

N  
O  
P

MEASUREMENT POINTS



ALKIA4179ZZ

Front

Point	Description
W	Roof notch rear
X,x	Body side rear joggle
Y,y	Rear panel notch


## Roof

INFOID:0000000014402258

### MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.

### MEASUREMENT POINTS



ALKIA420722

Front

Unit: mm (in)

Point	Description	Point	Description
A,a	Roof rail front center front locator hole 30.0 (1.18)	B,b	Rear body side rear hole locator hole 13.0 (0.51)

BRM

## Rear Body

INFOID:000000014402259


## MEASUREMENT

Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH side of the vehicle.

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]






AWKIA4163ZZ

Unit: mm (in)

↖ Front

## MEASUREMENT POINTS



AWKIA41642Z

← Front

Unit: mm (in)

Point	Description
A,a	Front square stake pocket 55.0 (2.17) X 43.0 (1.69) front outer point
B,b	Rear square stake pocket 55.0 (2.17) X 43.0 (1.69) rear outer point
C,c	Rear body front upper outer bolt hole 9.0 (0.35)
D,d	Rear body front lower outer bolt hole 9.0 (0.35)

**BRM****Underbody**

INFOID:000000014402260


**MEASUREMENT**

The following figure shows a bottom view and a side view of the vehicle.

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



AWKIA4234ZZ

Unit: mm (in).

Front


Dimensions marked with "\*" indicate symmetrically identical dimensions on both the LH and RH sides of the vehicle.

## MEASUREMENT POINTS

# BODY ALIGNMENT

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]



ALKIA456522

◀ Front

Unit: mm (in)

Points	Coordinates			Remarks
	X	Y	Z	
A, a	$\pm 447.4$ ( $\pm 16.86$ )	-747.0 (-29.41)	28.4 (1.12)	Front locator hole 20.0 (0.79)
B, b	$\pm 518.0$ ( $\pm 20.39$ )	-500.0 (-19.69)	105.0 (4.13)	1st cab bracket hole 32.2 (1.27)
C, c	$\pm 295.5$ ( $\pm 11.63$ )	-205.5 (-8.09)	-223.9 (-8.81)	Locator hole 13.0 (0.51)
D, d	$\pm 457.0$ ( $\pm 17.99$ )	-504.8 (-19.87)	-185.2 (-7.29)	Slotted hole 31.0 x 22.0 (1.22 x 0.87)
E, e	$\pm 641.0$ ( $\pm 25.24$ )	748.0 (29.45)	-72.0 (-72.0)	2nd cab bracket 75.0 (2.95)
F, f	$\pm 495.4$ ( $\pm 19.50$ )	1013.2 (39.89)	200.0 (7.87)	Locator hole 20.0 (0.79)
G, g	$\pm 563.8$ ( $\pm 22.20$ )	2543.4 (100.13)	-210.7 (-8.30)	Slotted hole 31.0 x 22.0 (1.22 x 0.87)
H, h	$\pm 625.0$ ( $\pm 24.61$ )	2970.0 (116.93)	150.7 (5.93)	Rear body front hole 20.0 (0.79)
J, j	$\pm 559.0$ ( $\pm 22.01$ )	4171.0 (164.21)	109.5 (4.31)	Rear bumper rear hole 12.0 (0.67)
K, k	$\pm 559.0$ ( $\pm 22.01$ )	4546.0 (178.98)	46.1 (1.81)	Rear bumper rear hole 12.0 (0.67)

## **BODY ALIGNMENT**

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REPAIR INFORMATION - NON-XD]

---