

8. Diagnostics with Phenomenon

A: DIAGNOSTIC PROCEDURE WITH PHENOMENON

Phenomenon		Check Item	Note
1	CRUISE switch is not turned ON. (CRUISE indicator does not illuminate.) Or the cruise control is cancelled without CRUISE switch operation.	(1) Perform cruise cancel conditions diagnosis. (2) Perform the real-time diagnosis. (3) Check the cruise control command switch. (4) Check the CRUISE indicator.	Perform the diagnosis according to displayed cancel code. Check the input signal of cruise control system. <Ref. to CC(diag)-15, 11, Diagnostic Procedure with Cancel Code.> <Ref. to CC(diag)-12, CHECK CRUISE INDICATOR LIGHT AND CRUISE SET INDICATOR LIGHT, Diagnostics with Phenomenon.>
2	Cruise control cannot be set. Or cruise control is cancelled without releasing operation.	(1) Perform cruise cancel conditions diagnosis. (2) Perform the real-time diagnosis. (3) Check the cruise control command switch. (4) Check stop light switch and brake switch. (5) Check clutch switch. (6) Check the neutral position switch. (7) Check vehicle speed sensor.	Perform the diagnosis according to displayed cancel code. Check the input signal of cruise control system. <Ref. to CC(diag)-15, 11, Diagnostic Procedure with Cancel Code.> <Ref. to BR-74, Stop Light Switch.> <Ref. to CC(diag)-17, 12, Diagnostic Procedure with Cancel Code.> <Ref. to CL-29, Clutch Switch.> <Ref. to CC(diag)-20, 13, Diagnostic Procedure with Cancel Code.> <Ref. to CC(diag)-21, 14, Diagnostic Procedure with Cancel Code.> <Ref. to CC(diag)-26, 62, Diagnostic Procedure with Cancel Code.> <Ref. to CC(diag)-25, 22, Diagnostic Procedure with Cancel Code.>
3	SET indicator does not illuminate.	Check the SET indicator.	<Ref. to CC(diag)-12, CHECK CRUISE INDICATOR LIGHT AND CRUISE SET INDICATOR LIGHT, Diagnostics with Phenomenon.>
4	Vehicle speed is not held within set speed ± 3 km/h (± 2 MPH).	Check the vehicle speed sensor.	<Ref. to CC(diag)-25, 22, Diagnostic Procedure with Cancel Code.>
5	Vehicle speed does not increase or does not return to set speed after RES/+ switch has been pressed.	(1) Perform the real-time diagnosis. (2) Check the RES/+ switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-15, 11, Diagnostic Procedure with Cancel Code.>
6	Vehicle speed does not decrease after SET/- switch has been pressed.	(1) Perform the real-time diagnosis. (2) Check the SET/- switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-15, 11, Diagnostic Procedure with Cancel Code.>
7	Cruise control is not released after CANCEL switch has been pressed.	(1) Perform the real-time diagnosis. (2) Check the CANCEL switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-15, 11, Diagnostic Procedure with Cancel Code.>
8	Cruise control is not released after brake pedal has been depressed.	(1) Perform the real-time diagnosis. (2) Check stop light switch and brake switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-17, 12, Diagnostic Procedure with Cancel Code.> <Ref. to BR-76, INSTALLATION, Stop Light Switch.>
9	Cruise control is not released after shifting to the neutral position.	(1) Perform the real-time diagnosis. (2) Check the neutral position switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-21, 14, Diagnostic Procedure with Cancel Code.> <Ref. to CC-16, Neutral Position Switch.>
10	Cruise control is not released after clutch pedal has been depressed.	(1) Perform the real-time diagnosis. (2) Check clutch switch.	Check the input signal of cruise control system. <Ref. to CC(diag)-20, 13, Diagnostic Procedure with Cancel Code.> <Ref. to CL-29, CLUTCH SWITCH, INSTALLATION, Clutch Switch.>

Diagnostics with Phenomenon

CRUISE CONTROL SYSTEM (DIAGNOSTICS)

B: CHECK CRUISE INDICATOR LIGHT AND CRUISE SET INDICATOR LIGHT

TROUBLE SYMPTOM:

Cruise control can be set, but the CRUISE indicator and SET indicator do not illuminate.

Step	Check	Yes	No
1 CHECK CRUISE INDICATOR LIGHT AND CRUISE SET INDICATOR LIGHT. Check the combination meter. <Ref. to IDI-7, OPERATION, Combination Meter System.>	Do the CRUISE & SET indicators illuminate?	Go to step 2 .	Replace the meter case assembly. <Ref. to IDI-18, Combination Meter.>
2 CHECK LAN SYSTEM. Perform the diagnosis for LAN system. <Ref. to LAN(diag)-2, Basic Diagnostic Procedure.>	Is a DTC of the LAN system detected?	Perform the diagnosis according to DTC for LAN system.	Replace the ECM. <Ref. to FU(H4DO)-94, Engine Control Module (ECM).>