

# Airbag Warning Light Illumination Pattern


## OCCUPANT DETECTION SYSTEM (DIAGNOSTICS)

---

### 12. Airbag Warning Light Illumination Pattern

#### A: INSPECTION

Turn the ignition switch to ON, and confirm that the airbag warning light remains on for approx. 6 seconds and then goes off afterwards.



- (1) Airbag warning light
- (2) Approx. 6 sec.
- (3) Ignition switch ON