


## 35. Day Time Running Resistor

### A: REMOVAL

- 1) Remove the front bumper face assembly. <Ref. to EI-39, REMOVAL, Front Bumper.>
- 2) Remove the daytime running resistor.
  - (1) Disconnect the connector.
  - (2) Remove the bolt, and remove the daytime running resistor.



### B: INSTALLATION

Install each part in the reverse order of removal.

***Tightening torque:***

***Daytime running resistor: 13 N·m (1.33 kgf·m, 9.6 ft-lb)***