

SUBARU
SERIES

**Subaru Sambar English
Factory Service
Manual**

Truck & Van

**SAMBAR
660**

1990~2006

**V-KS3
V-KS4
V-KVS
V-KV4**

2WD & 4WD

James L. Danko

Subaru Sambar English Factory Service Manual

English Version

Full Version

**Truck & Van
Sambar 660cc
2WD &4WD**

AT-MT Models

Subaru Kei Vehicles Series

**Written By,
James Danko**

**Yokohama, Japan
First Edition 2008**

Contents

Chapter 1

Vehicle Identification.....Page 11~19

1. VIN Class Breakdown
2. Engine & Transmission Decoding
3. Engine-Transmission Combination Charts
4. VIN & Code Locations
5. Jacking Positions
6. Tire Size & Air Pressure Guide

Chapter 2

General Maintenance & Tune Up.....Page 20~35

1. Engine Specifications
2. Testing Equipment
3. Battery & Coolant
4. Oil & Filter Including Supercharger
5. Air & Fuel Filter
6. Spark Plugs
7. V- Belts
8. Valve Adjustment
9. Vacuum Hose
10. Distributor Point Settings
11. Timing
12. Idle Setting
13. CO-HC Levels and Adjustment
14. Engine Vacuum & Troubleshooting
15. Main Relay Location Guide

(Continued)

Chapter 3

Suspension.....Page 37~46

1. Front Suspension Components
2. Rear Suspension Components
3. Front and Rear Alignment
4. Camber & Caster Settings
5. Front Strut Removal & Replacement
6. Traverse Link
7. Rear Shock Absorber Remove & Replace

Chapter 4

Steering.....Page 47~60

1. Specifications and Diagram
2. Exploded Component View (Steering Column)
3. Exploded Component View (Rack & Pinion)
4. Steering Column Removal/Disassembly/Assemble/Install
5. Steering Gear Box
6. Rack & Pinion Overhaul
7. Tie Rods

Chapter 5

Brake System.....Page 61~76

1. Bleeding Brake System (Air)
2. Parking Brake Adjustment
3. Master Cylinder System
4. Brake Booster
5. Disk Brake & Caliper Overhaul
6. Rear Brake Drum System Overhaul
7. Parking Brake Cable System
8. Complete Brake Line System

(Continued)

Chapter 6

Engine Coolant & Cooling System.....Page 77~88

1. Coolant System Specifications and Capacities
2. Coolant System Components Diagram
3. Coolant System Radiator Components Diagrams
4. Engine Room Fan System
5. Troubleshooting Chart
6. Coolant Line Diagrams (Chassis Mount)
7. Water Pump
8. Engine Room Fan Circuit
9. Cooling Master Control Unit & Circuit

Chapter 7

Air – Fuel System – ExhaustPage 89~106

1. Air Intake System (Carbureted)
2. Air Intake System (Fuel Injected-Supercharged)
3. Air Cleaner and Air Intake Sensor
4. Intake Manifold (Carbureted)
5. Complete Fuel System Specifications
6. Carburetor Adjustments and Breakdown
7. Fuel Tank
8. Fuel System EMPi (Fuel Injected Vehicles)
9. Fuel Pump-Pressure Regulator-Knock Sensor
10. Fuel Injection-Air/Water Temp Sensors-O2 Sensor
11. Exhaust Truck-Van

Chapter 8

Starter & Alternator.....Page 107~112

1. Starter Specifications –Hitachi Series-Mitsubishi Series
2. Starter Overhaul Diagrams
3. Alternator Specifications- Mitsubishi Series-Denso Series
4. Alternator Diagram

(Continued)

Chapter 9

Engine & Transmission Removal.....Page 113~122

1. Complete Engine and Transmission Removal

Chapter 10

Engine Overhaul.....Page 123~148

1. Engine Disassembly
2. Block Inspection
3. Cylinder Inspection
4. Piston Inspection Including Oversize Pistons
5. Block Deck-Journal and Bore Sizes
6. Piston Rings and Installation Positioning
7. Connecting Rods
8. Crankshaft & Journals
9. Journal Details and Clearances
10. Crankshaft Oil Seals
11. Block Assembly
12. Piston Installation
13. Oil Pump
14. Cylinder Head and Timing Belt System
15. Valve Rocker Assembly
16. Camshaft Specifications and Clearances
17. Camshaft Installation & Oil Seal
18. Cylinder Head – Valve Springs- Valves
19. Valve Guides- Valve Details
20. Oil Pump Overhaul
21. Oil Pressure Switch

(Continued)

Chapter 11

Transmission and Differential 2WD – 4WD.....Page 149~170

1. Gear Shift System
2. TM 60 Series 2WD Clutch Housing – Main Case – Side Case
3. TM 60 Series 2WD Main Shaft-Drive Pinion- Reverse Idler Shaft
4. TM 60 Series 2WD Shift & Select System
5. TM 60 Series 2WD Differential
6. TM 60 Series Selective 4WD Transmission Case Assembly
7. TM 60 Series Selective 4WD Shifter and Selector System
8. TM 60 Series Selective 4WD Drive Pinion-Main Shaft-Reverse Idler
9. TM 60 4WD Differential
10. TM 60 4WD Diff-Lock Differential Option
11. TM 60 4WD Diff-Lock Side Cover Assembly
12. TM 60 Selective 4WD Transfer Extension
13. Clutch & Pressure Plate Specifications
14. Clutch System Diagram
15. Clutch Cable Adjustment
16. Release Bearing and Fork
17. Clutch Disk – Flywheel – Pressure Plate
18. Clutch Assembly
19. Axel Shaft System
20. Axel Shaft Identification and Type

Chapter 12

Electrical Diagrams and Schematics.....Page 171~

1. General Harness Locations
2. Truck Full Main Harness and Connection Codes
3. Connection Codes Explained (Truck-Van)
4. Van Full Main Harness and Connection Codes
5. Engine & Transmission Harness and Connections
6. Engine & Transmission Harness Code Breakdown
7. Front Component (Main) Harness Dash-Front Lighting
8. Front Component (Main) Connector Breakdown

(Continued)

Electrical Schematic Breakdowns

- 1. Turn Signal & Hazard**
- 2. Stop Lamp Circuit**
- 3. Lighting Circuit (Headlights-Running Lights)**
- 4. Lighting Circuit Tail Assemblies & Illumination Lamps**
- 5. Engine Control and Fuel Pump Circuits**
- 6. Charging System**
- 7. Engine Room and Radiator Fan (Van & Special Trucks)**
- 8. Engine Radiator Fan (Basic Vehicle)**
- 9. Radio (Audio) Circuits and Cigarette Lighter**
- 10. Fuel Gage & Sending Unit**
- 11. Full Time 4WD Control Circuits**
- 12. Selective 4WD Control Circuits**
- 13. Diff-Lock Control Circuits**
- 14. EMPi Engine Control Management System Part 1 (Fuel Injection)**
- 15. EMPi Engine Control Management System Part 2 (Fuel Injection)**
- 16. Windshield Wiper System Front and Rear**
- 17. Rear Defogger Circuit**