

2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is displayed in odo/trip meter.	<p>When and how often are they displayed?</p> <p><input type="checkbox"/> Always</p> <p><input type="checkbox"/> Sometimes</p> <p><input type="checkbox"/> Only once</p> <p>Which communication error is displayed? (Record them all)</p> <p><input type="checkbox"/> Er IU (Fail in the body integrated unit)</p> <p><input type="checkbox"/> Er HC (Fail of high-speed CAN)</p> <p><input type="checkbox"/> Er LC (Fail of low-speed CAN)</p> <p><input type="checkbox"/> Er — (Fails of both high-speed and low-speed CAN)</p> <p><input type="checkbox"/> Er EG (Fail of EGI communication data)</p> <p><input type="checkbox"/> Er TC (fail of TCM communication data)</p> <p><input type="checkbox"/> Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data)</p> <p><input type="checkbox"/> Er bb (Fail of brake vacuum system)</p>
Ignition key position	<p><input type="checkbox"/> OFF</p> <p><input type="checkbox"/> ACC</p> <p><input type="checkbox"/> ON (Before starting engine)</p> <p><input type="checkbox"/> START</p> <p><input type="checkbox"/> ON (After starting Engine, engine is running)</p> <p><input type="checkbox"/> ON (After starting Engine, engine is at a standstill)</p>
Timing	<p><input type="checkbox"/> Immediately after turning the ignition to ON.</p> <p><input type="checkbox"/> Immediately after turning the ignition to START.</p>

2. DISPLAY IN COMBINATION METER

Display in combination meter	a) Display of engine coolant temperature gauge	<input type="checkbox"/> OK / <input type="checkbox"/> NG
	b) Display of fuel gauge	<input type="checkbox"/> OK / <input type="checkbox"/> NG
Display of other indicators	c) Malfunction indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	d) SPORT indicator light (AT warning light)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	f) Security indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> Blink / <input type="checkbox"/> OFF
	g) Seat belt warning light (Driver's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	h) Seat belt warning light (Passenger's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF

Check List for Interview

LAN SYSTEM (DIAGNOSTICS)

3. SYMPTOMS

Behavior of vehicle	a) Illumination volume control is not available.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	b) Rear wiper does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	c) Wiper deicer does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	d) Rear defogger does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	e) Door lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	f) Trunk/rear gate lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	g) Driver's door lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	h) Shift lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	i) Key illumination blinks.	<input type="checkbox"/> Yes / <input type="checkbox"/> No

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	<div style="display: flex; justify-content: space-between;"> <div> <input type="checkbox"/> At standstill (While idling) <input type="checkbox"/> When the vehicle is running <input type="checkbox"/> Accelerating <input type="checkbox"/> Decelerating (With braking) <input type="checkbox"/> Decelerating (Without braking) </div> <div> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="flex: 1;">Vehicle speed</div> <div>km/h (MPH)</div> </div> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="flex: 1;">Acceleration</div> <div>km/h (MPH) to km/h (MPH)</div> </div> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="flex: 1;">Deceleration</div> <div>km/h (MPH) to km/h (MPH)</div> </div> <div style="display: flex; align-items: center;"> <div style="flex: 1;">Deceleration</div> <div>km/h (MPH) to km/h (MPH)</div> </div> </div> </div>
	<input type="checkbox"/> Flat road <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Gravel road <input type="checkbox"/> Bumpy road <input type="checkbox"/> Snowy road
	Does it occur when operating any part? Operated part: Trouble Symptom:
	Are there any other troubles occurred? From where: Trouble Symptom: