

2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is displayed in odo/trip meter.	When and how often are they displayed? <input type="checkbox"/> Always <input type="checkbox"/> Sometimes <input type="checkbox"/> Only once Which communication error is displayed? (Record them all) <input type="checkbox"/> Er IU (Fail in the body integrated unit) <input type="checkbox"/> Er HC (Fail of high-speed CAN) <input type="checkbox"/> Er LC (Fail of low-speed CAN) <input type="checkbox"/> Er — (Fails of both high-speed and low-speed CAN) <input type="checkbox"/> Er EG (Fail of EGI communication data) <input type="checkbox"/> Er TC (Fail of TCM communication data) <input type="checkbox"/> Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data) <input type="checkbox"/> Er bb (Fail of brake vacuum system)
Ignition key position	<input type="checkbox"/> OFF <input type="checkbox"/> ACC <input type="checkbox"/> ON (before starting engine) <input type="checkbox"/> START <input type="checkbox"/> ON (after starting engine, while engine is running) <input type="checkbox"/> ON (after starting engine, engine is stopped)
Timing	<input type="checkbox"/> Immediately after turning the ignition ON. <input type="checkbox"/> Immediately after turning the ignition to START.

2. DISPLAY STATUS IN THE COMBINATION METER

Display status in the combination meter	a) Engine coolant temperature gauge display	<input type="checkbox"/> OK / <input type="checkbox"/> NG
	b) Fuel gauge display	<input type="checkbox"/> OK / <input type="checkbox"/> NG
Display of other indicators	c) Malfunction indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	d) SPORT indicator light (AT warning light)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	f) Security indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> Blink / <input type="checkbox"/> OFF
	g) Seat belt warning light (Driver's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	h) Seat belt warning light (Passenger's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF

3. SYMPTOM

Vehicle condition	a) Lighting adjustment is not possible by the illumination volume control.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	b) Rear wiper does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	c) Wiper deicer does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	d) Rear defogger does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	e) All door locks do not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	f) Trunk/rear gate lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	g) Driver's door lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	h) Shift lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	i) Key illumination blinks.	<input type="checkbox"/> Yes / <input type="checkbox"/> No

Check List for Interview

LAN SYSTEM (DIAGNOSTICS)

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <input type="checkbox"/> At standstill (While idling) </div> <div style="width: 50%;"></div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <input type="checkbox"/> When the vehicle is running </div> <div style="width: 50%;">Vehicle speed km/h (MPH)</div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <input type="checkbox"/> While accelerating </div> <div style="width: 50%;">Acceleration km/h (MPH) to km/h (MPH)</div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <input type="checkbox"/> While decelerating (With braking) </div> <div style="width: 50%;">Deceleration km/h (MPH) to km/h (MPH)</div> </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <input type="checkbox"/> While decelerating (Without braking) </div> <div style="width: 50%;">Deceleration km/h (MPH) to km/h (MPH)</div> </div>
	<input type="checkbox"/> Flat road <input type="checkbox"/> Uphill <input type="checkbox"/> Downhill <input type="checkbox"/> Gravel road <input type="checkbox"/> Bumpy road <input type="checkbox"/> Snowy road
	Does it occur when operating any part? Operated part: Trouble symptom
	Are there any other troubles occurred? From where: Trouble symptom