

2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is displayed in odo/trip meter.	When and how often are they displayed? <input type="checkbox"/> Always <input type="checkbox"/> Sometimes <input type="checkbox"/> Only once
	Which communication error is displayed? (Record them all) <input type="checkbox"/> Er IU (Fail in the body integrated unit) <input type="checkbox"/> Er HC (Fail of high-speed CAN) <input type="checkbox"/> Er LC (Fail of low-speed CAN) <input type="checkbox"/> Er — (Fails of both high-speed and low-speed CAN) <input type="checkbox"/> Er EG (Fail of EGI communication data) <input type="checkbox"/> Er TC (Fail of TCM communication data) <input type="checkbox"/> Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data) <input type="checkbox"/> Er bb (Fail of brake vacuum system)
Ignition key position	<input type="checkbox"/> OFF <input type="checkbox"/> ACC <input type="checkbox"/> ON (before starting engine) <input type="checkbox"/> START <input type="checkbox"/> ON (after starting engine, while engine is running) <input type="checkbox"/> ON (after starting engine, engine is stopped)
Timing	<input type="checkbox"/> Immediately after turning the ignition ON. <input type="checkbox"/> Immediately after turning the ignition to START.

2. DISPLAY STATUS OF THE INDICATOR

Display status in the combination meter	a) Engine coolant temperature gauge display	<input type="checkbox"/> OK / <input type="checkbox"/> NG
	b) Fuel gauge display	<input type="checkbox"/> OK / <input type="checkbox"/> NG
Display of other indicators	c) Malfunction indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	d) SPORT indicator light (AT warning light)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	f) Security indicator light	<input type="checkbox"/> ON / <input type="checkbox"/> Blink / <input type="checkbox"/> OFF
	g) Seat belt warning light (Driver's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF
	h) Seat belt warning light (Passenger's seat)	<input type="checkbox"/> ON / <input type="checkbox"/> OFF

Check List for Interview

LAN SYSTEM (DIAGNOSTICS)

3. SYMPTOM

Vehicle condition	Key cannot be removed from key cylinder.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Key can be removed from any other than parking range.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Shift lever can not be operated.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Shift lock does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Driver's seat belt warning light does not illuminate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Passenger's seat belt warning light does not illuminate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Seat belt warning alarm does not sound.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Illumination volume control is not available.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Key illumination does not illuminate	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Key illumination is blinking	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Room light does not interlock with doors.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Room light blinks.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Map light does not interlock with doors	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Map light blinks.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Luggage light blinks.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Wiper deicer does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Rear defogger does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Meter does not dim when headlights are ON.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Rear wiper does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Can not be locked/unlocked with central door lock switch.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Can not be locked/unlocked with keyless entry system.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Rear gate does not open with rear gate release switch.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Hazard answer-back does not operate.	<input type="checkbox"/> Yes / <input type="checkbox"/> No
	Engine does not start.	<input type="checkbox"/> Yes / <input type="checkbox"/> No

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	<input type="checkbox"/> At standstill (While idling)	
	<input type="checkbox"/> When the vehicle is running	Vehicle speed km/h (MPH)
	<input type="checkbox"/> While accelerating	Acceleration km/h (MPH) to km/h (MPH)
	<input type="checkbox"/> While decelerating (With braking)	Deceleration km/h (MPH) to km/h (MPH)
	<input type="checkbox"/> While decelerating (Without braking)	Deceleration km/h (MPH) to km/h (MPH)
	<input type="checkbox"/> Flat road	
	<input type="checkbox"/> Uphill	
	<input type="checkbox"/> Downhill	
	<input type="checkbox"/> Gravel road	
	<input type="checkbox"/> Bumpy road	
	<input type="checkbox"/> Snowy road	
	Does it occur when operating any part?	
	Operated part:	
	Trouble symptom	
	Are there any other troubles occurred?	
	From where:	
	Trouble symptom	