

2. Check List for Interview

A: CHECK

Inspect the following item about the vehicle's state.

1. DISPLAY OF COMMUNICATION ERROR

Communication error is displayed in odo/trip meter.	When and how often are they displayed? ☐ Always ☐ Sometimes ☐ Only once
	Which communication error is displayed? (Record them all) ☐ Er IU (Fail in the body integrated unit) ☐ Er HC (Fail of high-speed CAN) ☐ Er LC (Fail of low-speed CAN) ☐ Er — (Fails of both high-speed and low-speed CAN) ☐ Er EG (Fail of EGI communication data) ☐ Er TC (Fail of TCM communication data) ☐ Er Ab (Fail of vehicle dynamics control (VDC)/ABS communication data) ☐ Er bb (Fail of brake vacuum system)
Ignition key position	☐ OFF ☐ ACC ☐ ON (before starting engine) ☐ START ☐ ON (after starting engine, while engine is running) ☐ ON (after starting engine, engine is stopped)
Timing	☐ Immediately after turning the ignition ON. ☐ Immediately after turning the ignition to START.

2. DISPLAY STATUS OF THE INDICATOR

Display status in the combination meter	a) Engine coolant temperature gauge display	☐ OK / ☐ NG
	b) Fuel gauge display	☐ OK / ☐ NG
Display of other indicators	c) Malfunction indicator light	☐ ON / ☐ OFF
	d) SPORT indicator light (AT warning light)	☐ ON / ☐ OFF
	e) ABS warning light/Vehicle dynamics control (VDC) warning light	☐ ON / ☐ OFF
	f) Security indicator light	☐ ON / ☐ Blink / ☐ OFF
	g) Seat belt warning light (Driver's seat)	☐ ON / ☐ OFF
	h) Seat belt warning light (Passenger's seat)	☐ ON / ☐ OFF

Check List for Interview

LAN SYSTEM (DIAGNOSTICS)

3. SYMPTOM

Vehicle condition	Key cannot be removed from key cylinder.	☐ Yes / ☐ No
	Key can be removed from any other than parking range.	☐ Yes / ☐ No
	Shift lever can not be operated.	☐ Yes / ☐ No
	Shift lock does not operate.	☐ Yes / ☐ No
	Driver's seat belt warning light does not illuminate.	☐ Yes / ☐ No
	Passenger's seat belt warning light does not illuminate.	☐ Yes / ☐ No
	Seat belt warning alarm does not sound.	☐ Yes / ☐ No
	Illumination volume control is not available.	☐ Yes / ☐ No
	Key illumination does not illuminate	☐ Yes / ☐ No
	Key illumination is blinking	☐ Yes / ☐ No
	Room light does not interlock with doors.	☐ Yes / ☐ No
	Room light blinks.	☐ Yes / ☐ No
	Map light does not interlock with doors	☐ Yes / ☐ No
	Map light blinks.	☐ Yes / ☐ No
	Luggage light blinks.	☐ Yes / ☐ No
	Wiper deicer does not operate.	☐ Yes / ☐ No
	Rear defogger does not operate.	☐ Yes / ☐ No
	Meter does not dim when headlights are ON.	☐ Yes / ☐ No
	Rear wiper does not operate.	☐ Yes / ☐ No
	Can not be locked/unlocked with central door lock switch.	☐ Yes / ☐ No
	Can not be locked/unlocked with keyless entry system.	☐ Yes / ☐ No
	Rear gate does not open with rear gate release switch.	☐ Yes / ☐ No
	Hazard answer-back does not operate.	☐ Yes / ☐ No
	Engine does not start.	☐ Yes / ☐ No

4. CONDITIONS UNDER WHICH TROUBLE OCCURS

Driving condition	☐ At standstill (While idling)	
	☐ When the vehicle is running	Vehicle speed km/h (MPH)
	☐ While accelerating	Acceleration km/h (MPH) to km/h (MPH)
	☐ While decelerating (With braking)	Deceleration km/h (MPH) to km/h (MPH)
	☐ While decelerating (Without braking)	Deceleration km/h (MPH) to km/h (MPH)
	☐ Flat road	
	☐ Uphill	
	☐ Downhill	
	☐ Gravel road	
	☐ Bumpy road	
	☐ Snowy road	
Does it occur when operating any part?		
Operated part:		
Trouble symptom		
Are there any other troubles occurred?		
From where:		
Trouble symptom		