



HEATED OXYGEN SENSOR INSPECTION

SF1ZD-01

INSPECT HEATED OXYGEN SENSOR (BANK1, BANK2 OXYGEN SENSOR)

Using an ohmmeter, measure the resistance between the terminals.

Resistance:

Terminal No.	Resistance
1 (HT) ⇔ 2 (+B)	5 to 10 Ω at 20 °C (68 °F)
1 (HT) ⇔ 4 (E1)	No Continuity

If the resistance is not as specified, replace the sensor.