

Engine & Cooling

Fuel

Ignition

Electrical

Running gear

Torque settings

Capacities

Notes & Illustrations



Automotive
Technical
DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system900 Turbo 16V1988 to 1990

Type		B202 2S DOHC 16V
Capacity (cm³) / number of cylinders		1985 / 4
Compression ratio / pressure	bar	9.0 / _
Oil pressure	bar	[3.0]
Oil temperature	°C	80
Valve clearance - inlet	mm	0: Hyd.
- exhaust	mm	0: Hyd.
Firing order		1-3-4-2
No 1 cylinder position		R
Thermostat opening temperature	°C	89±2
Radiator cap pressure	bar	0.9 to 1.2

Fuel system900 Turbo 16V1988 to 1990

Idle speed - manual [auto]	rpm	850±50 [875±50]
Fast idle speed - manual [auto]	rpm	_
CO @ idle speed [3000 rpm] - see page VI	%	0.9 to 1.6
HC @ idle speed [3000 rpm] - see page VI	ppm	≤1200
CO2 @ idle speed [3000 rpm] - see page VI	%	_
O2 @ idle speed [3000 rpm] - see page VI	%	_
Carburettor / fuel injection		Bosch
Type / ref		LH-Jetronic + Turbo APC
Main jet / needle		_
Injection pressure	bar	2.5±0.05 above m'fold
Pump pressure	bar	_
Octane rating	RON	_ [R] ¹

Ignition system900 Turbo 16V1988 to 1990

Type		Computerized
Ignition coil		Bosch
Primary resistance	ohms	0.52 to 0.76
Ballast resistor	ohms	_
Voltage - Tmnl 15(+) to earth	V	_
Distributor		Bosch
Points gap (air gap)	mm	[≥0.25]
Dwell angle	° (%)	_
Condenser capacity	µF	_
Rotation		Anticlockwise
Ignition timing - basic [static	° Crankshaft @ rpm	16 BTDC @ 850
V = Vacuum NV = No Vacuum		NV
Total ignition advance	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	_
	° Crankshaft @ rpm	_
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	_
Spark plugs		NGK/Champion
Type		BCP7EV / C7GY
Electrode gap	mm	0.70

Electrical system900 Turbo 16V1988 to 1990

Battery	V / CC / RC	12 / 62Ah
Alternator voltage / full load current / engine rpm		14.0 / _ / 2700
Starter motor current / voltage - cranking	A / V	205 to 315 / 9.0
- locked	A / V	450 to 750 / 4.0 to 6.0

Running gear900 Turbo 16V1988 to 1990

Brakes -		
Front (min. friction material thickness)	mm	1.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	195/60x15
Estate / Van	Size	_
Pressure - front / rear - Saloon	bar	2.1 / 2.2
- Estate / Van	bar	_

Front suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+1.5±0.5
Camber		+0.25°±0.25°
Castor		+2°±0.25°
King pin inclination		+11.5°±1°

Rear suspension / wheel alignment		
Toe-in (+) / Toe-out (-)	mm [°]	+4.0±2.0
Camber		-0.5°±0.25°

Torque wrench settings900 Turbo 16V1988 to 1990

Cylinder head - stage 1	Nm	M15 / Torx bolts: 60 ²
- stage 2	Nm	90 ²
- stage 3	Nm	Warm up, then cool, slacken ²
- stage 4	Nm	80 + 90 ^{o2}
Big-end bearings	Nm	55
Main bearings	Nm	110
Clutch cover	Nm	22±2
Flywheel [driveplate]	Nm	60
Front hubs	Nm	290 to 310
Rear hubs	Nm	290 to 310
Wheel nuts / bolts	Nm	90 to 110
Spark plugs	Nm	28

Capacities900 Turbo 16V1988 to 1990


Engine oil & filter	litres	4.3
Gearbox - 4-speed [5-speed]	litres	3.0
Automatic transmission - refill	litres	2.5 to 3.0
Final drive	litres	AT: 1.4
Cooling system	litres	10.0
Fuel tank	litres	63. 89 ►: 68

Notes and Illustrations


¹92 to 98, controlled by APC

²M15 hex head or M12 Torx head bolts only. M17 bolts: 1) 60, 2) 95, 3) Warm up, then cool down and slacken eachbolt in turn, 4) 95


1: Idle speed2: CO / Mixture



1985 cm³, 16V



1985 cm³, 16V



LH-Jetronic