

Denotes connector No.

The same connector No. is used throughout the circuit diagrams to facilitate connector location search.

The first alphabetical symbol indicates the location site of the connector and a number that follows is the unique number. Numbers are usually assigned to part in clockwise order on the diagram.

Example: A-19

Number specific to connector (serial number)

Connector location site symbol

A: Engine compartment

B: Instrument panel

C: Floor and roof

D: Door

E: Tailgate

Denotes earth point.

Same earth number is used throughout circuit diagrams to facilitate search of earth point.
Refer to GROUP 70 COMPONENT LOCATIONS - EARTH MOUNTING LOCATIONS for details of earth points.

Denotes harness name.

Denotes a section covered by a corrugated tube.

The mark ★ shows the standard mounting position of wiring harness.

Denotes the colour of the tube
(If not specified, it is black).
R: Red
Y: Yellow

The number of connector pins and the connector colour (except milk white)* are shown for ease of retrieval.

Example: (2-B)

Connector colour
(milk white if no colour is indicated)

Number of connector pins

*: Typical connector colours

B: Black	BR: Brown
Y: Yellow	V: Violet
L: Blue	O: Orange
G: Green	GR: Grey
R: Red	None: Milk white

A-19

1

Front wiring harness (RH)

A-18

A-17

A-16

A-15

A-15 (2)
A-16 (2-GR)
A-17 (2-B)
A-18 (2-B)
A-19 (2-GR)

Fog lamp (RH)
Horn (LO)
Headlamp (RH)
Windshield washer motor
Dual pressure switch

Indicates the device to which the connector is connected.