

## 6. Switches and Harness

### A: NOTE

#### 1. P-CR OFF & LANE OFF SWITCH

The pre-collision brake OFF & lane departure warning OFF switch is integrated in the stereo camera cover assembly.


If the pre-collision brake OFF & lane departure warning OFF switch is faulty, replace the stereo camera cover assembly.<Ref. to ES-11, Stereo Camera.>

### B: INSPECTION


1) Remove the stereo camera cover assembly.

2) Check the resistance between the terminals of the pre-collision brake OFF switch or the lane departure warning OFF switch.

- Pre-collision brake OFF switch

Terminal No.	Inspection conditions	Standard	Connector Sketch
3 — 5	OFF	1 M $\Omega$ or more	 <p>ADA00413</p>
	ON	Less than 1 $\Omega$	

- Lane departure warning OFF switch

Terminal No.	Inspection conditions	Standard	Connector Sketch
4 — 5	OFF	1 M $\Omega$ or more	 <p>ADA00414</p>
	ON	Less than 1 $\Omega$	

3) If the result of the inspection is not within the standard value, replace the stereo camera cover assembly.