

GENERAL DESCRIPTION

Lighting System

1. General Description

S914001

A: SPECIFICATIONS

S914001E49

Headlight	12 V — 60/55 W (Halogen)	
Front fog light	12 V — 55 W	
Front turn signal light	12 V — 27 W	
Side turn signal light	12 V — 3.8 W	
Side marker/Parking light	12 V — 3.8 W	
Rear combination light	Tail/Stop light	12 V — 8/27 W
	Turn signal light	12 V — 27 W
	Back-up light	12 V — 27 W
License plate light	12 V — 3.8 W	
High-mount stop light	Sedan: 12 V — 18 W	Wagon: 12 V — 13 W
Room light	12 V — 8 W	
Spot light	12 V — 8 W	
Trunk room light	12 V — 5 W	
Luggage room light	12 V — 5 W	

B: PRECAUTIONS

S914001E59

- Before disassembling or reassembling parts, always disconnect battery ground cable. When replacing radio, control module, and other parts provided with memory functions, record memory contents before disconnecting the battery ground cable. Otherwise, the memory will be erased.
- Reassemble in reverse order of disassembly, unless otherwise indicated.
- Adjust parts to the given specifications.
- Connect connectors and hoses securely during reassembly.
- After reassembly, make sure functional parts operate smoothly.

WARNING:

- Air bag system wiring harness is routed near electrical parts and switches. All air bag system wiring harnesses and connectors are yellow. Do not use electric test equipment on these circuits.
- Be careful not to damage the air bag system wiring harness when servicing electrical parts and switches.

C: PREPARATION TOOL

S914001A17

1. GENERAL TOOL

S914001A1701

TOOL NAME	REMARKS
Circuit Tester	Used for measuring resistance, voltage and ampere.