

GENERAL DESCRIPTION

LIGHTING SYSTEM

1. General Description

A: SPECIFICATIONS

Headlight			12 V — 55 W/65 W (Halogen)
Front turn signal light			12 V — 21 W
Side marker light			12 V — 5 W
Parking light			12 V — 5 W
Front fog light			12 V — 55 W (Halogen)
Rear combination light	Sedan	Tail/Stop light	12 V — 21 W/5 W
		Tail light	12 V — 21 W/5 W
		Stop light	12 V — 21 W
		Turn signal light	12 V — 21 W
		Back-up light	12 V — 21 W
Rear combination light	Wagon	Tail/Stop light	12 V — 21 W/5 W
		Turn signal light	12 V — 21 W
		Back-up light	12 V — 21 W
		Side marker light	12 V — 5 W
License plate light			12 V — 5 W
High-mounted stop light	Sedan		12 V — 21 W
	Wagon		12 V — 13 W
Room light			12 V — 8 W
Spot light			12 V — 8 W
Luggage room light			12 V — 13 W
Trunk room light			12 V — 5 W
Glove box light			12 V — 1.4 W

B: PRECAUTIONS

- Before disassembling or reassembling parts, always disconnect the battery ground cable. When replacing the radio, control module, and other parts provided with memory functions, record the memory contents before disconnecting the battery ground cable. Otherwise, the memory will be erased.
- Reassemble in reverse order of disassembly, unless otherwise indicated.
- Adjust parts to the given specifications.
- Connect the connectors and hoses securely during reassembly.

- After reassembly, make sure functional parts operate smoothly.

WARNING:

- The air bag system wiring harness is routed near electrical parts and switches. All air bag system wiring harnesses and connectors are yellow. Do not use an electric test equipment on these circuits.**
- Be careful not to damage the air bag system wiring harness when servicing electrical parts and switches.**

C: PREPARATION TOOL

1. GENERAL TOOLS

TOOL NAME	REMARKS
Circuit Tester	Used for measuring resistance and voltage.