

### 7. Interior Light System

#### A: SCHEMATIC


##### 1. INTERIOR LIGHT

<Ref. to WI-106, SCHEMATIC, In Compartment Light System.>

#### B: INSPECTION

##### 1. DOOR SWITCH

Measure the door switch resistance.



| Switch position     | Terminal No. | Standard      |
|---------------------|--------------|---------------|
| When door is opened | 1 and 3      | Less than 1Ω  |
| When door is closed |              | More than 1MΩ |

##### 2. REAR GATE LATCH SWITCH

Measure the rear gate latch switch resistance.

| Switch position          | Terminal No. | Standard      |
|--------------------------|--------------|---------------|
| When rear gate is opened | 1 and 2      | Less than 1Ω  |
| When rear gate is closed |              | More than 1MΩ |

##### 3. TRUNK ROOM LIGHT SWITCH

Measure the trunk room light switch resistance.

| Switch position          | Terminal No. | Standard      |
|--------------------------|--------------|---------------|
| When trunk lid is opened | 1 and 2      | Less than 1Ω  |
| When trunk lid is closed |              | More than 1MΩ |